



# 5300 Series DustPruf Curve Conveyors

Installation, Maintenance and Parts Manual



Featuring: *SmartSlot*<sup>™</sup>

DORNER MFG. CORP.  
P.O. Box 20 • 975 Cottonwood Ave.  
Hartland, WI 53029-0020 USA

INSIDE THE USA  
TEL: 1-800-397-8664  
FAX: 1-800-369-2440

OUTSIDE THE USA  
TEL: 262-367-7600  
FAX: 262-367-5827

For other service manuals visit our website at:  
[www.dorner.com/service\\_manuals.asp](http://www.dorner.com/service_manuals.asp)

# Table of Contents

Introduction .....	2	Replacing a Section of Belt .....	15
Warnings – General Safety .....	3	Replacing the Entire Belt .....	16
Product Description .....	4	Conveyor Belt Tensioning .....	16
Specifications .....	4	Wear Strips .....	16
5300 Series Curve Conveyor Modules .....	5	Removal of Upper Wear Strips .....	17
5300 Series Infeed / Idler Module .....	5	Removal of Lower and Side Wear Strips .....	17
5300 Series Curve Module .....	5	Removal of Belt Returns .....	18
5300 Series Intermediate Module .....	5	Installation .....	18
5300 Series Exit / Drive Module .....	5	Spindle Removal .....	18
LPZ 5300 Series Curve Conveyor		A - Drive Spindle Removal .....	19
(Infeed Section to Knuckle) .....	5	B - Nose Bar Drive Spindle Removal .....	20
LPZ 5300 Series Curve Conveyor		C - Idler Spindle Removal .....	23
(Infeed Section to Curve) .....	5	D - Nose Bar Idler Spindle Removal .....	24
LPZ 5300 Series Curve Conveyor		Spindle Replacement .....	26
(Mid Section Between Knuckle and Curve) .....	6	Drive Spindle .....	26
LPZ 5300 Series Curve Conveyor		Nose Bar Drive Spindle .....	26
(Mid Section Between Knuckles) .....	6	Idler Spindle .....	26
LPZ 5300 Series Curve Conveyor (Curve Section) .....	6	Nose Bar Idler Spindle .....	26
LPZ 5300 Series Curve Conveyor		Bearing Replacement .....	26
(Discharge Section from Curve) .....	6	Drive Bearing Removal and Replacement .....	26
LPZ 5300 Series Curve Conveyor		Removal .....	26
(Discharge Section from Knuckle) .....	6	Replacement .....	26
Conveyor Supports .....	7	Maintenance of Knuckles .....	27
Installation .....	8	Guides .....	27
Required Tools .....	8	Lower Knuckle .....	27
Recommended Installation Sequence .....	8	Upper Knuckle .....	28
Conveyor Sections Longer than 12 ft (3658 mm) .....	8	Service Parts .....	30
Connecting Components .....	8	Drive End Components .....	30
LPZ Conveyors .....	9	Nose Bar Drive End Components .....	31
Upper Knuckle .....	9	Idler End Components .....	32
Lower knuckle .....	9	Nose Bar Idler End Components .....	33
All Conveyors .....	10	Frame Assembly .....	34
Curve Connecting Components .....	10	Upper Knuckle .....	35
Stand Installation .....	10	Lower Knuckle .....	36
Belt Installation .....	11	Curve Conveyor Frame and Wear Strips .....	37
Typical Belt Components .....	11	1.5" (38 mm) High Sides .....	38
Proper Methods of Attachment to Side Rails .....	12	3" (76 mm) High Sides .....	39
Self-Drilling Screws .....	12	Fully Adjustable Guiding .....	40
Pre-Drill for Standard Screws .....	13	Tool-Less Fully Adjustable Guiding .....	41
Guiding .....	14	1.5" (38 mm) High Sides for Curve Module .....	42
Drive Package Installation .....	14	3" (76 mm) High Sides for Curve Module .....	43
Preventive Maintenance and Adjustment .....	15	Fully Adjustable Guiding for Curve Module .....	44
Required Tools .....	15	Tool-Less Fully Adjustable Guiding for Curve Module .....	45
Checklist .....	15	Flat Belt Returns .....	46
Lubrication .....	15	Stand Mount Kit .....	47
Maintaining the Conveyor Belt .....	15	Ordering a Replacement Chain .....	47
Troubleshooting .....	15	Flat Belt Chain Repair Kit .....	47
Conveyor Belt Replacement .....	15	Return Policy .....	48

## Introduction



### CAUTION

**Some illustrations may show guards removed. DO NOT operate equipment without guards.**


Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage. Accessories may be shipped loose.
- See accessory instructions for installation.

The Dorner Limited Warranty applies.

Dorner 5300 Series conveyors have patents pending.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits logo .

## Warnings – General Safety

### **DANGER**



#### **SEVERE HAZARD!**

**KEEP OFF CONVEYORS.** Climbing, sitting, walking or riding on conveyor will result in death or serious injury.

### **DANGER**



#### **EXPLOSION HAZARD!**

- **DO NOT OPERATE CONVEYORS IN AN EXPLOSIVE ENVIRONMENT.** The electric gearmotor generates heat and could ignite combustible vapors.
- Failure to comply will result in death or serious injury.

### **WARNING**



#### **CRUSH HAZARD!**

- **DO NOT** place hands or fingers inside the conveyor while it is running.
- **DO NOT** wear loose garments while operating the conveyor. Loose garments can become caught up in the conveyor.
- Failure to comply could result in serious injury.

### **WARNING**



#### **CRUSH HAZARD!**

- **SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.**
- Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing serious injury.

### **WARNING**



#### **SEVERE HAZARD!**

**LOCK OUT POWER** before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

### **WARNING**



#### **BURN HAZARD!**

**DO NOT TOUCH** the motor while operating, or shortly after being turned off. Motors may be **HOT** and can cause serious burn injuries.

### **WARNING**



#### **PUNCTURE HAZARD!**

Handle drive shaft keyway with care. It may be sharp and could puncture the skin, causing serious injury.

### **WARNING**



#### **SEVERE HAZARD!**


- Dorner cannot control the physical installation and application of conveyors. Taking protective measures is the responsibility of the user.
- When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, **CHECK FOR POTENTIAL PINCH POINTS** and other mechanical hazards before system start-up.
- Failure to comply could result in serious injury.

# Product Description

Refer to **(Figure 1)** for typical conveyor components.

## Typical Components

- 1 Conveyor
- 2 Gearmotor
- 3 Belt (Flat Belt Shown)
- 4 Motor Controller
- 5 Drive End
- 6 Idler End



**Figure 1**

# Specifications

Flat Belt Conveyor Width Reference ( <u>WW</u> )	08 - 36 in 02 increments
Flat Belt Conveyor Belt Width	8" (203 mm) - 36" (914 mm) in 2" (51 mm) increments
LPZ Conveyor Width Reference ( <u>WW</u> )	08 - 24 in 02 increments
LPZ Conveyor Belt Width	8" (103 mm) - 24" (610 mm) in 2" (51 mm) increments
Maximum Conveyor Load	20 lbs. / ft <sup>2</sup> (97 kg/ m <sup>2</sup> ) with a maximum of 500 lbs. (227 kg)
Belt Travel	12" (305 mm) per revolution of pulley
Maximum Belt Speed	250 ft/minute (76 m/minute)

Conveyor Module Length Reference ( <u>LLL</u> )	021 - 999 in 001 increments
Conveyor Module Length	21" (533 mm) - 999" (25.4 m) in 1" (25 mm) increments
LPZ Section Length ( <u>LLL</u> )	024 - 288 in 001 increments
LPZ Section Length	24" (610 mm) - 288" (7315 mm) in 1" (25 mm) increments


## IMPORTANT

*Maximum conveyor loads are based on:*


- *Non-accumulating product*
- *Product moving toward gearmotor*
- *Conveyor being mounted horizontally*
- *Conveyor being located in a dry environment*
- *Conveyor equipped with standard belt only*

## 5300 Series Curve Conveyor Modules


### 5300 Series Infeed / Idler Module




### 5300 Series Exit / Drive Module




### 5300 Series Curve Module




### LPZ 5300 Series Curve Conveyor (Infeed Section to Knuckle)



### 5300 Series Intermediate Module




### LPZ 5300 Series Curve Conveyor (Infeed Section to Curve)




# Specifications


## LPZ 5300 Series Curve Conveyor (Mid Section Between Knuckle and Curve)




## LPZ 5300 Series Curve Conveyor (Discharge Section from Curve)




## LPZ 5300 Series Curve Conveyor (Mid Section Between Knuckles)



## LPZ 5300 Series Curve Conveyor (Discharge Section from Knuckle)



## LPZ 5300 Series Curve Conveyor (Curve Section)



## Conveyor Supports

### Infeed / Idler Module:

- “A” = 3 ft (914 mm) maximum (See Figure 2)
- Modules 24" - 47" long get 1 support stand
- All other lengths get 2 support stands, evenly spaced, plus an additional support stand at each straight section break (over 13' straight frame module)

### Intermediate Module:

- Modules 24" - 59" long get 1 support stand
- All other lengths get 2 support stands, evenly spaced, plus an additional support stand at each straight section break (modules over 13')

### Exit / Drive Module:

- “B” = 3 ft (914 mm) maximum (See Figure 2)
- Modules 24" - 47" long get 1 support stand
- All other lengths get 2 support stands, evenly spaced, plus an additional support stand at each straight section break (modules over 13')

### Curve Module:

- Reference chart for support stand quantities, evenly spaced along curve (see chart).

Width Degree	8"	10"	12"	14"	16"	18"	20"	22"	24"	26"	28"	30"	32"	34"	36"
45°	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1
90°	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2
135°	1	1	1	1	1	1	2	2	2	2	2	2	2	3	3
180°	1	1	1	2	2	2	2	2	2	3	3	3	3	3	3




Figure 2

# Installation

## ⚠ CAUTION

Conveyor **MUST** be mounted straight, flat and level within confines of conveyor. Use a level (Figure 3, item 1) during setup.




Figure 3

## Required Tools

- Level
- Torque wrench
- 4 mm hex wrench
- 5 mm hex wrench

## Recommended Installation Sequence

1. Assemble the conveyor (if required). Refer to “Conveyor Sections Longer than 12 ft (3658 mm)” on page 8 and “All Conveyors” on page 10.
2. Attach the stands. Refer to “Stand Installation” on page 10.
3. Install the belt. Refer to “Belt Installation” on page 11.
4. Install the guiding. Refer to “Guiding” on page 14.
5. Install the gearmotor. Refer to “Drive Package Installation” on page 14.

## Conveyor Sections Longer than 12 ft (3658 mm)

### Connecting Components

Typical Connecting Components (Figure 4)




Figure 4

1	Clamp Plate
2	Conveyor frames
3	Low Head Cap Screw, M8 - 1.25 x 16 mm

1. Locate and arrange conveyor sections by section labels (Figure 5, item 1).




Figure 5

2. Install two clamp plates (Figure 4, item 1) into one conveyor section (Figure 4, item 2) by lining up two holes in clamp plate with two holes in conveyor frame. Install two M8x16 low head cap screws (Figure 4, item 3) to secure each clamp plate.
3. Join both conveyor sections, and secure with two M8x16 low head cap screws (Figure 4, item 3) on both sides. Tighten all cap screws to 84 in-lb (9 Nm).


## LPZ Conveyors

### NOTE

*Be sure all frame sections are properly supported during LPZ assembly.*


### Upper Knuckle

1. Be sure that the upper edge wearstrip (**Figure 6, item 1**) and the return strip (**Figure 6, item 2**) are inserted into the proper frame channel on each side of conveyor.



**Figure 6**

2. Attach upper knuckle (**Figure 7, item 1**) to frame (**Figure 7, item 2**) with socket head screws (**Figure 7, item 3**). Repeat on other side.




**Figure 7**

3. Tighten all screws to 60 in-lb (7 Nm).


### Lower knuckle

1. Be sure that the return strip (**Figure 8, item 1**) is inserted into the proper frame channel on each side of conveyor.



**Figure 8**

2. Attach lower knuckle (**Figure 9, item 1**) to frame (**Figure 9, item 2**) by using socket head screws (**Figure 9, item 3**). Repeat on other side.



**Figure 9**

3. Tighten all screws to 60 in-lb (7 Nm).


# Installation

## All Conveyors

### Curve Connecting Components


Typical Curve Connecting Components (**Figure 10**)

- |   |                                       |
|---|---------------------------------------|
| 1 | Clamp Plate                           |
| 2 | Conveyor frames                       |
| 3 | Low Head Cap Screw, M8 - 1.25 x 16 mm |



**Figure 10**

1. Locate and arrange conveyor sections by section labels (**Figure 11, item 1**).



**Figure 11**

2. Install two clamp plates (**Figure 10, item 1**) into one conveyor section (**Figure 10, item 2**) by lining up two holes in clamp plate with two holes in conveyor frame. Install two M8x16 low head cap screws (**Figure 10, item 3**) to secure each clamp plate.
3. Join both conveyor sections, and secure with two M8x16 low head cap screws (**Figure 10, item 3**) on both sides. Tighten all cap screws to 84 in-lb (9 Nm).


## Stand Installation

### NOTE

*For detailed assembly instructions, please see your appropriate support stand manual.*


Typical stand components (**Figure 12**)

- |   |  |
|---|--|
| 1 | Conveyor Frame                               |
| 2 | Stand  |
| 3 | M6 - 1.0 x 20 mm socket head cap screws (x4) |



**Figure 12**

1. Properly support the conveyor.
2. Attach stands (**Figure 13, item 1**) to the bottom of the conveyor frame (**Figure 13, item 2**). Tighten socket head screws (**Figure 13, item 3**), on each side, to secure in place.




**Figure 13**

## Belt Installation


Typical Belt Components (Figure 14).

1	Chain Belt
2	Belt Rod



**Figure 14**

1. Position the belt on the conveyor frame.
2. Orient the belt direction such that the pin heads (Figure 15, item 1) are on the outside of the belt radius (Figure 15, item 2). The straight portion on the pin (Figure 15, item 3) will be on the inside radius.




**Figure 15**

### NOTE


*For "S" shaped conveyors, the pin heads must be oriented on the outside of the belt radius on the exiting or last curve on the conveyor.*

3. Wrap belt around idler tail (Figure 16, item 1).




**Figure 16**

4. Install belt around lower frame section and above lower wear strips (Figure 16, item 2).
5. On curve conveyors, install belt through wear strip (Figure 17, item 1) and install wear strip (Figure 17, item 2) on straight conveyor sections before installing and connecting belt.



**Figure 17**


6. Wrap the belt around the drive end of the conveyor, making sure the sprocket teeth have engaged the belt, with concave teeth (Figure 18, item 1) mating with rounded section (Figure 18, item 2) of belt.



**Figure 18**


# Installation

7. Bring the ends of the belt together (**Figure 19**).




**Figure 19**

8. Insert the belt rod (**Figure 20**, item 1).





**Figure 20**

9. Push the belt rod in as far as possible.
10. Lightly tap the head of the rod with a hammer until it snaps into position.
11. Lift belt off of frame and insert each edge strip (**Figure 21**, item 1) into side tabs of belt. Set belt and edge strips back into frame.



**Figure 21**

## Proper Methods of Attachment to Side Rails


 <b>WARNING</b>

<p><b>PUNCTURE HAZARD!</b> Installing self-drilling screws into the dustpruf side rail requires substantial force. Failure to properly support the conveyor while installing self-drilling screws may cause the operator or conveyor to slip, causing severe injury.</p> <p><b>SUPPORT CONVEYOR FRAMES WHILE INSTALLING SELF-DRILLING SCREWS.</b></p>

The 5300 DustPruf side rail is designed for self-drilling attachment of brackets and accessories. This can be done in two methods: self-drilling screws or pre-drill for standard screws.

### Self-Drilling Screws

All Dorner accessories are provided with 1/4-20 self-drilling screws.


1. Locate guide (**Figure 22**, item 1) and retaining clip (**Figure 22**, item 2) and hold to side rail. Hole should line up with notch (**Figure 22**, item 3) in side rail.



**Figure 22**

2. With a cordless drill or equivalent install self-drilling screw (**Figure 22**, item 4). Use high speed setting to drill through side wall. Once the tap portion is started switch drill power to a lower speed. Do not fully tighten with drill.

3. Hand tighten the screws to secure (**Figure 23**). Recommended torque is 150 in-lb (17 Nm).




**Figure 23**

## Pre-Drill for Standard Screws


The DustPruf side rail will also accept standard screws. M6-1.0 and 1/4-20 are acceptable. Strength grade 8 is recommended.

1. Locate guide (**Figure 24, item 1**) and retaining clip (**Figure 24, item 2**) and hold to side rail. Hole should line up with notch (**Figure 24, item 3**) in side rail. Mark the hole locations with a center punch (**Figure 24, item 4**) and remove the bracket.




**Figure 24**

2. Drill the hole locations (**Figure 25, item 1**) with a 3/16" drill bit (**Figure 25, item 2**).



**Figure 25**

3. Position and hold bracket (**Figure 26, item 1**) to side rail. With a standard M6-1.0 or 1/4-20 screw, install screws (**Figure 26, item 2**) with cordless drill or equivalent. Do not fully tighten with drill.



**Figure 26**



4. Hand tighten the screws to secure (**Figure 27**). Recommended torque is 150 in-lb (17 Nm).



**Figure 27**


# Installation

## Guiding

 <b>WARNING</b>

<p><b>PUNCTURE HAZARD!</b> Installing self-drilling screws into the dustpruf side rail requires substantial force. Failure to properly support the conveyor while installing self-drilling screws may cause the operator or conveyor to slip, causing severe injury. <b>SUPPORT CONVEYOR FRAMES WHILE INSTALLING SELF-DRILLING SCREWS.</b></p>

Due to the DustPruf construction ALL guiding must be located and installed by the end user. Take care in locating retaining clips prior to final installation.

1. Lay out retaining clip (**Figure 28, item 1**) locations. The end clips should be no greater than 12" from end of the conveyor. Hole should line up with notch (**Figure 28, item 2**) in side rail.




**Figure 28**

2. Hold guide (**Figure 28, item 3**) and retaining clip (**Figure 28, item 1**) to conveyor side rail. Install self-drilling screws (**Figure 28, item 4**) following the "Proper Methods of Attachment to Side Rails" on page 12 procedure.

## Drive Package Installation

<b>NOTE</b>
<i>For detailed assembly instructions, refer to the appropriate Drive Packages Installation, Maintenance and Parts Manual.</i>

1. Attach the motor (**Figure 29, item 1**) to the gear reducer (**Figure 29, item 2**). (End Drive shown below.)



**Figure 29**

# Preventive Maintenance and Adjustment

## Required Tools

- 4 mm hex wrench
- 5 mm hex wrench
- 6 mm hex wrench
- 8 mm hex wrench
- Punch and hammer (to remove belt rod)

## Checklist

- Keep service parts on hand. Refer to the "Service Parts" section starting on page 30 for recommendations.
- Replace any worn or damaged parts.

## Lubrication

No lubrication is required. Replace bearings if worn.

## Maintaining the Conveyor Belt

## Troubleshooting

### NOTE

Visit [www.dorner.com](http://www.dorner.com) for complete list of troubleshooting solutions.

Inspect conveyor belt for:

- Surface cuts or wear
- Skipping

Damage to belt links or rods, surface cuts and / or wear indicate:

- Sharp or heavy parts impacting belt
- Jammed parts
- Accumulated dirt
- Foreign material inside the conveyor
- Improperly positioned accessories

Skipping indicates:

- Excessive load on belt
- Worn spindle or impacted dirt on drive spindle

## Conveyor Belt Replacement



### WARNING




### SEVERE HAZARD!

**LOCK OUT POWER** before removing guards or performing maintenance. Exposed moving parts can cause serious injury.


## Replacing a Section of Belt

1. Lift belt off of frame and remove each edge strip (**Figure 30, item 1**) from side tabs of belt.



**Figure 30**

2. Use a punch and hammer to push the belt rod (**Figure 31, item 1**) out by striking the rod end opposite the retaining head.



**Figure 31**

# Preventive Maintenance and Adjustment

## ⚠ WARNING



### SEVERE HAZARD!

If conveyor belt is damaged or worn, replace belt section.

3. Remove the belt rods on both sides of the section of belt being replaced.
4. Replace old section of belt.

## ⚠ CAUTION

DO NOT reuse belt rods that are damaged or show signs of wear.

## Replacing the Entire Belt

1. Lift belt off of frame and remove each edge strip (Figure 32, item 1) from side tabs of belt.




Figure 32

2. Use a punch and hammer to push the belt rod (Figure 33, item 1) out by striking the rod end opposite the retaining head.




Figure 33

3. Slide the old belt (Figure 33, item 2) off the conveyor frame.
4. Replace the old belt with a new one. Refer to "Belt Installation" on page 11.

## ⚠ CAUTION

DO NOT reuse belt rods that are damaged or show signs of wear.

## Conveyor Belt Tensioning

## ⚠ WARNING



### SEVERE HAZARD!

LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

## NOTE

*Belt should not be stretched during installation. A proper length of belt can be installed by interlocking the ends by hand without excess links.*

1. Remove one or more belt links to take up tension. Refer to "Replacing a Section of Belt" on page 15.

## Wear Strips

Replace the wear strips if they become worn.

Typical Standard Wear Strips (Figure 34)

- |   |   |
|---|---|
| 1 | Wear Strips, Side                         |
| 2 | Wear Strips, Upper - Belt Running Surface |
| 3 | Wear Strips, Lower - Belt Return Surface  |




Figure 34


# Preventive Maintenance and Adjustment

## Removal of Upper Wear Strips

1. Remove belt. See “Conveyor Belt Replacement” on page 15.
2. Remove inner spacer (**Figure 35, item 1**) from top of frame assembly.

### NOTE

The upper wearstrips (**Figure 35, item 2**) have a screw (**Figure 35, item 3**) on end of wearstrip that is retained by the inner spacers (**Figure 35, item 1**).




**Figure 35**

3. Remove upper wear strips (**Figure 35, item 2**).


## Removal of Lower and Side Wear Strips

1. Remove conveyor idler end (**Figure 36, item 1**). See “C - Idler Spindle Removal” on page 23.



**Figure 36**

2. Slide lower wear strips (**Figure 37, item 1**), and raise wear strips (**Figure 37, item 2**) from frame assembly.




**Figure 37**

3. Slide lower curve wear strips (**Figure 38, item 1**), and upper wear strips (**Figure 38, item 2**) from curve frame assembly.

### NOTE

These wearstrips extend 3" beyond frame on each end.



**Figure 38**


# Preventive Maintenance and Adjustment

## Removal of Belt Returns

Replace the wear strips if they become worn.


Typical Standard Wear Strips (**Figure 39**)

- |   |                        |
|---|------------------------|
| 1 | Return Support Bracket |
| 2 | Return Strip           |




**Figure 39**

1. Remove return strips (**Figure 40, item 1**), from brackets (**Figure 40, item 2**).



**Figure 40**

2. If necessary, rotate upward and remove bracket (**Figure 41, item 1**), from frame channel (**Figure 41, item 2**).




**Figure 41**

## Installation

### NOTE

*The rounded ends of top wear strips (**Figure 42, item 1**) faces the idler end (**Figure 42, item 2**) of the conveyor.*



**Figure 42**

Install components reverse of removal.

## Spindle Removal

### ⚠ WARNING



#### SEVERE HAZARD!

**Exposed moving parts can cause severe injury. LOCK OUT POWER before removing guards or performing maintenance.**

Remove conveyor belt to access spindle(s). See “Replacing the Entire Belt” on page 16. Remove the desired spindle following the corresponding instructions below:


- **A** - Drive Spindle Removal
- **B** - Nose Bar Drive Spindle Removal
- **C** - Idler Spindle Removal
- **D** - Nose Bar Idler Spindle Removal

# Preventive Maintenance and Adjustment

## A - Drive Spindle Removal




1. Remove the gearmotor. For detailed instructions, refer to the appropriate drive package manual.
2. Remove the two socket head screws (Figure 43, item 1). Repeat on opposite side.




**Figure 43**

3. Remove the drive tail assembly (Figure 44, item 1) from the frame (Figure 44, item 2).




**Figure 44**

4. Remove the four socket head screws (Figure 45, item 1) and cover (Figure 45, item 2).




**Figure 45**

5. Loosen set screw (Figure 46, item 1) and remove clamp collar (Figure 46, item 2).



**Figure 46**


6. Remove end plate (Figure 47, item 1) from shaft (Figure 47, item 2).



**Figure 47**


# Preventive Maintenance and Adjustment

- Slide entire sprocket assembly slightly outward, and remove the first sprocket (**Figure 48, item 1**) off the drive spindle (**Figure 48, item 2**) and alignment bar (**Figure 48, item 3**).



**Figure 48**


- Remove remaining sprockets (**Figure 48, item 4**) off the alignment bar as you slide entire assembly off the drive spindle.
- To assemble sprockets onto drive spindle, slide one sprocket onto alignment bar and slide assembly onto drive spindle.
- Install second sprocket and subsequent sprockets (**Figure 48, item 4**) one by one, while sliding entire assembly onto alignment bar (**Figure 48, item 3**) and spindle (**Figure 48, item 2**).
- Check drive terminal assembly (**Figure 49, item 1**) for wear. If worn, remove two low head cap screws (**Figure 49, item 2**) and replace.



**Figure 49**

## NOTE

When reinstalling the drive spindle tail assembly, the drive tail assembly (**Figure 50, item 1**) should mate flush with the conveyor frame (**Figure 50, item 2**).



**Figure 50**

## B - Nose Bar Drive Spindle Removal




## WARNING



Drive shaft keyway may be sharp. **HANDLE WITH CARE.**


- Remove the gearmotor. For detailed instructions, refer to the appropriate drive package manual.
- Remove two socket head bolts (**Figure 51, item 1**) on each side of drive tail assembly (**Figure 51, item 2**).



**Figure 51**


# Preventive Maintenance and Adjustment

3. Remove the drive tail assembly (Figure 52, item 1) from the frame (Figure 52, item 2).



**Figure 52**

4. Remove wear strips, (Figure 52, item 3), as necessary.
5. Remove two socket head screws (Figure 53, item 1) on both sides of the conveyor.




**Figure 53**

6. Remove pinch guard (Figure 54, item 1).


## NOTE

Note orientation of guard (Figure 54, item 1) before removing from end plates.




**Figure 54**

7. On the non-drive side, remove four socket head screws (Figure 55, item 1) and cover (Figure 55, item 2).



**Figure 55**


8. Loosen the bearing collar set screw (Figure 56, item 1) and remove bearing collar (Figure 56, item 2).



**Figure 56**


# Preventive Maintenance and Adjustment

9. Remove two socket head screws (**Figure 57, item 1**) and remove plate (**Figure 57, item 2**).




**Figure 57**

10. Remove two socket head screws (**Figure 58, item 1**) from end plate (**Figure 58, item 2**).



**Figure 58**


11. Remove end plate (**Figure 59, item 1**), and remove lower roller assembly (**Figure 59, item 2**) from end plate and opposite end plate.



**Figure 59**


12. Remove drive spindle (**Figure 59, item 3**) from terminal assembly.

13. Remove shaft assembly (**Figure 60, item 1**) from end plate (**Figure 60, item 2**).



**Figure 60**

14. Remove each extrusion (**Figure 61, item 1**) and support plate (**Figure 61, item 2**) from crossmember (**Figure 61, item 3**).




**Figure 61**

15. Inspect and replace wear strip (**Figure 61, item 4**) if necessary.


# Preventive Maintenance and Adjustment

16. Check idler terminal assembly (**Figure 62, item 1**) for wear. If worn, remove two low head cap screws (**Figure 62, item 2**) and replace.




**Figure 62**

17. Remove rollers (**Figure 63, item 1**) and alignment bar (**Figure 63, item 2**) from shaft (**Figure 63, item 3**). Inspect and replace if worn.



**Figure 63**

18. Reinstall rollers and alignment bar, with each roller lining up with cutout area (**Figure 63, item 4**) on alignment bar.
19. Slide entire sprocket assembly slightly outward, and remove the first sprocket (**Figure 64, item 1**) off the drive spindle (**Figure 64, item 2**) and alignment bar (**Figure 64, item 3**).




**Figure 64**

20. Remove remaining sprockets (**Figure 64, item 4**) off the alignment bar as you slide entire assembly off the drive spindle.
21. To assemble sprockets onto drive spindle, slide one sprocket onto alignment bar and slide assembly onto drive spindle.
22. Install second sprocket and subsequent sprockets (**Figure 64, item 4**) one by one, while sliding entire assembly onto alignment bar (**Figure 64, item 3**) and spindle (**Figure 64, item 2**).

## NOTE


*After installing components and belt, secure assembly by backing out socket head screw (**Figure 65, item 1**). This prevents any rattling of components that may occur during use of conveyor.*



**Figure 65**

## C - Idler Spindle Removal


1. Be sure the conveyor is supported.
2. On one side of conveyor, remove the two socket head screws (**Figure 66, item 1**).



**Figure 66**


# Preventive Maintenance and Adjustment

3. Remove idler assembly (**Figure 67, item 1**) from conveyor (**Figure 67, item 2**).




**Figure 67**

4. Remove end plate (**Figure 68, item 1**) from roller assembly (**Figure 68, item 2**). Remove opposite end.



**Figure 68**


5. Remove rollers (**Figure 69, item 1**) and alignment bar (**Figure 69, item 2**) from shaft (**Figure 69, item 3**). Inspect and replace if worn.



**Figure 69**

6. Reinstall rollers and alignment bar, with each roller lining up with cutout area (**Figure 69, item 4**) on alignment bar.

7. Check idler terminal assembly (**Figure 70, item 1**) for wear. If worn, remove two low head cap screws (**Figure 70, item 2**) and replace.



**Figure 70**


## D - Nose Bar Idler Spindle Removal

1. Be sure the conveyor is supported.
2. On one side of conveyor, remove the two socket head screws (**Figure 71, item 1**). Repeat on opposite side.



**Figure 71**


3. Remove idler tail assembly (**Figure 72, item 1**).



**Figure 72**


# Preventive Maintenance and Adjustment

4. Remove two low head cap screws (**Figure 73, item 1**) from plate (**Figure 73, item 2**). Repeat procedure on opposite side.



**Figure 73**


5. Remove plate (**Figure 74, item 1**) from shaft bearing (**Figure 74, item 2**) and crossmember (**Figure 74, item 3**). Repeat procedure on opposite side.



**Figure 74**


6. Remove shaft (**Figure 74, item 4**) from opposite end plate.

7. Remove each extrusion (**Figure 75, item 1**) and support plate (**Figure 75, item 2**) from crossmember (**Figure 75, item 3**).



**Figure 75**

8. Inspect and replace wear strip (**Figure 75, item 4**) if necessary.
9. Check idler terminal assembly (**Figure 76, item 1**) for wear. If worn, remove three low head cap screws (**Figure 76, item 2**) and replace.



**Figure 76**

# Preventive Maintenance and Adjustment

## NOTE

After installing components and belt, secure assembly by backing out socket head screw (**Figure 65, item 1**). This prevents any rattling of components that may occur during use of conveyor.



Figure 77

## Spindle Replacement

### Drive Spindle

To replace the drive spindle, reverse the procedure “A - Drive Spindle Removal” on page 19.

### Nose Bar Drive Spindle

To replace the nose bar drive spindle, reverse the procedure “B - Nose Bar Drive Spindle Removal” on page 20.

### Idler Spindle

To replace the idler spindle, reverse the procedure “C - Idler Spindle Removal” on page 23.

### Nose Bar Idler Spindle

To replace the idler spindle, reverse the procedure “D - Nose Bar Idler Spindle Removal” on page 24.

## Bearing Replacement

### WARNING



Exposed moving parts can cause severe injury. LOCK OUT POWER before removing guards or performing maintenance.

## Drive Bearing Removal and Replacement



### WARNING



Drive shaft keyway may be sharp. HANDLE WITH CARE.

### Removal

1. Turn bearing (**Figure 78, item 1**) to align with slots (**Figure 78, item 2**) in bearing housing. Then remove bearing.




Figure 78

### Replacement

1. Inspect bearing housing bearing surface. If worn or damaged, replace. See “Service Parts” on page 30.
2. Insert bearing (**Figure 79, item 1**) into housing slot: Locate anti-rotation nub (**Figure 79, item 2**) to align with slot (**Figure 79, item 3**), and twist bearing into housing.




Figure 79

# Preventive Maintenance and Adjustment


## Maintenance of Knuckles

### NOTE

*Be sure all frame sections are properly supported.*

### Guides


1. Loosen socket head screw (**Figure 80, item 1**) on guide bracket (**Figure 80, item 2**) and remove guide (**Figure 80, item 3**). Repeat on opposite side.



**Figure 80**


### Lower Knuckle

1. Remove belt. See “Conveyor Belt Replacement” on page 15.
2. Remove two cap screws (**Figure 81, item 1**) on each side of the knuckle and remove the hold down roller guards (**Figure 81, item 2**). Repeat on opposite side.




**Figure 81**

3. Remove two socket head screws (**Figure 82, item 1**) and remove shaft cover (**Figure 82, item 2**). Repeat on opposite side.




**Figure 82**

4. Remove the hex jam nut (**Figure 83, item 1**) and the hold down roller (**Figure 83, item 2**). Repeat on opposite side.



**Figure 83**

5. Remove three socket head screws and washers (**Figure 84, item 1**) that retain bearing (**Figure 84, item 2**) to support bar (**Figure 84, item 3**). Repeat on opposite side.




**Figure 84**

---

# Preventive Maintenance and Adjustment


---

6. Remove knuckle belt supports (**Figure 85, item 1**).



**Figure 85**

7. Remove belt return wearstrip (**Figure 86, item 1**). Repeat on opposite side.




**Figure 86**

8. Replace parts as necessary.
9. Install parts reverse of removal.


## Upper Knuckle

1. Remove belt. See “Conveyor Belt Replacement” on page 15.
2. Remove two socket head screws (**Figure 87, item 1**). Repeat on other side.



**Figure 87**

3. Separate conveyor frame (**Figure 88, item 1**) from knuckle assembly (**Figure 88, item 2**).




**Figure 88**

---

# Preventive Maintenance and Adjustment


---

4. Remove upper edge wearstrip (**Figure 89, item 1**). Repeat on other side.




**Figure 89**

5. Remove belt return wearstrip (**Figure 90, item 1**). Repeat on other side.




**Figure 90**

6. Slide knuckle joint plate from slot in conveyor frame (**Figure 91, item 1**) and remove shaft assembly (**Figure 91, item 1**).




**Figure 91**

7. Remove tube spacer from shaft (**Figure 92, item 1**).



**Figure 92**

8. Remove rollers (**Figure 93, item 1**) and alignment bar from shaft (**Figure 93, item 2**).




**Figure 93**


9. Replace parts as necessary.  
10. Install parts reverse of removal.


# Service Parts

## NOTE

For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo . Dorner recommends keeping these parts on hand.

## Drive End Components




Item	Part Number	Description
	52BKD	Bearing Kit (Qty. 2)
2	807-1754	Sprocket
3	300139	Shaft Cover
4	352179- <u>WW</u>	Drive Spindle
	352361- <u>WW</u>	Double Output Shaft Drive Spindle
5	352181- <u>WW</u>	Sprocket Alignment Key
6	352184	Clamp Plate
7	352192	Cover Plate
8	352301-00131	Limiter Spacer for 8" - 24" wide conveyors
	352301-00800	Limiter Spacer for 26" - 36" wide conveyors
9	352351	Terminal Assembly

Item	Part Number	Description
10	352352	Drive Shoe
11	920612M	Socket Head Screw M6-1.00 x 12 mm
12	920620M	Socket Head Screw M6-1.00 x 20 mm
13	920630M	Socket Head Screw M6-1.00 x 30 mm
14	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
15	920895M	Low Head Cap Screw, M8-1.25 x 25 mm
16	352497- <u>WW</u>	Stiffener Plate
17	901-133	Button Head Cap Screw, 1/4-20 x .75"
18	53CDT- <u>WW</u>	Drive Spindle Kit (Includes items 2, 4 and 5)

WW = Conveyor width reference: 08 – 36 in 02 increments

## Nose Bar Drive End Components



Item	Part Number	Description
1	802-124	Bearing
2	52BKD	Bearing Kit (Qty. 2)
3	807-1754	Sprocket
4	300139	Shaft Cover
5	352179- <u>WW</u>	Drive Spindle
6	352181- <u>WW</u>	Sprocket Key
7	352184	Clamp Plate
8	352190- <u>WW</u>	Shaft Assembly
9	352196- <u>WW</u>	Alignment Bar
10	352252- <u>WW</u>	Spindle
11	352282	Wear Strip
12	352283	Tail Plate
13	352286- <u>WW</u>	Pinch Guard
14	352291- <u>WW</u>	Crossmember
15	352292	Terminal Assembly Right Hand

Item	Part Number	Description
16	352296	Support Plate
17	352299	Terminal Assembly Left Hand
18	506296	Idler Puck
19	710211- <u>LLLL</u>	Extrusion
20	708180P	Socket Head Screw M6-1.00 x 25 mm
21	920410M	Socket Head Screw M4-.70 x 10 mm
22	920612M	Socket Head Screw M6-1.00 x 12 mm
23	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
24	920895M	Low Head Cap Screw, M8-1.25 x 25 mm
25	53CNBDT- <u>WW</u>	Nose Bar Drive Spindle Kit (Includes items 1, 3, 5, 6 and 10)


WW = Conveyor width reference: 08 – 36 in 02 increments

LLLL = Length in inches with 2 decimal places.

Length Example: Length = 95.25" LLLL = 09525

# Service Parts


## Idler End Components



Item	Part Number	Description
1	352184	Clamp Plate
2	352190- <u>WW</u>	Shaft Assembly
3	352193	Cover Plate
4	352196- <u>WW</u>	Alignment Bar
5	352351	Terminal Assembly
6	506296	Idler Puck
7	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
8	53CET- <u>WW</u>	Idler Spindle Kit (Includes items 2, 4, and 6)

WW = Conveyor width reference: 08 - 36 in 02 increments

## Nose Bar Idler End Components




Item	Part Number	Description
1	802-124	Bearing
2	352184	Clamp Plate
3	352252- <u>WW</u>	Spindle
4	352259	Terminal Assembly Left Hand
5	352260	Terminal Assembly Right Hand
6	352287	Support Plate
7	352288	Tail Plate
8	352290- <u>WW</u>	Extrusion
9	352291- <u>WW</u>	Crossmember
10	352353- <u>WW</u>	Belt Support Rod
11	532289	Wear Strip

Item	Part Number	Description
12	708180P	Socket Head Screw, M6-1.00 x 25 mm
13	920612M	Socket Head Screw, M6-1.00 x 12 mm
14	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
15	53CNBET- <u>WW</u>	Nose Bar Idler Spindle Kit (Includes items 1, 3, and 10)
<u>WW</u> = Conveyor width reference: 08 - 36 in 02 increments		

# Service Parts


## Frame Assembly



Item	Part Number	Description
1	352171- <u>LLLLL</u>	Side Rail
2	352172- <u>WW</u>	First Spacer
3	352172-01	Spacer for 10", 14, 24", and 28" Wide Conveyors Only
	352172-00	Spacer for All Other Width Conveyors
4	352170- <u>WWC</u>	Center Rail
5	352108	Pan Screw, M5-.80 x 20 mm
6	352163- <u>LLLLL</u>	Edge Strip
7	352177- <u>LLLLL</u>	Edge Return Wear Strip
8	352167- <u>LLLLL</u>	Wear Strip

Item	Part Number	Description
9	352184	Clamp Plate
10	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
11	532162- <u>LLLLL</u>	Return Strip
12	352168	Return Support Bracket
<u>WW</u> = Conveyor width reference: 08 - 36 in 02 increments		
<u>LLLLL</u> = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" <u>LLLLL</u> = 09525		

Upper Knuckle




Item	Part Number	Description
1	352452-AA	Upper Joint Plate
2	352453-AA	Knuckle Cover Plate
3	352456-WW	Shaft Assembly
4	352457-WW	Alignment bar
5	352458	Upper Edge Wearstrip
6	352459	Return Strip
7	506296	Idler Puck
8	532127-00100	Tube Spacer

Item	Part Number	Description
9	920891M	Low Head Cap Screw, M8 - 1.25 x 10 mm
10	920893M	Low Head Cap Screw, M8 - 1.25 x 16 mm
11	53NV-WW	Upper Knuckle Kit (Includes Items 5, 6 and 7)
AA = Angle 05, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, and 60		
WW = Conveyor width reference: 08 - 24 in 02 increments		

# Service Parts


## Lower Knuckle



Item	Part Number	Description
1	802-050	Bearing
2	903-349	Flat Head Cap Screw, 3/4 - 10 x 2.25"
3	910-034	Hex Jam Nut
4	911-222	Washer
5	300139	Shaft Cover
6	352451-AA	Lower Joint Plate
7	352453-AA	Knuckle Cover Plate
8	352454	Roller Support Bar
9	352455-WW	Knuckle Belt Support

Item	Part Number	Description
10	352459	Return Wearstrip
11	352465	Hold-Down Wheel
12	920608M	Socket Head Screw, M6 - 1.00 x 8 mm
13	920893M	Low Head Cap Screw, M8 - 1.25 x 16 mm
14	53HI	Lower Knuckle Kit (Includes Items 1 and 10)
AA = Angle 05, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55 and 60		
WW = Conveyor width reference: 08 - 24 in 02 increments		

## Curve Conveyor Frame and Wear Strips




Item	Part Number	Description
1	352198- <u>WW</u> - <u>AAA</u>	Side Rail Outer Curve
2	352197- <u>WW</u> - <u>AAA</u>	Side Rail Inner Curve
3	352172- <u>WW</u> C	First Spacer
4	352172-01	Spacer for 10", 14, 24", and 28" Wide Conveyors Only
	352172-00	Spacer for All Other Width Conveyors
5	352170- <u>WW</u>	Center Rail
6	352108	Pan Screw, M5-.80 x 20 mm
7	352355- <u>WW</u> - <u>AAA</u>	Top Outer Wear Strip
8	352185	Nut Plate
9	920893M	Low Head Cap Screw, M8-1.25 x 16 mm
10	352357- <u>WW</u> - <u>AAA</u>	Bottom Outer Wear Strip
11	352354- <u>WW</u> - <u>AAA</u>	Top Inner Wear Strip
12	352356- <u>WW</u> - <u>AAA</u>	Bottom Inner Wear Strip
13	352358- <u>WW</u> - <u>AAA</u>	Wear Strip
14	352359- <u>WW</u> - <u>AAA</u>	Return Wear Strip
15	352168	Return Bracket

Item	Part Number	Description
<u>WW</u> = Conveyor width reference: 08 - 36 in 02 increments		
<u>AAA</u> = Degree of Curve		


# Service Parts

## 1.5" (38 mm) High Sides



Item	Part Number	Description
1	352182	Guide Retaining Clip
2	380500- <u>LLLLL</u>	1" Guides
3	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
<u>LLLLL</u> = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" <u>LLLLL</u> = 09525		


**3" (76 mm) High Sides**



Item	Part Number	Description
1	352182	Guide Retaining Clip
2	380400- <u>LLLL</u>	3" Guides
3	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
<u>LLLL</u> = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" <u>LLLL</u> = 09525		

# Service Parts


## Fully Adjustable Guiding



Item	Part Number	Description
1	807-948	Shaft Cap
2	807-652	Cross Block
3	202004	Mounting Bracket
4	202027M	Vertical Mounting Guide Shaft
5	532178	Horizontal Mounting Guide Shaft
6	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
7	920616M	Socket Head Screw, M6-1.00 x 16 mm

Item	Part Number	Description
8	532179	Washer
9	920893M	Low Head Cap Screw M8-1.25 x 16mm
10	352363-LLLLL	Guide Rail
11	532195	Guide Connecting Clip
12	807-1840	Hex Head Washer Screw
LLLLL = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" LLLLL = 09525		

Tool-Less Fully Adjustable Guiding




Item	Part Number	Description
1	807-948	Shaft Cap
2	807-1470	Cross Block
3	202004	Mounting Bracket
4	202027M	Vertical Mounting Guide Shaft
5	532178	Horizontal Mounting Guide Shaft
6	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
7	920616M	Socket Head Screw, M6-1.00 x 16 mm

Item	Part Number	Description
8	532179	Washer
9	920893M	Low Head Cap Screw M8-1.25 x 16mm
10	352363- <u>LLLL</u>	Guide Rail
11	532195	Guide Connecting Clip
12	807-1840	Hex Head Washer Screw
		<u>LLLL</u> = Length in inches with 2 decimal places.
		Length Example: Length = 95.25" <u>LLLL</u> = 09525


# Service Parts

## 1.5” (38 mm) High Sides for Curve Module



Item	Part Number	Description
1	807-1943	Self-Drilling Hex Head Screw, 1/4-20 x 5/8"
2	352294-LLLLL	1.5" High Side Curve Guiding
LLLLL = Length in inches with 2 decimal places.		
Length Example: Guiding Length = 95.25" LLLLL = 09525		


3" (76 mm) High Sides for Curve Module



Item	Part Number	Description
1	807-1943	Self-Drilling Hex Head Screw, 1/4-20 x 5/8"
2	352293- <u>LLLLL</u>	3" High Side Curve Guiding
<u>LLLLL</u> = Length in inches with 2 decimal places.		
Length Example: Guiding Length = 95.25" LLLLL = 09525		


# Service Parts

## Fully Adjustable Guiding for Curve Module



Item	Part Number	Description
1	807-948	Shaft Cap
2	807-652	Cross Block
3	202004	Mounting Bracket
4	202027M	Vertical Mounting Guide Shaft
5	532178	Horizontal Mounting Guide Shaft
6	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
7	920612M	Socket Head Screw, M6-1.00 x 12 mm
8	532179	Washer
9	960812MSS	Hex Head Cap Screw M8-1.25 x 12mm
10	352364-LLLLL	Guide Rail
11	532195	Guide Connecting Clip
12	807-1840	Hex Head Washer Screw
LLLLL = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" LLLLL = 09525		


## Tool-Less Fully Adjustable Guiding for Curve Module



Item	Part Number	Description
1	807-948	Shaft Cap
2	807-1470	Cross Block
3	202004	Mounting Bracket
4	202027M	Vertical Mounting Guide Shaft
5	532178	Horizontal Mounting Guide Shaft
6	807-1937	Self-Drilling Hex Head Screw, 1/4-20 x 1"
7	920612M	Socket Head Screw, M6-1.00 x 12 mm
8	532179	Washer
9	960812MSS	Hex Head Cap Screw M8-1.25 x 12mm
10	352364-LLLLL	Guide Rail
11	532195	Guide Connecting Clip
12	807-1840	Hex Head Washer Screw
LLLLL = Length in inches with 2 decimal places.		
Length Example: Length = 95.25" LLLLL = 09525		


# Service Parts

## Flat Belt Returns




Item	Part Number	Description
1	352168	Return Support Bracket
2	532162- <u>LLLLL</u>	Return Strip
<u>LLLLL</u> = Length in inches with 2 decimal places.		
Length Example: Guiding Length = 95.25" LLLLL = 09525		

## Stand Mount Kit



Item	Part Number	Description
1	300150M	Drop-In Tee Bar
2	605279P	Washer
3	920620M	Socket Head Screw, M6-1.00 x 20 mm

## Flat Belt Chain Repair Kit



Item	Part Number	Description
1	52BB-WW	Flat Belt Chain Repair Kit (Includes 1 ft (305 mm) of flat belt chain and assembly pins)
BB = Chain Reference number		
WW = Conveyor width ref: 08 - 36 in 02 increments		

## Ordering a Replacement Chain

Determine the length of chain required for the conveyor and round up to the nearest foot length. Order the proper number of chain repair kits (1' long each) for your conveyor. Dorner will ship chain kits that are of a reasonable length fully assembled

### Example:

Overall chain length = 42' 5" (rounded up = 43')

Order: Qty (43) of 52BB-WW

BB = Chain reference number

WW = Conveyor width ref: 08-36 in 02 increments

# Return Policy

Returns must have prior written factory authorization or they will not be accepted. Items that are returned to Dorner without authorization will not be credited nor returned to the original sender. When calling for authorization, please have the following information ready for the Dorner factory representative or your local distributor:

1. Name and address of customer.
2. Dorner part number(s) of item(s) being returned.
3. Reason for return.
4. Customer's original order number used when ordering the item(s).
5. Dorner or distributor invoice number (if available, part serial number).

A representative will discuss action to be taken on the returned items and provide a Returned Goods Authorization (RMA) number for reference. RMA will automatically close 30 days after being issued. To get credit, items must be new and undamaged. There will be a return charge on all items returned for credit, where Dorner was not at fault. It is the customer's responsibility to prevent damage during return shipping. Damaged or modified items will not be accepted. The customer is responsible for return freight.

## Conveyors and conveyor accessories

Standard catalog conveyors	30%
MPB, 7200, 7300 Series, cleated and specialty belt	50%
AquaGard & AquaPruf Series conveyors	non-returnable items
Engineered to order products	case by case
Drives and accessories	30%
Sanitary stand supports	non-returnable items

## Parts

Standard stock parts	30%
Plastic chain, cleated and specialty belts	non-returnable items

Returns will not be accepted after 60 days from original invoice date. The return charge covers inspection, cleaning, disassembly, disposal and reissuing of components to inventory. If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Contact Dorner for the name of your local representative. Our Customer Service Team will gladly help with your questions on Dorner products.

For a copy of Dorner's Warranty, contact factory, distributor, service center or visit our website at [www.dorner.com](http://www.dorner.com).

For replacement parts, contact an authorized Dorner Service Center or the factory.



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. © Dorner Mfg. Corp. 2011

## DORNER MFG. CORP.

975 Cottonwood Ave., PO Box 20  
Hartland, WI 53029-0020 USA  
TEL 1-800-397-8664 (USA)  
FAX 1-800-369-2440 (USA)  
Internet: [www.dorner.com](http://www.dorner.com)

Outside the USA:  
TEL 1-262-367-7600  
FAX 1-262-367-5827