



7600 Series CE Center Drive Conveyors

Installation, Maintenance and Parts Manual



DORNER MFG. CORP.
P.O. Box 20 • 975 Cottonwood Ave.
Hartland, WI 53029-0020 USA

INSIDE THE USA
TEL: 1-800-397-8664
FAX: 1-800-369-2440

OUTSIDE THE USA
TEL: 262-367-7600
FAX: 262-367-5827

For other service manuals visit our website at:
www.dorner.com/service_manuals.asp

Table of Contents

Introduction	2	Conveyor Belt Tracking	18
Warnings – General Safety	3	Tracking Procedure	18
Product Description	3	Conveyor Belt Tracking at Tails	18
Specifications	4	Conveyor Belt Tracking at Center Drive	19
Flat Belt 7600 Series Center Drive Conveyor	4	Spindle Removal	20
Conveyor Supports	5	A - Center Drive Spindle Removal	20
Specifications	5	B - Idler Spindle Removal	23
Installation	6	C - .5" Nose Bar Idler Spindle Removal	23
Required Tools	6	D - 1" Nose Bar Idler Spindle Removal	24
Recommended Installation Sequence	6	E - 1.875" Nose Bar Idler Spindle Removal	25
Conveyors Longer than 3048 mm	6	Reassembling Tail Assemblies	26
Connecting Components	6	Gas Assist Replacement	26
Wear Strip Installation	7	Bearing Replacement	27
Standard Wear Strips	7	Standard Bearings	27
Stainless Steel Sheet Bed Plates (optional)	7	.5" and 1" Nose Bar Return Spindle Bearings	27
Lifter Installation	8	1" Nose Bar Bearings	27
Belt Installation	8	1.875" Nose Bar Bearings	28
Guide Installation	10	Center Drive Tension Spindle Bearings	28
All Conveyors	10	NOTES	29
Belt Return Installation	10	Service Parts	30
Flat Belt	10	Center Drive Assembly Components	30
Scraper Installation	11	Idler End Components	31
Stand Installation	12	.5" Nose Bar Idler End	32
Drive Package Installation	13	1" Nose Bar Idler End	34
Preventive Maintenance and Adjustment	14	1.875" Nose Bar Idler End	36
Required Tools	14	Discharge End	37
Checklist	14	.5" Nose Bar Discharge End	38
Cleaning	14	1" Nose Bar Discharge End	40
Routine Cleaning	14	1.875" Nose Bar Discharge End	42
Standard Conveyors	14	Conveyor Frame and Extensions	
Conveyors with Lifters	14	with Standard Wear Strips	43
Periodic Cleaning	15	Wear Strips with Stainless Steel Sheet Bed Plate	44
Lubrication	15	Lifters	45
Conveyor Bearings	15	Gas Assisted Tip Up	45
Wearstrips and Belt Returns	15	76 mm High Sides	46
Scraper	15	Flat Belt Returns	47
Maintaining the Conveyor Belt	15	Scraper	47
Troubleshooting	15	Configuring Conveyor Belt Part Number	48
Conveyor Belt Replacement	15	Flat Belt Part Number Configuration	48
Conveyors with Guides	16	NOTES	49
Standard Belts	16	Return Policy	50
Conveyor Belt Tensioning	17		

Introduction

CAUTION

Some illustrations may show guards removed. DO NOT operate equipment without guards.

Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage. Accessories may be shipped loose.
- See accessory instructions for installation.

The Dorner Limited Warranty applies.

Dorner AquaPruf conveyors are covered by Patent Numbers 7,207,435, 7,246,697, 7,383,944, additional patent pending applications, and corresponding patents in other countries.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits logo .

Warnings – General Safety

⚠ DANGER



SEVERE HAZARD!
KEEP OFF CONVEYORS. Climbing, sitting, walking or riding on conveyor will result in death or serious injury.

⚠ DANGER



EXPLOSION HAZARD!

- **DO NOT OPERATE CONVEYORS IN AN EXPLOSIVE ENVIRONMENT.** The electric gearmotor generates heat and could ignite combustible vapors.
- Failure to comply will result in death or serious injury.

⚠ WARNING



CRUSH HAZARD!

- **DO NOT** place hands or fingers inside the conveyor while it is running.
- **DO NOT** wear loose garments while operating the conveyor. Loose garments can become caught up in the conveyor.
- Failure to comply could result in serious injury.

⚠ WARNING



CRUSH HAZARD!

- **SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.**
- Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing serious injury.

⚠ WARNING



SEVERE HAZARD!
LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

⚠ WARNING



BURN HAZARD!
DO NOT TOUCH the motor while operating, or shortly after being turned off. Motors may be **HOT** and can cause serious burn injuries.

⚠ WARNING



PUNCTURE HAZARD!
 Handle drive shaft keyway with care. It may be sharp and could puncture the skin, causing serious injury.

⚠ WARNING



SEVERE HAZARD!

- Dorner cannot control the physical installation and application of conveyors. Taking protective measures is the responsibility of the user.
- When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, **CHECK FOR POTENTIAL PINCH POINTS** and other mechanical hazards before system start-up.
- Failure to comply could result in serious injury.

Product Description

Refer to **(Figure 1)** for typical conveyor components.

- | | |
|---|------------------------|
| 1 | Conveyor |
| 2 | Gearmotor |
| 3 | Belt (Flat Belt Shown) |
| 4 | Support Stands |
| 5 | Motor Controller |
| 6 | Discharge End |
| 7 | Infeed End |
| 8 | Center Drive Module |





Figure 1

Specifications

Flat Belt 7600 Series Center Drive Conveyor



Conveyor Supports

Maximum Distances:

- 1 = Support Stand on Infeed End = 914 mm
- 2 = Between Support Stands = 2438 mm**
- 3 = Support Stand on Discharge End = 914 mm
- ** For conveyors longer than 3.05 m, install support at frame joint.




Figure 2

Specifications

Conveyor Width Reference (<u>WW</u>)	06 – 60 in 02 increments
Conveyor Belt Width	6" (152 mm) - 60" (1524 mm) in 2" (51 mm) increments
Maximum Conveyor Load	181 kg (400 lbs.)
Belt Travel	286 mm (11.25") per revolution of pulley
Maximum Belt Speed	100 m/minute (325 ft/minute)
Belt Take-up	38 mm (1.5")
Conveyor Length Reference (<u>LLL</u>)	048 - 480 in 001 increments
Conveyor Length	48" (1219 mm) - 480" (12192 mm) in 1" (25 mm) increments

IMPORTANT

Maximum conveyor loads are based on:

- *Non-accumulating product*
- *Product moving toward gearmotor*
- *Conveyor being mounted horizontally*
- *Conveyor being located in a dry environment*
- *Conveyor equipped with standard belt only*

Installation

⚠ CAUTION

Dorner recommends cleaning all the “food zones” prior to placing conveyor into service. Ensure adequate access is provided for cleaning and servicing equipment so that the required level of hygiene can be maintained.

⚠ CAUTION

Conveyor **MUST** be mounted straight, flat, and level within confines of conveyor. Use a level (Figure 3, item 1) during setup.




Figure 3

Required Tools

- Level
- Torque wrench

Recommended Installation Sequence

1. Assemble the conveyor (if required). Refer to “All Conveyors” on page 10.
2. Attach the stands. Refer to “Stand Installation” on page 13.
3. Install the gearmotor. Refer to “Drive Package Installation” on page 13.

Conveyors Longer than 3048 mm

Connecting Components

Typical Connection Components (Figure 4)

- | | |
|---|---------------------------------------|
| 1 | M10 x 1.5 mm hex head cap screws (x4) |
| 2 | Connector hex rods (x2) |
| 3 | Conveyor frames |




Figure 4

1. Locate the section number sequence etched on each section of frame (Figure 5, item 1).




Figure 5

2. Position the frame sections in the correct order.

3. Connect the frame sections by bolting the hex post connectors (**Figure 6, item 1**) to the sections of frame.




Figure 6

Wear Strip Installation

Standard Wear Strips

Typical Standard Wear Strips (**Figure 7**)

1	Wear Strips
---	-------------




Figure 7

1. Position the wear strips (**Figure 8, item 1**) on the frame.




Figure 8

2. Make sure the slots in the wear strips (**Figure 8, item 2**) line up properly with the frame slots (**Figure 8, item 3**).

Stainless Steel Sheet Bed Plates (optional)

Typical Stainless Steel Sheet Bed Plates (**Figure 9**)

1	Bed Plates
2	Wear Strips




Figure 9

1. Attach the wear strips to the frame. Refer to “Standard Wear Strips” on page 7.
2. Place the sheet bed plates (**Figure 10, item 1**) over the wear strips (**Figure 10, item 2**).




Figure 10

Installation

Lifter Installation

Typical Lifter Components (**Figure 11**)

1	Belt lift pivot bar
2	Lifter bars
3	Belt lift handle
4	M8 - 1.25 x 16 mm hex head cap screw




Figure 11

1. Slide the belt lift pivot bar (**Figure 12, item 1**) through the designated holes in the frame. The pins on the belt lift pivot bar should be located inside the frame side rails.




Figure 12

2. Attach the lifter bars (**Figure 12, item 2**) to the belt lift pivot bar (**Figure 12, item 1**). Make sure the hooked ends of the lifter bars are facing down when resting against the frame.
3. Attach the lifter handle (**Figure 12, item 3**) to the belt lift pivot rod.

Belt Installation

Typical Standard Belt (**Figure 13**)

1	Belt
---	------




Figure 13

1. Place the idler tail (**Figure 14, item 1**) in the up position.




Figure 14

2. Remove the 2 pull pins (**Figure 15, item 1**) from the center drive side plate (**Figure 15, item 2**).




Figure 15

- Lift up on the center drive guard (Figure 16, item 1) and remove it.




Figure 16

- Slide the tension spindle assembly (Figure 17, item 1) out of the housing.




Figure 17

- Repeat steps 2 - 4 on the other side of the drive assembly.

 WARNING

SEVERE HAZARD!
<ul style="list-style-type: none"> • ONLY DISCONNECT ONE PIVOT BRACKET AT A TIME AND ONLY IF THE STANDS ARE BOLTED TO THE FLOOR. • Disconnecting more than one pivot bracket at a time or not bolting the stands to the floor can cause the conveyor to tip and may result in serious injury.

- Lower the quick release arm (Figure 18, item 1) on one of the stands. *Note: if the conveyor is not equipped with Quick Release (QR Type) stands, it will be necessary to remove the entire stand.* For detailed instructions, refer to the “Sanitary Support Stands Installation, Maintenance and Parts Manual.”




Figure 18

- Slide the belt (Figure 19, item 1) on over the conveyor frame (Figure 19, item 2).




Figure 19

- Secure the quick release arm on the stand and repeat steps 6 and 7 until the belt is around the entire length of the conveyor.
- Slide the tension spindle assemblies (Figure 17, item 1) back into the housing.
- Reattach the center drive guards (Figure 16, item 1).
- Insert the pull pins (Figure 15, item 1).
- Add tension to the belt by lowering the tip-up tail or by sliding the idler tail out and tightening the nuts. Refer to “Conveyor Belt Tensioning” on page 17.
- Adjust the belt tracking as necessary. Refer to “Conveyor Belt Tracking” on page 18.

Installation

Guide Installation

Typical Guide Components (Figure 20)

1	Guide
2	Pull pin




Figure 20

1. Position the guide (Figure 21, item 1) so that the flat surface is facing the belt and then slide the guide onto the frame rail (Figure 21, item 2).




Figure 21

2. Line up the guide holes with the holes in the frame.
3. Insert the pull pins (Figure 22, item 1) into the holes in the guide (Figure 22, item 2).




Figure 22

All Conveyors

Belt Return Installation

Flat Belt

Typical Flat Belt Components (Figure 23)

1	Flat belt returns
---	-------------------




Figure 23

1. Slide the return shaft (Figure 24, item 1) up and through the large slot (Figure 24, item 2) in the frame.




Figure 24

2. Push up on the return shaft (Figure 25, item 1) and slide the notched end of the shaft through the small slot (Figure 25, item 2) on the opposite side of the frame.




Figure 25

3. Repeat the procedure for all other belt returns.

Scraper Installation

Typical Scraper Components (Figure 26)

1	Scraper adjust plate
2	Scraper shaft
3	Scraper bar holder
4	UHMW scraper
5	Scraper mount plate
6	Pull pin
7	Handle
8	M10-1.50 hex head cap screws (x4)




Figure 26

1. Attach the scraper adjust plate (Figure 26, item 1) and the scraper mount plate (Figure 26, item 5) to the frame using four M10-1.5 x 12mm hex head cap screws.
2. Slide the notched end of the scraper shaft (Figure 27, item 1) through the adjustment plate (Figure 27, item 2).




Figure 27

3. Insert the notched end of the scraper shaft (Figure 28, item 1) so that it is situated within the groove in the mounting plate (Figure 28, item 2).




Figure 28

4. Attach the scraper bar holders (Figure 29, item 1) to the scraper shaft (Figure 29, item 2).




Figure 29

5. Attach the UHMW scraper (Figure 29, item 3) to the scraper bar holders (Figure 29, item 1).
6. Insert the pin (Figure 30, item 1) to lock the scraper bar in place (Figure 30, item 2).




Figure 30

7. Adjust the scraper to the desired position using the scraper bar handle (Figure 30, item 3).

Installation

⚠ CAUTION

Apply minimal pressure between the scraper (Figure 31, item 1) and the belt (Figure 31, item 2).

Positioning the scraper so that it is digging into the belt will increase resistance, cause unnecessary strain on the motor and lead to premature belt failure.




Figure 31

8. Secure the scraper by tightening the handle (Figure 32, item 1).




Figure 32

Stand Installation

Drive Package Installation

Typical Stand Components (Figure 33)

See manual 851-656

1	Conveyor
2	Stand
3	Knob
4	M10-1.50 x 12 mm hex head cap screws (x2)




Figure 33

1. Properly support the conveyor.
2. Attach the non-quick release side of the stand (**Figure 34, item 1**) to the MOTOR SIDE of the conveyor (**Figure 34, item 2**) using two M10-1.5 x 12mm hex head cap screws (**Figure 34, item 3**).




Figure 34

3. Attach the quick-release arm to the stand with the knob. (**Figure 33, item 3**).

For detailed assembly instructions, refer to the "Sanitary Support Stands Installation, Maintenance and Parts Manual."

Preventive Maintenance and Adjustment

Required Tools

- 8 mm wrench (or adjustable wrench)
- 10 mm wrench
- 17 mm wrench
- 14 mm wrench
- 4 mm or 5/32 in. hex wrench (for bearing shaft assembly fasteners)
- 3 mm hex wrench

Checklist

- Keep service parts on hand. Refer to the "Service Parts" section starting on page 30 for recommendations.
- Replace any worn or damaged parts.

Cleaning

NOTE

Proper conveyor application, cleaning, and sanitation are the responsibility of the end user.

CAUTION

Dorner recommends cleaning all the "food zones" prior to placing conveyor into service. Ensure adequate access is provided for cleaning and servicing equipment so that the required level of hygiene can be maintained.

Routine Cleaning

WARNING



SEVERE HAZARD!

LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

Dorner recommends cleaning the inside and the outside of the conveyor on a daily basis. Refer to the following steps to access the inside of the conveyor.

Standard Conveyors

1. Remove the guides, if applicable, by removing the pull pins (**Figure 35, item 1**) that connect the guide (**Figure 35, item 2**) to the frame.




Figure 35

2. Place the tip up tail (**Figure 36, item 1**) in the up position.




Figure 36

3. Lift up on the belt (**Figure 36, item 2**).

Conveyors with Lifters

1. Remove the guides, if applicable, by removing the pull pins (**Figure 35, item 1**) that connect the guide (**Figure 35, item 2**) to the frame.
2. Place the tip up tail in the up position.
3. Use the lifter handle (**Figure 37, item 1**) to raise the belt (**Figure 37, item 2**).




Figure 37

CAUTION

DO NOT submerge or soak bearing assemblies. This will reduce the life of the bearing.

Preventive Maintenance and Adjustment

Periodic Cleaning

Dorner recommends complete disassembly of the conveyor periodically for thorough cleaning.

For conveyor disassembly and reassembly instructions:

- Refer to “Conveyor Belt Replacement” on page 15.
- Refer to “Spindle Removal” on page 20.

Lubrication

Conveyor Bearings

Conveyor bearing lubrication is required. Dorner recommends using an H-1 food grade grease.

NOTE

Although bearings are sealed, re-greasing is recommended to increase bearing life. An H-1 food grade grease is recommended. The frequency of bearing re-greasing is dependent upon the application in which the conveyor is being used. Frequency of re-greasing will increase with the frequency of conveyor washing.

1. Add grease to the bearing using the zerk fitting (**Figure 38, item 1**) on the exterior of the bearing shaft assembly.




Figure 38

2. Replace the bearings if they become worn.

Wearstrips and Belt Returns

Replace the wearstrips and belt returns if they become worn.

For wearstrip and belt return installation instructions:

- Refer to “Wear Strip Installation” on page 7.
- Refer to “Belt Return Installation” on page 10.

Scraper

Replace the UHMW scraper if it becomes worn.

Refer to “Scraper Installation” on page 11 for scraper installation instructions.

Maintaining the Conveyor Belt

Troubleshooting

NOTE

Visit www.dorner.com for complete list of troubleshooting solutions.

Inspect conveyor belt for:

- Surface cuts or wear

Damage to the belt, surface cuts and / or wear indicate:

- Sharp or heavy parts impacting belt
- Jammed parts
- Accumulated dirt
- Foreign material inside the conveyor
- Improperly positioned accessories
- Excessive load on belt
- Dirt impacted on spindle
- Excessive or improper side loading
- Improper tracking

Skipping indicates:

- Excessive load on belt
- Worn spindle or impacted dirt on drive spindle
- Improper tracking

Conveyor Belt Replacement



WARNING



SEVERE HAZARD!

LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

Preventive Maintenance and Adjustment

Conveyors with Guides

1. Remove the pull pins (**Figure 39, item 1**) that connect the guide (**Figure 39, item 2**) to the frame.




Figure 39

2. Remove the guide (**Figure 40, item 1**) from the conveyor (**Figure 40, item 2**).




Figure 40

Standard Belts

1. Place the idler tail (**Figure 41, item 1**) in the up position.




Figure 41

2. Remove the pull pins (**Figure 42, item 1**) from the center drive side plate (**Figure 42, item 2**).




Figure 42

3. Lift up on the center drive guard (**Figure 43, item 1**) and remove it.




Figure 43

4. Slide the tension spindle assembly (**Figure 44, item 1**) out of the housing.




Figure 44

5. Repeat steps 2 - 4 on the other side of the drive assembly.

Preventive Maintenance and Adjustment

⚠ WARNING

SEVERE HAZARD!
<ul style="list-style-type: none">• ONLY DISCONNECT ONE PIVOT BRACKET AT A TIME AND ONLY IF THE STANDS ARE BOLTED TO THE FLOOR.• Disconnecting more than one pivot bracket at a time or not bolting the stands to the floor can cause the conveyor to tip and may result in serious injury.

6. Lower the quick release arm (**Figure 45, item 1**) on one of the stands. *Note: if the conveyor is not equipped with Quick Release (QR Type) stands, it will be necessary to remove the entire stand.* For detailed instructions, refer to the “Sanitary Support Stands Installation, Maintenance and Parts Manual.”




Figure 45

7. Slide the old belt (**Figure 46, item 1**) off the conveyor frame (**Figure 46, item 2**).




Figure 46

8. Secure the quick release arm on the stand and repeat steps 6 and 7 until the entire belt is off the conveyor.
9. Replace the old belt with a new one. Refer to “Belt Installation” on page 8.

Conveyor Belt Tensioning

⚠ WARNING

SEVERE HAZARD!
LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

⚠ CAUTION
Over-tensioning of conveyor may stretch conveyor belt and reduce bearing life.

Preventive Maintenance and Adjustment

1. Loosen the back nuts (**Figure 47, item 1**) on both sides of the idler tail shaft.




Figure 47

2. Turn the front nuts closest to the tail (**Figure 48, item 1**) clockwise in order to increase tension on the belt.




Figure 48

CAUTION
Ensure that there is at least 152 mm from the frame to the end of the tail.




Figure 49

3. Tighten the back nuts (**Figure 48, item 2**) to secure the tail.

Conveyor Belt Tracking

IMPORTANT

When installing a new belt, set conveyor tracking elements to the “zero position” and start the tracking procedure. The zero position is when the tails are tensioned out to the 6” dimension as shown in (**Figure 49**, and the infeed tension roller (**Figure 52, item 1**) on the center drive assembly is set to its outermost position (roller away from center of box, against guard).

Tracking Procedure

Inspect belt tracking at tails and at center drive assembly. Track belt where needed. Refer to “Conveyor Belt Tracking at Tails” on page 18 and “Conveyor Belt Tracking at Center Drive” on page 19.

For conveyors 6 ft long and under, the majority of the belt tracking will be accomplished at the center drive assembly (may be able to track belt without tracking the tails).

Conveyor Belt Tracking at Tails

To adjust conveyor belt tracking at the tails:

1. Loosen the back nut (**Figure 48, item 2**) on the idler tail shaft that needs to be adjusted.
2. Tighten the front nut (**Figure 48, item 1**) on the idler tail shaft to adjust the belt tracking.

CAUTION
Ensure that there is at least 152 mm from the frame to the end of the tail.

Preventive Maintenance and Adjustment

- a. Loosen the nut to shorten the length of the idler tail shaft and bring the belt closer to that side of the conveyor (**Figure 50**).




Figure 50

- b. Tighten the nut to increase the length of the idler tail shaft and move the belt away from that side of the conveyor (**Figure 51**).




Figure 51

3. Tighten the back nut on the idler tail shaft when finished.

Conveyor Belt Tracking at Center Drive




Figure 52

Tracking of belt through the center drive is done by adjusting the position of the infeed roller (**Figure 52, item 1**) on the center drive assembly.

To adjust conveyor belt tracking at the center drive:

1. Loosen the guide plate nuts (**Figure 53, item 1**) on the infeed side of the center drive assembly.




Figure 53

2. Tighten the guide plate bolt (**Figure 53, item 2**) to move the belt away from that side of the conveyor.
3. Tighten the guide plate nuts when finished.

IMPORTANT

Belt tracking will need to be readjusted if the direction of travel is changed.

Preventive Maintenance and Adjustment

Spindle Removal

⚠ WARNING

SEVERE HAZARD! LOCK OUT POWER before removing guards or performing maintenance. Exposed moving parts can cause serious injury.

1. Remove the conveyor belt to access the spindles. Refer to “Conveyor Belt Replacement” on page 15.
2. Remove the spindle by following the instructions for the specific spindle type:
 - A - Center Drive Spindle Removal
 - B - Idler Spindle Removal
 - C - .5" Nose Bar Idler Spindle Removal
 - D - 1" Nose Bar Idler Spindle Removal
 - E - 1.875" Nose Bar Idler Spindle Removal

A - Center Drive Spindle Removal

⚠ WARNING

PUNCTURE HAZARD! Handle drive shaft keyway with care. It may be sharp and could puncture the skin, causing serious injury.

1. Place the idler tail (Figure 54, item 1) in the up position.




Figure 54

2. Remove the pull pins (Figure 55, item 1) from the center drive side plate (Figure 55, item 2).




Figure 55

3. Lift up on the center drive guard (Figure 56, item 1) and remove it.




Figure 56

4. Slide the tension spindle assembly (Figure 57, item 1) out of the housing.




Figure 57

5. Repeat steps 2 - 4 on the other side of the drive assembly.

Preventive Maintenance and Adjustment

⚠ WARNING

↓

CRUSH HAZARD!

- **SUPPORT MOTOR PRIOR TO LOOSENING THE BOLTS.**
- **Loosening motor bolts may cause it to drop down, causing serious injury.**

6. Remove the plastic cap on the end of the motor and remove the socket head screw (Figure 58, item 1) and the bore plug (Figure 58, item 2).




Figure 58

7. Remove the bent bars (Figure 59, item 1) from the motor mounting bracket (Figure 59, item 2).




Figure 59

8. Slide the gearmotor assembly (Figure 60, item 1) off of the drive spindle (Figure 60, item 2).




Figure 60

9. Remove the drive spindle key (Figure 61, item 1) from the drive spindle keyway (Figure 61, item 2).




Figure 61

10. Remove the bearing cover (Figure 62, item 1) on the center drive shaft assembly (Figure 62, item 2).




Figure 62

Preventive Maintenance and Adjustment

11. Use a 4 mm hex wrench to loosen the button head screws on the bearing (**Figure 63, item 1**).




Figure 63

12. Remove the bolt (**Figure 64, item 1**) that connects the drive shaft assembly (**Figure 64, item 2**) to the block shaft mount (**Figure 64, item 3**).




Figure 64

13. Lower the end of the drive shaft spindle (**Figure 65, item 1**) until it is clear of the side plate (**Figure 65, item 2**) and remove it.




Figure 65

B - Idler Spindle Removal

1. Remove the back nuts (**Figure 66, item 1**) on both idler tail shafts.




Figure 66

2. Slide the idler tail assembly (**Figure 66, item 2**) out of the take up blocks (**Figure 66, item 3**).
3. Remove the bearing covers (**Figure 66, item 4**).
4. Use a 4 mm hex wrench (**Figure 67, item 1**) to loosen the bearing shaft assembly fasteners (**Figure 67, item 2**).




Figure 67

5. Remove the bearing shafts (**Figure 68, item 1**) and both pinch guards (**Figure 68, item 2**).




Figure 68

Preventive Maintenance and Adjustment

C - .5" Nose Bar Idler Spindle Removal

1. Remove the back nuts (**Figure 69, item 1**) on both discharge nose bar shafts.




Figure 69

2. Slide the nose bar tail assembly (**Figure 70, item 1**) out of the take up blocks (**Figure 70, item 2**).




Figure 70

3. Slide the nose bar shafts (**Figure 71, item 1**) off of the nose bar weldment (**Figure 71, item 2**).




Figure 71

4. Use a 10 mm wrench to remove one of the acorn nuts (**Figure 72, item 1**) from the nose bar shaft.




Figure 72

5. Remove the nose bar shaft (**Figure 73, item 1**), the rollers (**Figure 73, item 2**) and the roller mounts (**Figure 73, item 3**).




Figure 73

6. Remove the nose bar return spindle (**Figure 74, item 1**).




Figure 74

Preventive Maintenance and Adjustment

D - 1" Nose Bar Idler Spindle Removal

1. Remove the back nuts (**Figure 75, item 1**) on both discharge nose bar shafts.




Figure 75

2. Slide the nose bar tail assembly (**Figure 76, item 1**) out of the take up blocks (**Figure 76, item 2**).




Figure 76

3. Slide the nose bar shafts (**Figure 77, item 1**) off of the nose bar weldment (**Figure 77, item 2**).




Figure 77

4. Use a 17 mm wrench to remove both pilot nose bolts (**Figure 78, item 1**) from the nose bar weldment (**Figure 78, item 2**).




Figure 78

5. Slide the nose bar puck holders (**Figure 79, item 1**) and the nose bar spindle (**Figure 79, item 2**) off of the nose bar weldment (**Figure 79, item 3**).




Figure 79

6. Remove the nose bar return spindle (**Figure 80, item 1**).




Figure 80

Preventive Maintenance and Adjustment

E - 1.875" Nose Bar Idler Spindle Removal

1. Slide the pinch guard blocks (**Figure 81, item 1**) off the nose bar spindles (**Figure 81, item 2**).




Figure 81

2. Remove the transfer bearing screws (**Figure 82, item 1**) and the cover (**Figure 82, item 2**) using an 8 mm wrench.




Figure 82

3. Remove the back nuts (**Figure 83, item 1**) on both discharge nose bar shafts.




Figure 83

4. Slide the nose bar tail assembly (**Figure 84, item 1**) out of the take up blocks (**Figure 84, item 2**).




Figure 84

5. Use a 4 mm hex wrench to loosen all the bearing fasteners (**Figure 85, item 1**).




Figure 85

6. Slide the nose bar shafts (**Figure 86, item 1**) off the nose bar spindles (**Figure 86, item 2**).




Figure 86

Preventive Maintenance and Adjustment

Reassembling Tail Assemblies

Refer to the "Service Parts" section starting on page 30 for complete diagrams and lists of all tail assembly components.

Gas Assist Replacement

1. Raise the tip up tail.
2. Remove the pull pin (**Figure 87, item 1**).




Figure 87

3. Remove the hex bolt (**Figure 88, item 1**) that connects the gas spring (**Figure 88, item 2**) to the gas spring standoff post (**Figure 88, item 3**).




Figure 88

4. Remove the inside hex bolt that connects the standoff post (**Figure 88, item 3**) to the frame.

Preventive Maintenance and Adjustment

Bearing Replacement

Standard Bearings

1. Secure the bearing shaft.
2. Remove the bearing cover.
3. Insert the rod end of another bearing shaft through the bearing orifice (**Figure 89**).



Figure 89

4. Apply lateral pressure to the rod until the bearing comes loose.
5. Remove the worn or damaged bearing (**Figure 90**).




Figure 90

6. Replace the bearing.

NOTE

When inserting the new bearing, make sure the anti-rotation notch (**Figure 90, item 1**) on the bearing lines up with the groove inside the housing (**Figure 90, item 2**).

7. Use a hex wrench to tighten the bearing shaft assembly fasteners to 6 N•m (54 in-lbs). Check after 24 hours of conveyor use.

.5" and 1" Nose Bar Return Spindle Bearings

1. Remove the nose bar return spindle. Refer to "Spindle Removal" starting on page 20.
2. Using a bearing removal tool (**Figure 91, item 1**), remove the bearing (**Figure 91, item 2**).




Figure 91

3. Replace the bearing.

1" Nose Bar Bearings

1. Remove the nose bar spindle. Refer to "Spindle Removal" starting on page 20.
2. Remove the nose bar puck holders (**Figure 92, item 1**).




Figure 92

3. Using a bearing removal tool (**Figure 93, item 1**) remove the bearing (**Figure 93, item 2**).




Figure 93

4. Replace the bearing.

Preventive Maintenance and Adjustment

1.875" Nose Bar Bearings

1. Remove the nose bar spindle. Refer to "Spindle Removal" starting on page 20.
2. Remove the bearing (**Figure 94, item 1**) from the nose bar shaft assembly (**Figure 94, item 2**).




Figure 94

3. Replace the bearing.

Center Drive Tension Spindle Bearings

1. Remove the tension spindle. Refer to steps 1 - 5 in "A - Center Drive Spindle Removal" on page 20.
2. Remove the bearing cover (**Figure 95, item 1**).




Figure 95

3. Use a 4 mm hex wrench to remove the button head screws that connect the bearing to the spindle (**Figure 96, item 1**).




Figure 96

4. Slide the housing block (**Figure 97, item 1**) and bearing off of the tension spindle (**Figure 97, item 2**).




Figure 97

5. Remove the bearing (**Figure 98, item 1**) from the housing block (**Figure 98, item 2**).





Figure 98

Service Parts

NOTE

For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo . Dorner recommends keeping these parts on hand.

Center Drive Assembly Components




Item	Part Number	Description
1	807-1454	Bearing Cover
2	500683	Center Drive Housing Block
3	810-187	Zerk Fitting
4	961055MSS	Hex Head Cap Screw M10-1.50 x 55mm
5	961040MSS	Hex Head Cap Screw M10-1.50 x 40mm
6	500688	Center Drive Block Shaft Mount
7 *	500696	Center Drive Shaft Assembly with Bearing and Cover
8	500692	Center Drive Side Plate
9	807-1553	Pull Pin
10	961035MSS	Hex Head Cap Screw M10-1.50 x 35mm
11	991009MSS	Hex Nut
12	5094WW	Infeed Center Drive Guard Assembly
13	5095WW	Center Drive Tension Spindle
14	802-162	Bearing

Item	Part Number	Description
15	5292WW	Center Drive Spindle
16	961016MSS	Hex Head Cap Screw M10-1.50 x 16mm
17	5125WW	Center Drive Cross Member Post
18	5149WW	Outfeed Center Drive Guard Assembly
19 	76CDD	Center Drive Bearing Kit when Conveyor is ordered with a Dorner Gearmotor Mounting Package (Includes Items 1 and 14)
	76CDC	Center Drive Bearing Kit when Conveyor is ordered without a Dorner Gearmotor Mounting Package (Includes Items 1 and 14)
20	5301WW	Center Drive Module (Includes items 1 through 18)

WW = Conveyor width ref: 06 - 60 in 02 increments

* When the conveyor is ordered with a Dorner gearmotor mounting package a shaft assembly is replaced with a gearmotor mounting bracket.

Idler End Components





Item	Part Number	Description
1	500891	Idler Shaft Assembly with Bearing and Cover
2	500791	Nut
3	500694	Pinch Guard Right Hand
4	5104WW	Idler Spindle
5	500695	Pinch Guard Left Hand
6	500675	Key Stop

Item	Part Number	Description
7	5048WW	Tip Up Shaft Assembly
8	802-162	Bearing
9	807-1454	Bearing Cover
10	76BK-WW	Bearing Kit (Includes Items 8 and 9)
11	76ST-WW	Idler Tail Kit (Includes Items 1 through 5)

WW = Conveyor width ref: 06 - 60 in 02 increments

Service Parts

.5" Nose Bar Idler End



Item	Part Number	Description
1	500997	.5" Nose Bar Shaft Assembly
2	500791	Nut
3	501087	Roller .5" x 1.06"
4	501086	Roller .5" x 1.72"
5	990608MSS	Acorn Nut
6	5099WW	Nose Bar Shaft
7	See Chart	Roller Mount
8	802-164	Return Spindle Bearing
9	5097WW	.5" Nose Bar Return Spindle


Item	Part Number	Description
10	5092WW	.5" Nose Bar Weldment Assembly
11	500675	Key Stop
12	5048WW	Tip Up Shaft Assembly
13	76NB5-WW	.5" Nose Bar Kit (Includes Items 3 through 7)
14	76NB-WW	.5" Idler Spindle Kit (Includes Items 3 through 9)
15	76NBT-WW	.5" Idler Tail Kit (Includes Items 1 through 10)

WW = Conveyor width ref: 06 - 60 in 02 increments

Item 7: Roller Mount	
Width	Part Number
152 mm	501078
203 mm	501077
254 mm	501078 & 501079
305 mm	501077 & 501079
356 mm	501077 & 501078
406 mm	501077 (x2)
457 mm	501077, 501078 & 501079
508 mm	501077 (x2) & 501079
559 mm	501077 (x2) & 501076
610 mm	501077 (x3)
660 mm	501077 (x2), 501078 & 501079
711 mm	501077 (x3) & 501079
762 mm	501077 (x3) & 501078
813 mm	501077 (x4)
864 mm	501077 (x3), 501078 & 501079
914 mm	501077 (x4) & 501079
965 mm	501077 (x4) & 501078
1016 mm	501077 (x5)
1067 mm	501077 (x4), 501078 & 501079
1118 mm	501077 (x5) & 501079
1168 mm	501077 (x5) & 501078
1219 mm	501077 (x6)
1270 mm	501077 (x5), 501078 & 501079
1321 mm	501077 (x6) & 501079
1372 mm	501077 (x6) & 501078
1422 mm	501077 (x7)
1473 mm	501077 (x6), 501078 & 501079
1524 mm	501077 (x7) & 501079

Service Parts

1" Nose Bar Idler End



Item	Part Number	Description
1	500997	1" Nose Bar Shaft Assembly
2	500791	Nut
3	802-164	Return Spindle Bearing
4	5107 WW	1" Nose Bar Return Spindle
5	802-123	Nose Bar Bearing
6	See Chart	1" Nose Bar Spindle
7	500975	Nose Bar Puck Holder Right Hand
8	5105 WW	1" Nose Bar Weldment Assembly
9	500976	Nose Bar Puck Holder Left Hand
10	501178	Pilot Nose Bolt


Item	Part Number	Description
11	500675	Key Stop
12	5048 WW	Tip Up Shaft Assembly
13	500977	Nose Bar Puck Holder, Center
14	76NB1- WW	1" Idler Spindle Kit (Includes Items 3 through 7 and 9)
15	76NBT1- WW	1" Idler Tail Kit (Includes Items 1 through 10)
16	76BK1- WW	Bearing Kit (Includes Items 3 and 5)

~~WW~~ = Conveyor width ref: 06 - 60 in 02 increments

Item 6: 1" Nose Bar Spindle	
Width	Part Number
152 mm	505107
203 mm	505108
254 mm	505109
305 mm	505110
356 mm	505103 (x2) & 505107
406 mm	505103 (x2) & 505108
457 mm	505103 (x2) & 505109
508 mm	505103 (x2) & 505110
559 mm	505104 (x2) & 505107
610 mm	505104 (x2) & 505108
660 mm	505104 (x2) & 505109
711 mm	505104 (x2) & 505110
762 mm	505106 (x2) & 505107
813 mm	505106 (x2) & 505108
864 mm	505106 (x2) & 505109
914 mm	505106 (x2) & 505110
965 mm	505104 (x4) & 505107
1016 mm	505104 (x4) & 505108
1067 mm	505104 (x4) & 505109
1118 mm	505104 (x4) & 505110
1168 mm	505105 (x4) & 505107
1219 mm	505105 (x4) & 505108
1270 mm	505105 (x4) & 505109
1321 mm	505105 (x4) & 505110
1372 mm	505106 (x4) & 505107
1422 mm	505106 (x4) & 505108
1473 mm	505106 (x4) & 505109
1524 mm	505106 (x4) & 505110

Service Parts

1.875" Nose Bar Idler End




Item	Part Number	Description
1	960520MSS	Hex Head Cap Screw M5-0.8 x 20 mm
2	501085	Transfer Bearing Cover
3	810-187	Grease Fitting
4	501083	1.875" Nose Bar Shaft Assembly Right Hand
5	500791	Nut
6	802-171	Bearing
7	501081	Pinch Guard block
8	5101WW	1.875" Nose Bar Spindle
9	501084	1.875" Nose Bar Shaft Assembly Left Hand

Item	Part Number	Description
10	500675	Key Stop
11	5048WW	Tip Up Shaft Assembly
12	76NB2-WW	1.875" Idler Spindle Kit (Includes Items 6 through 8)
13	76NB2-WW	1.875" Idler Tail Kit (Includes Items 1 through 9)
14	76BK2-WW	Bearing Kit (Includes Item 6)

WW = Conveyor width ref: 06 - 60 in 02 increments

Discharge End




Item	Part Number	Description
1	500892	Discharge Shaft Assembly with Bearing and Cover
2	500791	Nut
3	500694	Pinch Guard Right Hand
4	5104WW	Idler Spindle
5	500695	Pinch Guard Left Hand
6	802-162	Bearing

Item	Part Number	Description
7	807-1454	Bearing Cover
8	76BK-WW	Bearing Kit (Includes Items 6 and 7)
9	76SD-WW	Discharge Tail Kit (Includes Items 1 through 7)

WW = Conveyor width ref: 06 - 60 in 02 increments

Service Parts

.5" Nose Bar Discharge End



Item	Part Number	Description
1	501093	Discharge Nose Bar Shaft Assembly
2	500791	Nut
3	501087	Roller .5" x 1.06"
4	501086	Roller .5" x 1.72"
5	990608MSS	Acorn Nut
6	5099WW	Nose Bar Shaft
7	See Chart	Roller Mount
8	802-164	Return Spindle Bearing


Item	Part Number	Description
9	5097WW	.5" Nose Bar Return Spindle
10	5092WW	.5" Nose Bar Weldment Assembly
11	76NB5-WW	.5" Nose Bar Discharge Kit (Includes Items 3 through 7)
12	76NB-WW	.5" Spindle Discharge Kit (Included Items 3 through 9)
13	76NBD5-WW	.5" Discharge Tail Kit (Includes Items 1 through 10)

WW = Conveyor width ref: 06 - 60 in 02 increments

Item 7: Roller Mount	
Width	Part Number
6" (152 mm)	501078
8" (203 mm)	501077
10" (254 mm)	501078 & 501079
12" (305 mm)	501077 & 501079
14" (356 mm)	501077 & 501078
16" (406 mm)	501077 (x2)
18" (457 mm)	501077, 501078 & 501079
20" (508 mm)	501077 (x2) & 501079
22" (559 mm)	501077 (x2) & 501076
24" (610 mm)	501077 (x3)
26" (660 mm)	501077 (x2), 501078 & 501079
28" (711 mm)	501077 (x3) & 501079
30" (762 mm)	501077 (x3) & 501078
32" (813 mm)	501077 (x4)
34" (864 mm)	501077 (x3), 501078 & 501079
36" (914 mm)	501077 (x4) & 501079
38" (965 mm)	501077 (x4) & 501078
40" (1016 mm)	501077 (x5)
42" (1067 mm)	501077 (x4), 501078 & 501079
44" (1118 mm)	501077 (x5) & 501079
46" (1168 mm)	501077 (x5) & 501078
48" (1219 mm)	501077 (x6)
50" (1270 mm)	501077 (x5), 501078 & 501079
52" (1321 mm)	501077 (x6) & 501079
54" (1372 mm)	501077 (x6) & 501078
56" (1422 mm)	501077 (x7)
58" (1473 mm)	501077 (x6), 501078 & 501079
60" (1524 mm)	501077 (x7) & 501079

Service Parts

1" Nose Bar Discharge End



Item	Part Number	Description
1	501093	Discharge Nose Bar Shaft Assembly
2	500791	Nut
3	802-164	Return Spindle Bearing
4	5107WW	1" Nose Bar Return Spindle
5	802-123	Nose Bar Bearing
6	See Chart	1" Nose Bar Spindle
7	500975	Nose Bar Puck Holder, Right Hand
8	5105WW	1" Nose Bar Weldment Assembly
9	500976	Nose Bar Puck Holder, Left Hand


Item	Part Number	Description
10	501178	Pilot Nose Bolt
11	500977	Nose Bar Puck Holder, Center
12	76NB1-WW	1" Discharge Spindle Kit (Includes Items 3 through 7 and 9)
13	76NBD1-WW	1" Discharge Tail Kit (Includes Items 1 through 10)
14	76BK1-WW	Bearing Kit (Includes Items 3 and 5)

WW = Conveyor width ref: 06 - 60 in 02 increments

Item 6: 1" Nose Bar Spindle	
Width	Part Number
6" (152mm)	505107
8" (203mm)	505108
10" (254mm)	505109
12" (305mm)	505110
14" (356mm)	505103 (x2) & 505107
16" (406mm)	505103 (x2) & 505108
18" (457mm)	505103 (x2) & 505109
20" (508mm)	505103 (x2) & 505110
22" (559mm)	505104 (x2) & 505107
24" (610mm)	505104 (x2) & 505108
26" (660mm)	505104 (x2) & 505109
28" (711mm)	505104 (x2) & 505110
30" (762mm)	505106 (x2) & 505107
32" (813mm)	505106 (x2) & 505108
34" (864mm)	505106 (x2) & 505109
36" (914mm)	505106 (x2) & 505110
38" (965mm)	505104 (x4) & 505107
40" (1016mm)	505104 (x4) & 505108
42" (1067mm)	505104 (x4) & 505109
44" (1118mm)	505104 (x4) & 505110
46" (1168mm)	505105 (x4) & 505107
48" (1219mm)	505105 (x4) & 505108
50" (1270mm)	505105 (x4) & 505109
52" (1321mm)	505105 (x4) & 505110
54" (1372mm)	505106 (x4) & 505107
56" (1422mm)	505106 (x4) & 505108
58" (1473mm)	505106 (x4) & 505109
60" (1524mm)	505106 (x4) & 505110

Service Parts

1.875" Nose Bar Discharge End




Item	Part Number	Description
1	960520MSS	Hex Head Cap Screw M5-0.8 x 20mm
2	501085	Transfer Bearing Cover
3	810-187	Grease Fitting
4	501089	1.875" Discharge Nose Bar Shaft Assembly Right Hand
5	500791	Nut
6	802-171	Bearing
7	501081	Pinch Guard block

Item	Part Number	Description
8	5101WW	1.875" Nose Bar Spindle
9	501090	1.875" Discharge Nose Bar Shaft Assembly Left Hand
10	76NB2-WW	1.875" Discharge Spindle Kit (Includes Items 6 through 8)
11	76NBD2-WW	1.875" Discharge Tail Kit (Includes Items 1 through 9)
12	76BK2-WW	Bearing Kit (Includes Item 6)

WW = Conveyor width ref: 06 - 60 in 02 increments

Conveyor Frame and Extensions with Standard Wear Strips




Item	Part Number	Description
1	-----	Consult Factory for Frame Part Number
2	501800-LLL	Wear Strip

Item	Part Number	Description
3	500193	Hex Post Connector
4	961020MSS	Hex Head Cap Screw M10-1.5 x 20 mm
LLL = Conveyor length ref: 036 - 480 in 001 increments		


Service Parts

Wear Strips with Stainless Steel Sheet Bed Plate



Item	Part Number	Description
1	5123 <u>WW</u> - <u>LLL</u>	Bed Plate
2 	501098- <u>LLL</u>	Wear Strip
<u>WW</u> = Conveyor width ref: 06 - 60 in 02 increments		
<u>LLL</u> = Conveyor length ref: 036 - 480 in 001 increments		


Lifters



Item	Part Number	Description
1	5121WW	Belt Lifter Shaft
2	500195	Belt Lifter
3	500491	Belt Lifter Handle
4	960812MSS	Hex Head Cap Screw, M8-1.25 x 12 mm

WW = Conveyor width ref: 06 - 60 in 02 increments

Gas Assisted Tip Up




Item	Part Number	Description
1	5049WW	Gas Assist Tip Up Shaft Assembly
2	500675	Key Stop
3	500895	Tip Up Bushing
4	807-1553	Pull Pin
5	807-1562	Gas Spring 70 lb. for Standard Tails 42"-60" wide or Nose Bar Tails 18"-30" wide
	807-1563	Gas Spring 130 lb., for Nose Bar Tails 32"-46" wide
	807-1564	Gas Spring 160 lb., for Nose Bar Tails 48"-60" wide
6	500794	Gas Spring Stand Off Post
7	960616MSS	Hex Head Cap Screw, M6-1.00 x 16mm
8	961016MSS	Hex Head Cap Screw, M10-1.50 x 16mm
9	500792	Gas Spring Clevis
10	500793	Gas Spring Eyelet

WW = Conveyor width ref: 06 - 60 in 02 increments

Service Parts


76 mm High Sides



Item	Part Number	Description
1	503460-LLLLL	High Side Guide for Conveyors 3'-11' Long
	503550-LLLLL	High Side Right Hand Guide for Conveyors over 11' Long
2	503460-LLLLL	High Side Guide for Conveyors 3'-11' Long

Item	Part Number	Description
3	503650-LLLLL	High Side Right Hand Guide for Conveyors over 11' Long
	503450-LLLLL	High Side Guide Square End
4	807-1553	Pull Pin
LLLLL = Guide Length in inches with 2 decimal places.		
Example: Guide Length = 95.25" LLLLL = 09525		


Flat Belt Returns



Item	Part Number	Description
1	807-1551	Clamp
2	500990	Return Disk
3	5108WW	Return Shaft
4	76R-WW	Return Kit (Includes Items 1 and 2)

WW = Conveyor width ref: 06 - 60 in 02 increments

Scraper



Item	Part Number	Description
1	961012MSS	Hex Head Cap Screw, M10-1.50 x 12 mm
2	500878	Scraper Adjust Plate
3	5102WW	Scraper Shaft Assembly
4	500881	Scraper Holder Bar
5	5047WW	Scraper Wear Bar
6	807-1553	Pull Pin
7	500879	Scraper Mount Plate
8	807-1559	Handle

WW = Conveyor width ref: 06 - 60 in 02 increments

Service Parts

Configuring Conveyor Belt Part Number




Figure 99

Flat Belt Part Number Configuration

Refer to model number on the conveyor frame (**Figure 99**). From the model number determine the conveyor width (WW), length (LLL), drive/tail types (A) and belt type (BB). Use data to configure belt part number as indicated below.
*Add "V" for v-guided belts.

76-WW LLL A / BB V*

76- _____ / ____ V*
(Fill In)

Return Policy

Returns must have prior written factory authorization or they will not be accepted. Items that are returned to Dorner without authorization will not be credited nor returned to the original sender. When calling for authorization, please have the following information ready for the Dorner factory representative or your local distributor:

1. Name and address of customer.
2. Dorner part number(s) of item(s) being returned.
3. Reason for return.
4. Customer's original order number used when ordering the item(s).
5. Dorner or distributor invoice number.

A representative will discuss action to be taken on the returned items and provide a Returned Goods Authorization number for reference.

There will be a return charge on all new undamaged items returned for credit where Dorner was not at fault. Dorner is not responsible for return freight on such items.

Conveyors and conveyor accessories

Standard catalog conveyors	30%
MPB Series, cleated and specialty belt conveyors	50%
7400 & 7600 Series conveyors	non-returnable items
Engineered special products	case by case
Drives and accessories	30%
Sanitary stand supports	non-returnable items

Parts

Standard stock parts	30%
MPB, cleated and specialty belts	non-returnable items

Returns will not be accepted after 60 days from original invoice date.

The return charge covers inspection, cleaning, disassembly, disposal and reissuing of components to inventory.

If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Contact Dorner for the name of your local representative. Our Technical Sales, Catalog Sales and Service Teams will gladly help with your questions on Dorner products.

For a copy of Dorner's Warranty, contact factory, distributor, service center or visit our website at www.dorner.com.

For replacement parts, contact an authorized Dorner Service Center or the factory.



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. © Dorner Mfg. Corp. 2008

DORNER MFG. CORP.
975 Cottonwood Ave., PO Box 20
Hartland, WI 53029-0020 USA
USA
TEL 1-800-397-8664 (USA)
FAX 1-800-369-2440 (USA)
Internet: www.dorner.com

Outside the USA:
TEL 1-262-367-7600
FAX 1-262-367-5827