

Important Safety Notice

Light Load Fixed Speed Gearmotors Models: 62M015PL411FN and 62M036PL411FN and Light Load Replacement Motor Model: 62MPL411FN



Introduction

Dorner Light Load Fixed Speed Gearmotors, 62M015PL411FN and 62M036PL411FN, and Light Load Replacement Motor, 62MPL411FN, shipped from December 15, 1998 to February 13, 2001 contain a thermal overload. If these motors are overloaded, the thermal overload will open and the motor will stop. Once cooled, the motor will start on its own. Please follow the enclosed instructions to disable the thermal overload. The motor will then be protected by its line fuse, which will not automatically reset if tripped.

Instructions

- 1. Install the wiring harness and fuse as detailed on pages 2 through 5 of this document.
- 2. Complete the form on the back page of this document. Fax this form to 1-800-369-2440.
- 3. If any questions arise while performing this service, call Dorner Service Manager at 1-800-397-8664.

In appreciation for your efforts, the warranty for all Gearmotors serviced will be extended for 1 year from the date the service was performed.

Required Tools

- D Pliers (2x)
- **D** Wire Cutter
- D Flat-blade screwdriver



- A Wiring Harness
- B Wire nut
- C Fuse (1/2 Amp.)
- **1.** Gather components (Figure 1).



NOTE: For your convenience, Dorner has included two sets of male and female wire terminals (Figure 2). These terminals will only be required if damage is done to existing terminals while performing service, resulting in the need to install new terminals. Call Dorner Service manager at 1-800-397-8664 ext. 1315 with any questions regarding installation of these replacement terminals.



2. Locate gearmotor. Gearmotors will be found on Side Mount Packages (Figure 3), Top Mount Packages (Figure 4) or Bottom Mount Packages (Figure 5).



Figure 3





Figure 4

Figure 5

NOTE: The following steps show the installation being performed on a motor without mount package for ease of clarity only. All steps can be performed without disassembly of gearmotor from mount package.

3. Unplug motor cord (D of Figure 6) from electrical outlet.



Figure 6

4. Remove two (2) cover screws (E of Figure 7) and remove cover (F).



Figure 7

5. Locate black wire (K of Figure 8) connected to red wire (J).



Figure 8

IMPORTANT: To unplug wires, use pliers to grip terminal leads (as in Figure 9). Do not pull wires.

6. Unplug red wire (J of Figure 9) from black wire (K).



Figure 9

7. Cut red lead (J of Figure 10).



Figure 10

8 Turn wire nut (B of Figure 11) clockwise onto end of red wire (J).



Figure 11

9. Locate motor grommet (L of Figure 12).



Figure 12

10. Locate dark blue wire (H of Figure 13) passing through motor grommet (L). If the dark blue wire (H) is connected to the black wire (G), proceed to step 11a. If the dark blue wire (H of Figure 14) is connected to the gray wire (I), proceed to step 11b.







IMPORTANT: To unplug wires, use pliers to grip terminal leads (as in Figure 9). Do not pull wires.

11a. Unplug black wire (G of Figure 15) from dark blue wire (H).





NOTE: Wire terminals may require some force to fully insert. Take care to ensure that wire terminals are fully inserted.

12a. Connect female end of wiring harness (A of Figure 17) to dark blue wire (H).





13a. Connect male ends of wiring harness (A of Figure 18) to black wire (G) and black wire (K) (from red). Proceed to step 14.



Figure 18

IMPORTANT: To unplug wires, use pliers to grip terminal leads (as in Figure 9). Do not pull wires.

11b. Unplug gray wire (I of Figure 16) from dark blue wire (H).



Figure 16

NOTE: Wire terminals may require some force to fully insert. Take care to ensure that wire terminals are fully inserted.

12b. Connect female end of wiring harness (A of Figure 19) to dark blue wire (H).



Figure 19

13b. Connect male ends of wiring harness (A of Figure 20) to gray wire (I) and black wire (K) (from red).



Figure 20

14. Insert wires into enclosure and attach cover (F of Figure 21) with screws (E) taking care not to pinch wires with cover.





15. Push in and turn to open fuse holder cover (M of Figure 22).



Figure 22

16. Remove and discard old fuse (N of Figure 23).



Figure 23

17. Insert new 1/2 Amp. fuse (C of Figure 24) and reinstall fuse holder cover (M).



Figure 24

18. Please complete the form on the back page of this document and fax it back to Dorner at 1-800-369-2440. Thank you for your assistance.

Fax or Mail to Dorner

Please complete this form and fax or mail to Dorner.

Dorner Attn.: Service Manager Fax: 1-800-369-2440 Phone: 1-800-397-8664 ext. 1315

Address: P.O. Box 20 Hartland, WI 53029-0020

Please make a copy of this form for your records.

Thank you for your assistance. In appreciation for your efforts, the warranty for all Gearmotors serviced will be extended for 1 year from the date the service was performed.