


## 3200 Series Center Drive Flat Belt Conveyors





## Table of Contents

Warnings – General Safety .....	2	End Pulley Removal .....	15
Introduction .....	2	A – Idler Pulley Removal .....	15
Product Description .....	3	C – Transfer Tail Pulley Removal .....	16
Specifications .....	3	Center Drive Pulleys Removal .....	17
Installation .....	6	A – Tensioner Pulley Removal .....	18
Required Tools .....	6	B – Idler Pulley Removal .....	19
Recommended Installation Sequence .....	6	C – Drive Pulley Removal .....	20
Conveyors Up to 12 ft (3658 mm) .....	6	Bearing Replacement .....	22
Conveyors Longer Than 12 ft (3658 mm) .....	6	Idler Bearing Replacement .....	22
Mounting Brackets .....	7	Drive Bearing Removal and Replacement .....	22
Return Rollers .....	7	Transfer Tail Pulley .....	24
4 – 6" (102 – 152 mm) Wide Conveyors .....	7	Pulley Replacement .....	24
8 – 48" (203 – 1219 mm) Wide Conveyors .....	7	Idler Pulley .....	24
Gearmotor Installation .....	8	Drive Pulley .....	24
Preventative Maintenance & Adjustment .....	9	Transfer Tail Pulley .....	24
Required Tools .....	9	Service Parts .....	27
Standard Tools .....	9	Center Drive Assembly .....	26
Checklist .....	9	Center Drive 90 Deg Industrial Gearmotors .....	28
Lubrication .....	9	Conveyor Belt Part Number Configuration .....	29
Maintaining Conveyor Belt .....	9	Transfer Tail Assembly .....	30
Troubleshooting .....	9	Idler End Tail Assembly .....	31
Cleaning .....	9	Frame Assembly .....	32
Conveyor Belt Replacement .....	10	–04 3" (76mm) Aluminum Side .....	34
Conveyor Belt Replacement Sequence .....	10	–05 1.5" (38mm) Aluminum Side .....	35
Belt Removal for Conveyor Without		–07 Low to Side Wiper .....	36
Stands or Gearmotor Mounting Package .....	10	–09 Low to High Side .....	37
Belt Removal for Conveyor With		–10 .5" (13mm) Extruded Plastic .....	38
Stands and Gearmotor Mounting Package .....	11	–13 Adjustable Guiding .....	39
Belt Installation for Conveyor Without		Flared Side Guiding .....	40
Stands or Gearmotor Mounting Package .....	12	Flat Belt Mounting Bracket .....	41
Belt Installation for Conveyor With		Cleated Belt Mounting Bracket .....	41
Stands and Gearmotor Mounting Package .....	12	Connecting Assembly without Stand Mount .....	42
Conveyor Belt Tensioning .....	13	Flat Belt Connecting Assembly without	
Conveyor Belt Tracking .....	13	Stand Mount .....	42
V – Guided Belts .....	13	Cleated Belt Connecting Assembly without	
Non V–Guided Belts .....	13	Stand Mount .....	42
Center Drive Tracking .....	14	2" (51mm) to 6" (152mm) Flat Belt Return Roller .....	42
V – Guided Belts .....	14	8" (203mm) to 48" (1219mm) Flat Belt Return Roller .....	43
Non V–Guided Belts .....	14	Return Policy .....	44



## Warnings – General Safety



	<b>WARNING</b>	
<p>The safety alert symbol, black triangle with white exclamation, is used to alert you to potential personal injury hazards.</p>		



	 <b>DANGER</b>
<p>Climbing, sitting, walking or riding on conveyor will cause severe injury. <b>KEEP OFF CONVEYORS.</b></p>	



	 <b>WARNING</b>
<p>Gearmotors may be HOT. <b>DO NOT TOUCH Gearmotors.</b></p>	

	 <b>DANGER</b>
<p><b>DO NOT OPERATE CONVEYORS IN AN EXPLOSIVE ENVIRONMENT.</b></p>	

	 <b>WARNING</b>
<p>Exposed moving parts can cause severe injury. <b>LOCK OUT POWER</b> before removing guards or performing maintenance.</p>	

	 <b>WARNING</b>
<p>Exposed moving parts can cause severe injury. <b>REMOVE COMPRESSED AIR SUPPLY</b> before removing guards or performing maintenance.</p>	

	 <b>WARNING</b>
<p>Dorner cannot control the physical installation and application of conveyors. Taking protective measures is the responsibility of the user.  When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, <b>CHECK FOR POTENTIAL PINCH POINTS</b> and other mechanical hazards before system start-up.</p>	

	 <b>WARNING</b>
<p>Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing severe injury. <b>SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.</b></p>	

## Introduction

**IMPORTANT:** Some illustrations may show guards removed. **DO NOT** operate equipment without guards.

Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage.
- Accessories may be shipped loose. See accessory instructions for installation.

Dorner's Limited Warranty applies.

Dorner 3200 series conveyors are covered by Patent Numbers 5,156,260, and corresponding patents and patent applications in other countries.

Dorner reserves the right to make changes at any time without notice or obligation.

# Product Description

Refer to Figure 1 for typical conveyor components.

Typical Components	
A	Conveyor
B	Gearmotor
C	Guiding & Accessories
D	Mounting Brackets
E	Support Stand
F	Variable Speed Controller
G	Center Drive Module
H	Idler End




Figure 1

# Specifications

## Models:

### Center Drive 3200 Series Conveyor 3 1 5 M WW LLLL / PP TT

- Belt Type\*  
Profile\*
- Conveyor Length Reference
- Conveyor Width Reference
- Document Language, M = English
- 5 = 3" tails
- 6 = 1" tail at infeed
- 7 = 1" tail at discharge
- 8 = 1" tails
- 1 = Flat belt with tracking cams and supports
- 2 = Flat belt with V-guide tracking and supports
- 3 = Flat belt with tracking cams
- 4 = Flat belt with V-guide tracking

\* See Ordering and Specifications Catalog for details.

## Conveyor Supports:

### Maximum Distances:

I = 36" (914 mm) (Infeed End)

J = 12 ft (3658 mm)

K = 36" (914 mm) (Discharge End)






Figure 2

# Specifications

## Specifications:



Conveyor Width Reference (WW)	04	06	08	10	12	18	24	30	36	48	
Conveyor Belt Width	3.75" (95mm)	6" (152mm)	8" (203mm)	10" (254mm)	12" (305mm)	18" (457mm)	24" (609mm)	30" (762mm)	36" (915mm)	48" (1220mm)	
Conveyor Length Reference (LLLL)	0300 to 9900 in 0001 increments										
Conveyor Length	4 ft (1219mm) to 99 ft (30175mm) in 0.12" (0.31mm) increments										
Belt Travel	18.8" (478 mm) per revolution of pulley										
Maximum Belt Speed*	600 ft/minute (183 m/minute)										
Belt Takeup	16" (407 mm) of Belt Takeup										

\* See Ordering and Specifications Catalog for details.

**NOTE:** Maximum conveyor loads based on:

- Non-accumulating product
- Product moving towards gearmotor
- Conveyor being mounted horizontal

**Table 1: Belt Speeds for Variable Speed 90° VDC Gearmotors**

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHD9DEN	25	630	71	4.0–40.0	1.2–12.2
32M080HHD9DEN	31	575	65	5.0–50.0	1.5–15.2
32M060HHD9DEN	42	469	53	6.7–66.7	2.0–20.3

(vp) = voltage and phase

11 = 115 V, 1-phase

23 = 208 – 230/460 V, 3-phase

**Table 2: Belt Speeds for Fixed Speed 90° Gearmotors**

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHvpfN	17	913	103	27.6	8.4
32M080HHvpfN	22	833	94	34.5	10.5
32M060HHvpfN	29	680	77	46.0	14.0
32M050HHvpfN	35	1206	136	55.2	16.8
32M040HHvpfN	43	1023	116	69.0	21.0
32M030HHvpfN	58	1217	138	92.0	28.0
32M025HHvpfN	69	1069	121	110.4	33.7
32M020HHvpfN	86	1184	134	138.0	42.1
32M015HHvpfN	115	910	103	184.0	56.1
32M010HHvpfN	173	636	72	276.0	84.1
32M008HHvpfN	230	482	54	368.0	112.2

**Table 3: Belt Speeds for Variable Speed 90° VFD Gearmotors**

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHvpfN	17	913	103	2.8–27.6	0.8–8.4
32M080HHvpfN	22	833	94	3.5–34.5	1.1–10.5
32M060HHvpfN	29	680	77	4.6–46.0	1.4–14.0
32M050HHvpfN	35	1206	136	5.5–55.2	1.7–16.8
32M040HHvpfN	43	1023	116	6.9–69.0	2.1–21.0
32M030HHvpfN	58	1217	138	9.2–92.0	2.8–28.0
32M025HHvpfN	69	1069	121	11.0–110.4	3.4–33.7
32M020HHvpfN	86	1184	134	13.8–138.0	4.2–42.1
32M015HHvpfN	115	910	103	18.4–184.0	5.6–56.1
32M010HHvpfN	173	636	72	27.6–276.0	8.4–84.1
32M008HHvpfN	230	482	54	36.8–368.0	11.2–112.2

**Table 4: Belt Speeds for Variable Speed 90° VFD Integrated Motor Control Gearmotors**

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HH411EC	17	913	103	4.6–36.7	1.4–11.2
32M060HH411EC	29	680	77	7.7–61.2	2.3–18.7
32M040HH411EC	43	1023	116	11.5–91.8	3.5–28.0
32M015HH411EC	69	712	80	18.4–146.8	5.6–44.8
32M020HH411EC	86	592	67	23.0–183.5	7.0–56.0
32M015HH411EC	115	455	51	30.7–244.7	9.4–74.6

(vp) = voltage and phase

11 = 115 V, 1-phase

23 = 208 – 230/460 V, 3-phase

**NOTE: For belt speed other than those listed, contact factory for details.**

# Installation

**NOTE:** Conveyor **MUST** be mounted straight, flat and level within confines of conveyor. Use a level (L of Figure 3) for setup.




Figure 3

## Required Tools

- Hex-key wrenches:  
4 mm, 5 mm
- Level
- Torque wrench
- 8 mm Hex, Open End Wrench

## Recommended Installation Sequence

- Install support stands (see accessory instructions)
- Assemble conveyor (if required)
- Attach mounting brackets to conveyor
- Attach conveyor to stands
- Install return rollers on conveyor (optional)
- Mount gearmotor mounting package (see page 8)
- Attach guides/accessories (see page 34 through 43 of “Service Parts” section for details)

## Conveyors Up to 12 ft (3658 mm)

No assembly is required. Install mounting brackets and return rollers. Refer to “Mounting Brackets” on page 7 and “Return Rollers” on page 7.

## Conveyors Longer Than 12 ft (3658 mm)

1. Locate conveyor sections (M Figure 4)

### Installation Component List

M	Conveyor frame with drive end
N	Conveyor frame with idler end
O	Belt
P	Connector bracket




Figure 4

2. Roll out conveyor belt and place conveyor frame sections (M of Figure 5) into belt loop.



Figure 5

3. Join conveyor sections and install connector brackets (Q of Figure 6) or connector/mount brackets (QA) and screws (R) on both sides as indicated. Tighten screws to 60 in-lb (7 Nm).





Figure 6

4. Install mounting brackets and return rollers. Refer to “Mounting Brackets” on page 7 and “Return Roller” on page 7.
5. Install Gearmotor. See “Gearmotor Installation” section on page 8.
6. Tighten conveyor belt, refer to “Conveyor Belt Tensioning” on page 13.
7. If belt tracking is necessary, refer to “Conveyor Belt Tracking” on page 13 and “Center Drive Module Tracking” on page 14.


## Mounting Brackets

1. Locate brackets. Exploded views shown in Figure 7.



Mounting Brackets for Flat Belt Conveyor  
**Figure 7**

2. Remove screws (S & T of Figure 7), washers (U), nuts (V) and T-bars (W) from brackets.
3. Insert T-bars (W of Figure 7) into conveyor side slots (W of Figure 8). Fasten brackets (X of Figure 8) to conveyor with mounting screws (S).




**Figure 8**

4. Fasten brackets to support stand with mounting screws (T of Figure 8), washers (U) and nuts (V).
5. Tighten screws (S & T of Figure 8) to 60 in-lb (7 Nm).

## Return Rollers


### 4–6" (51–152 mm) Wide Conveyors

1. Locate return rollers. Exploded view shown in Figure 9.



Return Rollers for Flat Belt Conveyor  
**Figure 9**


2. Remove screws (Y of Figure 9) and clips (Z) from roller assembly.
3. Install roller assemblies (AA of Figure 10) as shown. Tighten screws (Y) to 60 in-lb (7 Nm).



**Figure 10**


### 8–48" (203–1219 mm) Wide Conveyors

1. Locate return rollers. Exploded view shown in Figure 11.



**Figure 11**

2. Remove screws (AB of Figure 11) and clips (AC) from roller assembly.
3. Install roller assembly as shown (AD of Figure 12). Tighten screws (AB) to 60 in-lb (7 Nm).



**Figure 12**


# Installation

## Gearmotor Installation

### Required Tools

- Hex key wrenches:  
2 mm, 2.5 mm, 3 mm, 5 mm
- Torque wrench

### Mounting



1. Locate components of Figure 13.




Figure 13

#### Gearmotor Installation Component List

AE	Gearhead with mounting bracket
AF	Motor
AG	Gear Reducer Key
AH	Cover
AI	Cover Bolts
AJ	Motor Mount Bolts
AK	Spacer Ring

**NOTE:** Gearmotor may be operated in positions 1, 3 or 4 (Figure 14).




Figure 14

2. If required, change gearmotor position by removing four (4) screws (AL of Figure 15). Rotate gearmotor mounting plate to other position and replace screws (AL). Tighten to 200 in-lb (22.5 Nm).




Figure 15



3. Install key (AG of Figure 16) on drive shaft(AM). Install cover (AH) over bearing housing (AN)




Figure 16



4. Install cover (AH of Figure 17) with four (4) screws (AI).




Figure 17

5. Slide gearmotor (AE of Figure 18) on to drive shaft (AM of Figure 16). Tighten mounting screws (AJ) to 200 in-lbs (22.5 N-m).




Figure 18

---

## Preventive Maintenance and Adjustment

---

### Required Tools

#### Standard Tools

- Hex-key wrenches:  
2.5 mm, 4 mm, 5 mm, 6 mm
- 8 mm Hex, Open End Wrench

#### Checklist

- Keep service parts on hand (see “Service Parts” section for recommendations)
- Keep supply of belt cleaner (part # 625619)
- Clean entire conveyor and knurled pulley while disassembled
- Replace worn or damaged parts

#### Lubrication

No lubrication is required. Replace bearings if worn.

### Maintaining Conveyor Belt

#### Troubleshooting

Inspect conveyor belt for:

- Surface cuts or wear
- Stalling or slipping
- Damage to V-guide

Surface cuts and wear indicate:

- Sharp or heavy parts impacting belt
- Jammed parts
- Improperly installed bottom wipers (if installed)

- Accumulated dirt in wipers (if installed)
- Foreign material inside the conveyor
- Improperly positioned accessories
- Bolt-on guiding is pinching belt

Stalling or slipping indicates:

- Excessive load on belt
- Conveyor belt or drive timing belt are not properly tensioned
- Worn knurl or impacted dirt on drive pulley
- Intermittent jamming or drive train problems

Damage to V-guide indicates:

- Twisted or damaged conveyor frame
- Dirt impacted on pulleys
- Excessive or improper side loading

---

**NOTE:** Visit [www.dorner.com](http://www.dorner.com) for complete list of troubleshooting solutions.

---

#### Cleaning

---

**IMPORTANT:** Do not use belt cleaners that contain alcohol, acetone, Methyl Ethyl Ketone (MEK) or other harsh chemicals.



---

Use Dorner Belt Cleaner (part # 625619). Mild soap and water may also be used. Do not soak the belt.

For /05 woven polyester and /06 black anti-static belts, use a bristled brush to improve cleaning.

# Preventive Maintenance and Adjustment

## Conveyor Belt Replacement



### Conveyor Belt Replacement Sequence

- Remove old conveyor belt:
  - Conveyor without Stands or Gearmotor Mounting Package
  - Conveyor with Stands and Gearmotor Mounting Package
- Install new conveyor belt
- Tension conveyor belt

### Belt Removal for Conveyor Without Stands

1. Remove air supply and remove hose (AO of Figure 19) from center drive.




Figure 19

2. If equipped, remove return rollers and guiding and accessories from one side of conveyor.

3. Temporarily support idler guard assembly (AP of Figure 20). Remove screws (AQ).




Figure 20

4. Swing down idler guard assembly (AP of Figure 21). Remove screw (AR) from both sides of center drive and remove idler guard assembly (AP).



Figure 21

5. Remove screws (AS of Figure 22) and tensioning guards (AT) from both sides of center drive.




Figure 22

6. Temporarily support the tensioning roller guard (AV of figure 23). Remove screws (AU of Figure 23) on

# Preventive Maintenance and Adjustment

both sides of center drive and remove tensioning roller guard (AV of Figure 23 and 24).




Figure 23

7. Loosen tensioning roller set screws (AW of Figure 24).




Figure 24

8. Push shaft (AX of Figure 24) through block, slide block (AY of Figure 25) towards air cylinder (AZ).




Figure 25

9. Push shaft (AX of Figure 26) through block (AY) on opposite side of center drive, slide block toward air cylinder (AZ).




Figure 26

10. Slide out tensioning roller (BA of Figure 27).




Figure 27

11. Remove belt (BB of Figure 28) from center drive module (B) and conveyor.




Figure 28

## Belt Removal for Conveyor With Stands

	<div data-bbox="1136 1648 1510 1711"> <b>WARNING</b></div> <p data-bbox="1136 1722 1510 1848">Removing mounting brackets without support under gearmotor will cause conveyor to tip, causing severe injury.</p> <p data-bbox="1136 1858 1510 1932"><b>PROVIDE SUPPORT UNDERNEATH THE GEARMOTOR WHEN CHANGING THE BELT</b></p>
--	--

# Preventive Maintenance and Adjustment

1. Place temporary support stands (BC of Figure 29) at both ends of the conveyor. See **WARNING**.




Figure 29

2. If equipped, remove return rollers, guiding and accessories from one side of conveyor.
3. Repeat steps 1 thru 10 of the “Belt Removal for Conveyors Without Stands” section on page 10.
4. Remove first mounting brackets (BD of Figure 29) from one side of conveyor. (Reverse steps 3 & 4 of “Mounting Brackets” section on page 7).
5. Remove belt (BB of Figure 30) from conveyor, one stand at a time. Start on one end of conveyor and work down to opposite end.




Figure 30

## Belt Installation for Conveyor without Stands

1. Orient belt so splice leading fingers (BE of Figure 31) point in the direction of belt travel as identified by the conveyor directional label (BF).




Figure 31

2. Slide belt onto the conveyor frame assembly.
3. Reverse steps 1 thru 10 of the “Belt Removal for Conveyors Without Stands” section on page 10.

4. If equipped, install wipers, return rollers and guiding.
5. Reattach air supply (AO of Figure 32) to center drive. Refer to “Conveyor Belt Tensioning” section on page 13 for more information.




Figure 32

6. Track conveyor and center drive if required. See “Center Drive Module Tracking” section on page 14 and “Conveyor Belt Tracking” section on page 13.

## Belt Installation for Conveyor with Stands

	<div data-bbox="1047 1012 1404 1075"> <b>WARNING</b></div> <p data-bbox="1047 1087 1421 1207">Removing mounting brackets without support under gearmotor will cause conveyor to tip, causing severe injury.</p> <p data-bbox="1047 1218 1421 1291"><b>PROVIDE SUPPORT UNDERNEATH THE GEARMOTOR WHEN CHANGING THE BELT</b></p>
--	--

1. Ensure temporary support stands (BC of Figure 29) are placed at both ends of the conveyor. See **WARNING**.
2. Orient belt so splice leading fingers (BE of Figure 31) point in the direction of belt travel as identified by the conveyor directional label (BF).
3. Install belt (BB of Figure 33) on conveyor. Lift conveyor slightly to avoid pinching belt on temporary support stands.




Figure 33

# Preventive Maintenance and Adjustment


- Reverse steps 1 thru 10 of the “Belt Removal for Conveyors Without Stands” section on page 10.
- Re-install conveyor mounting brackets. Refer “Mounting Brackets” on page 7, steps 3 through 5.
- If equipped, install wipers, return rollers and guiding.
- Reattach air supply (AO of Figure 32) to center drive. Refer to “Conveyor Belt Tensioning” section on page 13 for more information.
- Track drive and conveyor if required. See “Center Drive Module Tracking” section on page 14 and “Conveyor Belt Tracking” section on page 13.

## Suggested Tensioning Air Pressure for LPZ & 3200 Series Flat Belt Center Drive Conveyors

Width	Pressure
4" (95 mm)	20 psi (138 kPa)
6" (152 mm)	30 psi (207 kPa)
8" (203 mm)	40 psi (276 kPa)
10" (254 mm)	50 psi (345 kPa)
14" (356 mm)	60 psi (414 kPa)
18" (457 mm)	70 psi (483 kPa)
24" (610 mm) & wider	80 psi (552 kPa)

- If proper belt tension cannot be achieved before the out of tension indicator (BH of Figure 35) begins to turn red, the belt must be replaced.

## Conveyor Belt Tensioning



- Connect air supply (AO of Figure 34) to regulator (BG).
- Adjust regulator (BG of Figure 34) until gage reads the appropriate pressure. See following table for suggested pressures.




Figure 34




Figure 35

- If belt tracking is necessary, refer to “Conveyor Belt Tracking” on page 13 and “Center Drive Module Tracking” on page 14.

## Conveyor Belt Tracking

### V-Guided Belts

V-guided belts do not require tracking adjustment.

### Non V-Guided Belts

Non V-guided belt conveyors are equipped with belt tracking assemblies.

When adjusting belt tracking, always adjust the discharge end of the conveyor first. To adjust belt tracking:

- On the side of conveyor which the belt is tracking towards, loosen the head plate fastening screws (BI of Figure 36).

# Preventive Maintenance and Adjustment




Figure 36

2. With the conveyor running, use wrench (BJ of Figure 37) to rotate the tracking screw (BK of Figure 38) in small increments until the belt tracks in the center of the conveyor.




Figure 37




Figure 38

3. Re-tighten the head plate fastening screws (BI of Figure 36) with a 5 mm hex-key wrench to 146 in-lb (16.5 Nm).

## Center Drive Module Tracking

### V-Guided Belts

V-guided belts do not require tracking adjustment.

### Non V-Guided Belts

Non V-guided belt center drives are equipped with cam tracking assemblies.

To adjust center drive tracking, with the conveyor running:

1. Inspect belt as it exits the center drive:  
Figure 39 – Normally tracked belt, do nothing  
Figure 40 – Tracking necessary, adjust tight side cam



Figure 39



Figure 40

2. If necessary, adjust the tracking cam: loosen the center drive fastening screws (BL of Figure 41) on the side of center drive to be tracked.




Figure 41

3. Rotate the tracking cam (BM of Figure 42) in small increments, each time inspecting the belt as it exits the center drive. Continue to rotate the tracking cam until conveyor belt is tracking normally.



# Preventive Maintenance and Adjustment








Figure 42

4. Tighten the center drive fastening screws (BL of Figure 41) to 146 in-lbs (16.5 N-m).

## End Pulley Removal

	 <b>WARNING</b> Exposed moving parts can cause severe injury. <b>LOCK OUT POWER</b> before removing guards or performing maintenance.
--	--

	 <b>WARNING</b> Exposed moving parts can cause severe injury. <b>REMOVE COMPRESSED AIR SUPPLY</b> before removing guards or performing maintenance.
---	--

1. Remove air supply and remove hose (AO of Figure 43) from center drive.




Figure 43

2. Temporarily support idler guard assembly (AP of Figure 20). Remove screws (AQ).




Figure 44

3. Swing down idler guard assembly (AP of Figure 45).



Figure 45

Remove the desired pulley following the corresponding instructions below:

- A – 3" Idler Pulley Removal
- B – Transfer Tail Pulley Removal

### A – Idler Pulley Removal

1. Temporarily support the idler pulley.



Figure 46

2. On one side of conveyor, loosen the two (2) back fastening screws (BI of Figure 47) and remove two (2) front fastening screws (BN).

# Preventive Maintenance and Adjustment




Figure 47




Figure 50

3. Pull back the outer headplate (BO of Figure 48) and remove the inner spacer (BP).




Figure 48

4. Slide the idler pulley assembly (BQ of Figure 49) out of the headplate on the opposite side.




Figure 49

5. Remove the pulley shaft assembly: remove the clip ring (BR of Figure 50) and washer (BS) from one side of the pulley assembly.

6. Slide the shaft assembly (BT of Figure 51) out of the pulley (BQ).




Figure 51

## B – Transfer Tail Pulley Removal

1. Temporarily support the transfer tail assembly.



Figure 52

2. On one side of conveyor, loosen the two (2) back fastening screws (BI of Figure 53), and remove the two (2) front fastening screws (BN).



# Preventive Maintenance and Adjustment




Figure 53

3. Remove the inner spacer (BP of Figure 54).




Figure 54

4. Slide the transfer tail pulley assembly (BV of Figure 55) out of the headplate on the opposite side.




Figure 55

5. Remove hex nuts (BW of Figure 56).



Figure 56

6. Remove support plates (BX of Figure 57) and washers (BY).




Figure 57

7. Remove pulleys (BZ of Figure 58) and additional washers (CA).





Figure 58

8. To remove additional pulleys, repeat steps 6 through 7.

## Center Drive Pulleys Removal

	<p><b>! WARNING</b></p> <p>Exposed moving parts can cause severe injury.</p> <p><b>LOCK OUT POWER</b> before removing guards or performing maintenance.</p>
--	---

# Preventive Maintenance and Adjustment



- A – Tensioner Pulley Removal
- B – Idler Pulley Removal
- C – Drive Pulley Removal

## A – Tensioner Pulley Removal

1. Remove air supply and remove hose (AO of Figure 59) from center drive.




Figure 59

2. Remove screws (AS of Figure 60) and tensioning guards (AT) from both sides of center drive.




Figure 60

3. Temporarily support the tensioning roller guard (AV of figure 61). Remove screws (AU) on both sides of center drive and remove tensioning roller guard (AV of Figure 61 and 62).




Figure 61

4. Loosen tensioning roller set screws (AW of Figure 62) on one side of center drive.




Figure 62

5. Push shaft (AX of Figure 61) through block, slide block (AY of Figure 63) towards air cylinder (AZ).




Figure 63

6. Push shaft (AX of Figure 64) through block (AY) on opposite side of center drive, slide block toward air cylinder (AZ).

# Preventive Maintenance and Adjustment




Figure 64

7. Slide out tensioning pulley (BA of Figure 65).




Figure 65

8. Remove the tension pulley locking collar (CB of Figure 66), spacer (CC) and pulley shaft (CD) from the roller pulley shaft assembly.




Figure 66

## B – Idler Pulley Removal

1. Remove air supply and remove hose (AO of Figure 67) from center drive.




Figure 67

2. Temporarily support idler guard assembly (AP of Figure 68). Remove screws (AQ).




Figure 68

3. Swing down idler guard assembly (AP of Figure 69). Remove screw (AR) from both sides of center drive and remove idler guard assembly (AP).



Figure 69

# Preventive Maintenance and Adjustment

4. Remove screws (CE of Figure 70) and idler guide side plate (CF).




Figure 70

5. Slide the idler pulley assembly (CG of Figure 71) out of the idler guide side plate on the opposite side.




Figure 71

6. Remove the pulley shaft assembly: remove the clip ring (BR of Figure 72) and washer (BS) from one side of the pulley assembly.




Figure 72

7. Slide the shaft assembly (BT of Figure 73) out of the pulley (BQ).




Figure 73

## C – Drive Pulley Removal

	<div><b>WARNING</b></div> <p>Drive shaft keyway may be sharp. <b>HANDLE WITH CARE.</b></p>
--	---

1. Remove air supply and remove hose (AO of Figure 74) from center drive.





Figure 74

2. Remove screws (CH of Figure 74) and guard (CI).
3. Remove screws (CJ of Figure 75) and remove gearmotor (CK) (NOTE: Gearhead shown with motor removed for clarity, motor can remain attached to gearhead).

**NOTE: Gearhead shown with motor removed for clarity, motor can remain attached to gearhead.**




# Preventive Maintenance and Adjustment




**Figure 75**

4. Remove spacer ring (AK of Figure 76) and key (AG).




**Figure 76**

5. Reverse steps 3 thru 10 of the “Belt Removal for Conveyors Without Stands” section on page 10.
6. Loosen clamp screw (CL of Figure 77) and remove bearing collar (CM).




**Figure 77**

7. Disconnect flexible air hose (CN of Figure 78) from fitting (CO).



**Figure 78**

8. Temporarily support the drive pulley (CP of Figure 79).



**Figure 79**

9. Loosen clamp screw (CL of Figure 80) and remove bearing collar (CM).

# Preventive Maintenance and Adjustment




Figure 80

10. Remove screws (CQ) and pull side plate assembly (CR) off conveyor.




Figure 81

11. Slide drive pulley (CP of Figure 82) out of attached side plate.




Figure 82

## Bearing Replacement

	<div style="background-color: black; color: white; padding: 5px; text-align: center;"> <b>WARNING</b> </div> <p>Exposed moving parts can cause severe injury.  <b>LOCK OUT POWER</b> before removing guards or performing maintenance.</p>
--	--

	<div style="background-color: black; color: white; padding: 5px; text-align: center;"> <b>WARNING</b> </div> <p>Exposed moving parts can cause severe injury.  <b>REMOVE COMPRESSED AIR SUPPLY</b> before removing guards or performing maintenance.</p>
--	--

- A – Idler Bearing
- B – Drive Bearing
- C – Transfer Tail Bearing

### A – Idler Bearing Replacement

The bearings in a 3200 Series Idler Pulley can not be removed. Replace the entire pulley assembly when worn.

### B – Drive Bearing Removal and Replacement

	<div style="background-color: black; color: white; padding: 5px; text-align: center;"> <b>WARNING</b> </div> <p>Drive shaft keyway may be sharp.  <b>HANDLE WITH CARE.</b></p>
--	--

### Drive Side Bearing

1. Remove air supply (AO of Figure 83) from center drive module.

# Preventive Maintenance and Adjustment




Figure 83

2. Remove screws (CJ of Figure 84) and remove gearmotor (CK) (NOTE: Gearhead shown with motor removed for clarity, motor can remain attached to gearhead).




Figure 84

3. Remove spacer ring (AK of Figure 85) and key (AG). Loosen clamp screw (CL) and remove bearing collar (CM).




Figure 85

4. Remove the three (3) mounting screws (CS of Figure 86).




Figure 86

5. Remove and replace bearing housing assembly (AN of Figure 86).
6. Tighten three (3) mounting screws (CS of Figure 87) to 200 in-lbs (22.5 N-m).




Figure 87

7. Reinstall bearing collar (CM of Figure 85). Tighten clamp screw (CL) to 95 in-lbs (11 N-m).
8. Reinstall key (AG of Figure 85).
9. Reinstall spacer ring (AK of Figure 88) and gearmotor (CK). Tighten screws (CJ of Figure 84) to 150 in-lbs (17 N-m).




Figure 88

# Preventive Maintenance and Adjustment

## Idler Side Bearing

1. Remove air supply (AO of Figure 89) from center drive module.




Figure 89

2. Remove screws (CH of Figure 89) and cover (CI).
3. Loosen clamp screw (CL of Figure 90) and remove bearing collar (CM).




Figure 90

4. Remove the three (3) mounting screws (CS of Figure 91).




Figure 91

5. Remove and replace housing assembly (AN of Figure 91).
6. Tighten three (3) mounting screws (CS of Figure 91) to 200 in-lbs (22.5 N-m).
7. Reinstall bearing collar (CM of Figure 90). Tighten clamp screw (CL) to 95 in-lbs (11 N-m).
8. Reinstall cover (CI of Figure 89). Tighten screws (CH) to 69 in-lbs (8 N-m).

## C – Transfer Tail Bearing Replacement

The bearings in a 3200 Series Transfer Tail Pulley can not be removed. Replace the entire pulley assembly when worn.

## Pulley Replacement

### Idler Pulley

To replace the idler pulley, reverse the “Idler Pulley Removal” procedure on page 15.

### Drive Pulley

To replace the drive pulley, reverse the “Drive Pulley Removal” procedure on page 20.

### Transfer Tail Pulley

To replace the transfer tail pulley, reverse the “Transfer Tail Pulley Removal” procedure on page 16.






# Service Parts

NOTE: For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory.

## Center Drive Assembly




Item	Part Number	Description
1	200038	Cam Clamping Plate
2	See Table 1	Flat Guard <u>WW</u>
3	301088	Tail Clamping Bar
4	301098	Idler Stub Shaft
5	301214	Cylinder Channel Guard
6	301216	Cylinder Guard Mounting Block
7	301217	Torsion Arm Plate
8	301218	Side Plate Spacer
9	301219	Center Drive Side Plate
10	301220	End Roller Mounting Plate
11	301221	Horseshoe Guard Mount Plate
12	301222	Center Drive Tension Pulley Spacer
13	301278	Center Drive Bearing Guard
14	301281	Pipe Guard
15	301355	Cylinder Mounting Block
16	301356	Cylinder–Rod Mounting Block
17	301357	Tension Pulley Spacer
18	3242 <u>WW</u>	Tension Pulley Axle Shaft <u>WW</u>
19	3243 <u>WW</u>	Bottom End Guard <u>WW</u>
20	3244 <u>WW</u>	Bottom Corner Guard <u>WW</u>
21	3287 <u>WW</u>	6" Diameter Pulley <u>WW</u>
22	3290 <u>WW</u>	3" Center Drive Pulley
23	200039P	Belt Tracking Cam
24	200341M	Cam Retaining Block
25	See Table 1	Inner Shaft Tube
26	802–138	3 Bolt Bearing
27	807–226	Snap Out Plastic Plug
28	807–1162	Hex Stand Off
29	807–1167	Gearhead Cover
30	812–061	Anti–rotation Bushing
31	824–331	1/2" EMT Steel Connector
32	825–160	1/4" BSPT Pipe Plug
33	911020M	Button Head Screw M10 x 20mm
34	912–111	Square Key
35	915–265	E Retaining Ring
36	920512M	Socket Head Screw M5 x 12mm
37	920520M	Socket Head Screw M5 x 20mm
38	920610M	Socket Head Screw M6 x 10mm

39	920816M	Socket Head Screw M8 x 16mm
40	920860M	Socket Head Screw M8 x 60mm
41	920892M	Low Head Screw M8 x 12mm
42	970820M	Cup Set Screw M8 x 20mm
43	301213	Pneumatic Tension Assy
<u>WW</u> = Conveyor width reference: 04 – 60 in 02 increments		

Table 1 – Part Number Per Conveyor Width		
Conveyor Width	Item 2 – Flat Guard	Item 25 – Inner Shaft Tube
4"	300895–00374	301164
6"	300895–00599	301198–00209
8"	300895–00799	301198–00409
10	300895–00999	301198–00609
12	300895–01199	301198–00809
14	300895–01399	301198–01009
16	300895–01599	301198–01209
18	300895–01799	301198–01409
20	300895–01999	301198–01609
22	300895–02199	301198–01809
24	300895–02399	301198–02009
26	300895–02599	301198–02209
28	300895–02799	301198–02409
30	300895–02999	301198–02609
32	300895–03199	301198–02809
34	300895–03399	301198–03009
36	300895–03599	301198–03209
38	300895–03799	301198–03409
40	300895–03999	301198–03609
42	300895–04199	301198–03809
44	300895–04399	301198–04009
46	300895–04599	301198–04209
48	300895–04799	301198–04409
50	300895–04999	301198–04609
52	300895–05199	301198–04809
54	300895–05399	301198–05009
56	300895–05599	301198–05209
58	300895–05799	301198–05409
60	300895–05999	301198–05609

# Service Parts

## 3200 Center Drive 90° Industrial Gearmotors



**Figure 92**

Item	Part No.	Part Description
1	820-314	Gear Reducer, 7.5:1 NEMA 140TC
	820-315	Gear Reducer, 10:1 NEMA 140TC
	820-316	Gear Reducer, 15:1 NEMA 140TC
	820-317	Gear Reducer, 20:1 NEMA 140TC
	820-318	Gear Reducer, 25:1 NEMA 140TC
	820-319	Gear Reducer, 30:1 NEMA 140TC
	820-320	Gear Reducer, 40:1 NEMA 140TC
	820-321	Gear Reducer, 50:1 NEMA 140TC
	820-322	Gear Reducer, 60:1 NEMA 56C
	820-323	Gear Reducer, 80:1 NEMA 56C
	820-324	Gear Reducer, 100:1 NEMA 56C
2	826-328	Motor, 0.25hp (0.19Kw), 115/230 Volts, 60 Hz, 1-Phase
	826-017	Motor, 0.5hp (0.37Kw), 115/230 Volts, 60Hz, 1-Phase
	826-025	Motor, 0.5hp (0.37Kw) 208-230/460 Volts, 60Hz, 3 Phase
	826-173	Motor, 1 hp (0.75Kw), 230 Volts, 3 Phase
	826-249	Motor, 0.5hp (0.37Kw), 230 Volts, 3 Phase Inverter Duty
	826-259	Motor, 1hp (0.75Kw), 230 Volts, 3 Phase Inverter Duty
	826-271	Motor, 1.5hp (1.1Kw), 230 Volts, 3 Phase Inverter Duty
	826-279	Motor, 1.5hp (1.1Kw), 230 Volts, 3 Phase
	826-333	Motor, 0.5hp (0.37Kw), 90 Volts DC,
	826-391	Motor, 2.0hp (1.5Kw), 230 Volts, 3 Phase Inverter Duty
	826-393	Motor, 2.0hp (1.5Kw), 230 Volts, 3 Phase
	826-394	Motor, 1.0hp (0.75Kw), 115 Volts, Integrated Controller
	826-395	Motor, 0.5hp (0.37Kw), 115 Volts, Integrated Controller
3	820-329	Bushing Shaft Adapter, 56C to 140TC

Conveyor Belt Part Number Configuration





Figure 93


Flat Belt Part Number Configuration

Refer to Dorner patent plate (Figure 93). From the model number, determine conveyor tracking ("T"), drive/tail type ("D"), width ("WW"), length ("LLLL") and belt type ("BB"). Use data to configure belt part number as indicated below.



# Service Parts

## Transfer Tail Assembly




Item	Part Number	Description
1	301082	Nosebar Cover Plate
2	301084	1" Inner Tail Plate
3	301088	Tail Bar Clamp
4	301090	Transfer Tail Support Plate
5	301196	Hex Tension Tracking Shaft
6	301352	Nut, E-ring, Brace
7	301354	Inner Transfer Tail Support Plate
8	3202WW	Tail Articulation Bar
9	3217WW	1" Idler Tail Axle Shaft
10	3219WW	Roller Assy Support Bar

11	3237WW	Transfer Tail Roller
12	807-1125	Groove Pin
13	807-1136	Washer
14	807-1151	Retaining Ring
15	807-1152	Hex Head Cap Screw M6 x 20mm
16	910-203	3/8" Hex Nut
17	915-319	Retaining Ring
18	920408M	Hex Head Cap Screw M4 x 8mm
19	920893M	Low Head Socket Screw M8 x 16mm

WW = Conveyor width reference: 04 – 48 in 02 increments

## Idler End Assembly




Item	Part Number	Description
1	301049	Idler Cover Plate
2	301083	Inner 3" Tail Plate
3	301088	Tail Bar Clamp
4	301353	Idler Tail Stub Shaft
5	301196	Hex Tension Tracking Shaft
6	3202WW	Tail Articulation Bar
7	3284WW	3" Idler Pulley

8	605280P	Hard Washer
9	807-1125	Groove Pin
10	807-1151	Tracking Shaft Retaining Ring
11	807-1152	Hex Head Cap Screw M6 x 20mm
12	915-235	Stub Shaft Retaining Ring
13	920893M	Low Head Socket Screw M8 x 16mm
WW = Conveyor width reference: 04 – 48 in 02 increments		

# Service Parts

## Frame Assembly



Item	Part Number	Description
1	240420	Rack Gear
2	301091	Pinion Bearing
3	807-1136	Washer
4	920482M	Flange Socket Screw M4 x 12mm
5	920616M	Socket Head Screw M6 x 16mm
6	920693M	Low Head Socket Screw M6 x 16mm
7	3245WW	Cross Support Rail
8	301041-LLLLL	RH Side Rail
9	301042-LLLLL	LH Side Rail
10	3229WW	Pinion
11		Bed Plate Rail
WW = Conveyor width reference: 04 – 48 in 02 increments LLLLL = Frame Length (see Bed Plate & Frame Formulas)		

Item 11: Bed Plate Rail	
Width	Part Number
1.75" (mm)	300887-LLLLL
2" (54mm)	300888-LLLLL
4" (102mm)	300889-LLLLL
6" (152mm)	300890-LLLLL
LLLLL = Bed Plate Length (see Bed Plate & Frame Formulas)	

### Bed Plate and Frame Formulas


Bed Plate LLLLL = Frame LLLLL – 00013  
Frame LLLLL =  $\frac{\text{Conveyor Length LLLL X 12} - \text{Tail Adder}}{\text{\# of Sections of Conveyor}}$   
Tail Adder = 00600 for each Tension End  
00425 for each Non-Tension End



Width	Bed Plate Configuration												
4"							1.75"						
6"							4"						
8"							6"						
10"						2"	4"	2"					
12"						2"	6"	2"					
14"						4"	4"	4"					
16"						4"	6"	4"					
18"						6"	4"	6"					
20"						6"	6"	6"					
22"					4"	4"	4"	4"	4"				
24"					4"	4"	6"	4"	4"				
26"					6"	4"	4"	4"	6"				
28"					6"	4"	6"	4"	6"				
30"					6"	6"	4"	6"	6"				
32"					6"	6"	6"	6"	6"				
34"				4"	4"	6"	4"	6"	4"	4"			
36"				4"	4"	6"	6"	6"	4"	4"			
38"				4"	6"	6"	4"	6"	6"	4"			
40"				4"	6"	6"	6"	6"	6"	4"			
42"				6"	6"	6"	4"	6"	6"	6"			
44"				6"	6"	6"	6"	6"	6"	6"			
46"			4"	4"	6"	6"	4"	6"	6"	4"	4"		
48"			4"	4"	6"	6"	6"	6"	6"	4"	4"		
50"			4"	6"	6"	6"	4"	6"	6"	6"	4"		
52"			4"	6"	6"	6"	6"	6"	6"	6"	4"		
54"			6"	6"	6"	6"	4"	6"	6"	6"	6"		
56"			6"	6"	6"	6"	6"	6"	6"	6"	6"		
58"		4"	4"	6"	6"	6"	4"	6"	6"	6"	4"	4"	
60"		4"	4"	6"	6"	6"	6"	6"	6"	6"	4"	4"	
62"		4"	6"	6"	6"	6"	4"	6"	6"	6"	6"	4"	
64"		4"	6"	6"	6"	6"	6"	6"	6"	6"	6"	4"	
66"		6"	6"	6"	6"	6"	4"	6"	6"	6"	6"	6"	
68"		6"	6"	6"	6"	6"	6"	6"	6"	6"	6"	6"	
70"	4"	4"	6"	6"	6"	6"	4"	6"	6"	6"	6"	4"	4"
72"	4"	4"	6"	6"	6"	6"	6"	6"	6"	6"	6"	4"	4"

# Service Parts

## -04 3" (76mm) Aluminum Side



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	380400-LLLLL (see Formulas)	3200 Guide 3" (76mm) HS
3	200695P	Single Drop-in Tee Bar
4	920694M	Socket Head Screw M6 x 20mm

### Length Formulas

$$LLLLL = \frac{(\text{Conveyor Length } XXXX) \times 12 - \text{Tail Factor}}{\text{\# of Sections of Conveyor}}$$

**Tail Factor =**

00000	for center drive with transfer tail both ends
00100	for end drive with one transfer tail
00200	for end drive and center drives with standard tails
00325	for All Cleated Conveyors

$$\text{\# of Conveyor Sections} = \frac{(\text{Conveyor Length } XXXX - 0100)}{1200}$$

XXXX = Conveyor Length (XX.XX ft)

### Example

17'4" End Drive Conveyor with Standard Tails


Conveyor Length = 1733

Tail Factor = 00200

$$\text{\# of Sections (round up)} = \frac{(1733 - 0100)}{1200} = 1.36 = 2 \text{ Sections}$$

$$LLLLL = \frac{(1733 \times 12) - 00200}{2} = 10298$$

-05 1.5" (38mm) Aluminum Side



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	380500-LLLLL (see Formulas)	3200 Guide .5" (13mm) HS
3	639971M	Single Drop-in Tee Bar
4	920694M	Socket Head Screw M6 x 20mm

Length Formulas

$$LLLLL = \frac{(\text{Conveyor Length } XXXX) \times 12 - \text{Tail Factor}}{\text{\# of Sections of Conveyor}}$$

Tail Factor =   00000   for center drive with transfer tail both ends  
                  00100   for end drive with one transfer tail  
                  00200   for end drive and center drives with standard tails  
                  00325   for All Cleated Conveyors

$$\text{\# of Conveyor Sections} = \frac{(\text{Conveyor Length } XXXX - 0100)}{1200}$$

XXXX = Conveyor Length (XX.XX ft)

Example

17'4" End Drive Conveyor with Standard Tails

Conveyor Length = 1733


Tail Factor = 00200

$$\text{\# of Sections (round up)} = \frac{(1733 - 0100)}{1200} = 1.36 = 2 \text{ Sections}$$

$$LLLLL = \frac{(1733 \times 12) - 00200}{2} = 10298$$

# Service Parts

## -07 Low to Side Wiper



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	380900-LLLLL (see Formulas)	3200 Guide .5" (13mm) HS
3	41-00-24	Side Wiper Nylatron (per foot)
4	639971M	Single Drop-in Tee Bar
5	920694M	Socket Head Screw M6 x 20mm

### Length Formulas

$$LLLLL = \frac{(\text{Conveyor Length } XXXX) \times 12 - \text{Tail Factor}}{\text{\# of Sections of Conveyor}}$$

Tail Factor =   00000   for center drive with transfer tail both ends  
                  00100   for end drive with one transfer tail  
                  00200   for end drive and center drives with standard tails  
                  00325   for All Cleated Conveyors

$$\text{\# of Conveyor Sections} = \frac{(\text{Conveyor Length } XXXX - 0100)}{1200}$$

XXXX = Conveyor Length (XX.XX ft)

#### Example

17'4" End Drive Conveyor with Standard Tails


Conveyor Length = 1733

Tail Factor = 00200

$$\text{\# of Sections (round up)} = \frac{(1733 - 0100)}{1200} = 1.36 = 2 \text{ Sections}$$

$$LLLLL = \frac{(1733 \times 12) - 00200}{2} = 10298$$

-09 Low to High Side



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	380900-LLLLL (see Formulas)	2200 Guide .5" (13mm) HS
3	639971M	Single Drop-in Tee Bar
4	920694M	Socket Head Screw M6 x 20mm

Length Formulas

$$LLLLL = \frac{(\text{Conveyor Length } XXXX) \times 12 - \text{Tail Factor}}{\text{\# of Sections of Conveyor}}$$
  
Tail Factor = 00000 for center drive with transfer tail both ends  
00100 for end drive with one transfer tail  
00200 for end drive and center drives with standard tails  
00325 for All Cleated Conveyors

$$\text{\# of Conveyor Sections} = \frac{(\text{Conveyor Length } XXXX - 0100)}{1200}$$

XXXX = Conveyor Length (XX.XX ft)

Example

17'4" End Drive Conveyor with Standard Tails

Conveyor Length = 1733


Tail Factor = 00200

$$\text{\# of Sections (round up)} = \frac{(1733 - 0100)}{1200} = 1.36 = 2 \text{ Sections}$$

$$LLLLL = \frac{(1733 \times 12) - 00200}{2} = 10298$$

# Service Parts

## -10 .5" (13mm) Extruded Plastic



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	200054P	Snap-On Guide (per foot)
3	3810000-LLLLL (see Formulas)	2200 Guide
4	639971M	Single Drop-in Tee Bar
5	920694M	Socket Head Screw M6 x 20mm

### Length Formulas

$$\text{LLLLL} = \frac{(\text{Conveyor Length XXXX}) \times 12 - \text{Tail Factor}}{\text{\# of Sections of Conveyor}}$$

Tail Factor =	00000	for center drive with transfer tail both ends
	00100	for end drive with one transfer tail
	00200	for end drive and center drives with standard tails
	00325	for All Cleated Conveyors

$$\text{\# of Conveyor Sections} = \frac{(\text{Conveyor Length XXXX} - 0100)}{1200}$$

XXXX = Conveyor Length (XX.XX ft)

#### Example

17'4" End Drive Conveyor with Standard Tails


Conveyor Length = 1733

Tail Factor = 00200

$$\text{\# of Sections (round up)} = \frac{(1733 - 0100)}{1200} = 1.36 = 2 \text{ Sections}$$

$$\text{LLLLL} = \frac{(1733 \times 12) - 00200}{2} = 10298$$

## -13 Adjustable Guiding




Item	Part Number	Description
1	202983	Aluminum Profile Guide 2' (610mm)
	202984	Aluminum Profile Guide 3' (914mm)
	202985	Aluminum Profile Guide 4' (1219mm)
	202986	Aluminum Profile Guide 5' (1524mm)
	202987	Aluminum Profile Guide 6' (1829mm)
	202988	Aluminum Profile Guide 7' (2134mm)
	202989	Aluminum Profile Guide 8' (2438mm)
	202990	Aluminum Profile Guide 9' (2743mm)
	202991	Aluminum Profile Guide 10' (3048mm)
	202992	Aluminum Profile Guide 11' (3353mm)
	202993	Aluminum Profile Guide 12' (3658mm)
	202994	Aluminum Profile Guide 13' (3962mm)

2	200830M	Drop-In Tee Bar
3	202004	Mounting Bracket
4	202027M	Guide Mounting Shaft Vertical
5	202028M	Guide Mounting Shaft Horizontal
6	674175MP	Square Nut
7	807-652	Cross Block
8	807-948	Vinyl Shaft Cap
9	614068P	Flat Extruded Guide (per foot)
10	920612M	Socket Head Screw M6 x 12mm
11	920616M	Socket Head Screw M6 x 16mm

# Service Parts

## Flared Side Guiding




Item	Part Number	Description
1	200121	Guide Retaining Clip
2	202212	Side-Flare Mounting Guide 2' (610mm)
	202213	Side-Flare Mounting Guide 3' (914mm)
	202214	Side-Flare Mounting Guide 4' (1219mm)
	202215	Side-Flare Mounting Guide 5' (1524mm)
	202216	Side-Flare Mounting Guide 6' (1829mm)

3	202522M	Flared Guide 45° 2' (610mm)
	202523M	Flared Guide 45° 3' (914mm)
	202524M	Flared Guide 45° 4' (1219mm)
	202525M	Flared Guide 45° 5' (1524mm)
	202526M	Flared Guide 45° 6' (1829mm)
4	639971	Drop-In Tee Bar
5	910506M	Button Head Screw M5 x 6mm
6	911-512	Washer
7	920694M	Cap Low-Head Screw M6 x 20mm




Flat Belt Mounting Brackets



Item	Part Number	Description
1	240831	Stand Mount
2	300150M	Drop-In Tee Bar
3	605279P	Washer

4	807-920	Square Nut M6 5mm x 10mm
5	920620M	Socket Head Screw M6 x 20mm
6	920692M	Socket Head Screw M6 x 12mm

Connecting Assembly without Stand Mount




Item	Part Number	Description
1	240858	Frame Bar Connector

2	240859	Intermediate Clamp Plate
3	920692M	Socket Head Screw M6 x 12mm

# Service Parts


## Flat Belt Connecting Assembly with Stand Mount



Item	Part Number	Description
1	240858	Frame Connector Bar
2	240837	Stand Mount Joint
3	605279P	Washer

4	807-920	Square Nut M6 5mm x 10mm
5	920620M	Socket Head Screw M6 x 20mm
6	920692M	Socket Head Screw M6 x 12mm


## 4" (102mm) to 6" (152mm) Flat Belt Return Roller



Item	Part Number	Description
1	240825	Short Return Roller Guard
2	240827	Return Roller Clip

3	802-123	Bearing
4	913-100	Dowel Pin
5	920693M	Socket Head Screw M6 x 16mm

8” (203mm) to 48” (1219mm) Flat Belt Return Roller



Item	Part Number	Description
1	240826	Return Roller
2	240827	Return Roller Clip
3	2409 <del>WW</del>	Return Roller Guard

4	2410 <del>WW</del>	Return Roller Rod
5	920693M	Socket Head Screw M6 x 16mm
<del>WW</del> = Conveyor width reference: 08 – 48 in 02 increments		

---

## Return Policy

---

No returns will be accepted without prior written factory authorization. When calling for authorization, please have the following information ready for the Dorner Factory representative or your local distributor:

1. Name and address of customer.
2. Item(s) being returned.
3. Reason for return.
4. Customer's original order number used when ordering the item(s).
5. Dorner or distributor invoice number.

A representative will discuss action to be taken on the Returned items and provide a Returned Goods Authorization Number to reference.

There will be a 15% restocking charge on all new items returned for credit where Dorner was not at fault. These will not be accepted after 60 days from original invoice date. The restocking charge covers inspection, cleaning, disassembly, and reissuing to inventory.

If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Feel free to contact Dorner for the name of your local representative. Our technical sales and service staff will gladly help with your questions on Dorner products.

For a copy of Dorner's Limited Warranty, contact factory, distributor, service center or visit our website at [www.dorner.com](http://www.dorner.com).

**For replacement parts, contact an authorized  
Dorner Service Center or the factory.**

**DORNER<sup>®</sup>**

Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. ©Dorner Mfg. Corp. 2000

**DORNER MFG. CORP.**

975 Cottonwood Ave., PO Box 20  
Hartland, WI 53029-0020 USA

**USA**  
**TEL 1-800-397-8664 (USA)**  
**FAX 1-800-369-2440 (USA)**  
**Internet: [www.dorner.com](http://www.dorner.com)**

**Outside the USA:**  
**TEL 1-262-367-7600**  
**FAX 1-262-367-5827**