




3200 Series Flat Belt Center Drive LPZ Conveyors

Installation, Maintenance & Parts Manual



DORNER MFG. CORP.
P.O. Box 20 • 975 Cottonwood Ave.
Hartland, WI 53029-0020 USA

INSIDE THE USA
TEL: 1-800-397-8664
FAX: 1-800-369-2440

OUTSIDE THE USA
TEL: 262-367-7600
FAX: 262-367-5827

For other service manuals visit our website at:
www.dorner.com/service_manuals.asp

Table of Contents

Introduction	3	Pulley Replacement.....	32
Warnings - General Safety	4	Idler Pulley.....	32
Product Description	5	Drive Pulley	32
Specifications	5	Transfer Tail Pulley	32
Installation	8	Knuckle Pulley.....	32
Required Tools.....	8	Knuckle Return Roller	32
Recommended Installation Sequence	8	Notes	33
Conveyors Up to 13 ft (3962 mm).....	8	Service Parts.....	34
Conveyors Longer Than 13 ft (3962 mm)	8	Center Drive Assembly	34
Mounting Brackets.....	9	Center Drive Manual Tensioner	36
Return Rollers	10	3200 Center Drive 90° Industrial Gearmotors.....	36
4–6" (102–152 mm) Wide Flat Belt Conveyors.....	10	Transfer Tail Assembly	37
8–48" (203–1219 mm) Wide Flat Belt Conveyors.....	10	Idler End Tail Assembly.....	38
Gearmotor Installation	11	Knuckle Assembly	39
Required Tools	11	Frame Assembly.....	40
Mounting	11	Bed Plate and Frame Formulas	41
Preventive Maintenance and Adjustment	13	Conveyor Configurations	42
Required Tools.....	13	Guiding Options (TT).....	42
Standard Tools.....	13	Section and Length Determination.....	42
Checklist	13	Walk Through Frame – Section L1.....	43
Lubrication	13	Walk Through Frame – Section L2.....	44
Maintaining Conveyor Belt	13	Walk Through Frame – Section L3.....	45
Troubleshooting	13	Nose Over Frame – Section L2.....	46
Cleaning	13	Nose Over Frame – Section L3.....	47
Conveyor Belt Replacement	13	–13 Adjustable Guiding	48
Conveyor Belt Replacement Sequence	13	–14 Tool-Less Adjustable Guiding	49
Belt Removal for Conveyor Without Stands.....	14	Flat Belt Mounting Brackets	50
Belt Removal for Conveyor With Stands.....	16	Connecting Assembly without Stand Mount.....	50
Belt Installation for Conveyor without Stands.....	16	Flat Belt Connecting Assembly with Stand Mount.....	51
Belt Installation for Conveyor with Stands	17	4" (102 mm) to 6" (152 mm) Flat Belt Return Roller....	51
Conveyor Belt Tensioning	17	8" (203 mm) to 48" (1219 mm) Flat Belt Return Roller	52
A - With Pneumatic Tensioning.....	18	Conveyor Belt Part Number Configuration.....	52
B - With Manual Tensioning.....	18	Flat Belt Part Number Configuration	52
Conveyor Belt Tracking.....	19	Notes	53
V-Guided Belts.....	19	Return Policy.....	54
Non V-Guided Belts.....	19		
Center Drive Module Tracking.....	19		
V-Guided Belts.....	19		
Non V-Guided Belts.....	19		
Conveyor Angle Adjustment	20		
End and Knuckle Pulley Removal	21		
A – Idler Pulley Removal.....	22		
B – Transfer Tail Pulley Removal	23		
C – Knuckle Idler Pulley Removal	24		
D – Knuckle Return Roller Removal	25		
Center Drive Pulleys Removal	25		
A – Tensioner Pulley Removal	26		
B – Idler Pulley Removal.....	27		
C – Drive Pulley Removal	28		
Bearing Replacement.....	30		
A – Idler Bearing Replacement.....	30		
B – Drive Bearing Removal and Replacement	30		
C – Transfer Tail Bearing Replacement	32		
D – Knuckle Idler Bearing Replacement	32		
E – Knuckle Return Roller Bearing Replacement	32		

IMPORTANT

Some illustrations may show guards removed. DO NOT operate equipment without guards.


Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage.
- Accessories may be shipped loose. See accessory instructions for installation.

Dorner's Limited Warranty applies.

Dorner 3200 series conveyors are covered by Patent Numbers 5,156,260, 6,871,737B2, 6,910,571B1, 6,971,509B2, and corresponding patents and patent applications in other countries.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits  logo.

Warnings - General Safety

⚠ WARNING

The safety alert symbol, black triangle with white exclamation, is used to alert you to potential personal injury hazards.

⚠ DANGER



Climbing, sitting, walking or riding on conveyor will cause severe injury.
KEEP OFF CONVEYORS.

⚠ DANGER



DO NOT OPERATE CONVEYORS IN AN EXPLOSIVE ENVIRONMENT.

⚠ WARNING



LPZ Series Conveyors are not reversible. Reversing creates pinch points which can cause severe injury.
DO NOT REVERSE LPZ SERIES CONVEYORS.

⚠ WARNING



Gearmotors may be **HOT**.
DO NOT TOUCH Gearmotors.

⚠ WARNING



Exposed moving parts can cause severe injury.
LOCK OUT POWER before removing guards or performing maintenance.

⚠ WARNING



Dorner cannot control the physical installation and application of conveyors. Taking protective measures is the responsibility of the user.
When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, **CHECK FOR POTENTIAL PINCH POINTS** and other mechanical hazards before system start-up.

⚠ WARNING



Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing severe injury.
When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, **CHECK FOR POTENTIAL PINCH POINTS** and other mechanical hazards before system start-up.
SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.

Product Description

Refer to Figure 1 for typical conveyor components.

A	Conveyor
B	Center Drive Module
C	Gearmotor
D	Guiding & Accessories
E	Mounting Brackets
F	Knuckle
G	Support Stand
H	Idler/Tension End




Figure 1

Specifications

Models

Flat Belt LPZ Series Center Drive Conveyor

3 E 1 5 M WW LLLL-LLLL-LLLL A PP BB

- 3 — Conveyor Section Length Reference
- E — Elevating
- 1 — Manual tracking and supports
- 5 — V-guide tracking and supports
- M — Document Language, M = English
- WW — Conveyor Width Reference
- LLLL-LLLL-LLLL — Conveyor Section Length Reference
- A — Conveyor Section Length Reference
- PP — Output Shaft Position*
- BB — Belt Type*

Idler Pulley Type: Pneumatic Tensioning

- 5 = 3" idler pulleys at both ends
- 6 = Two 1" pulleys at infeed
- 7 = Two 1" pulleys at discharge
- 8 = Two 1" pulleys at both ends

Idler Pulley Type: Manual Tensioning

- 2 = 3" idler pulley at both ends
- 3 = Two 1" pulleys at infeed
- 4 = Two 1" pulleys at discharge
- 9 = Two 1" pulleys at both ends

Tracking and Supports

- 1 = Manual tracking and supports
- 2 = V-guide tracking and supports
- 3 = Manual tracking
- 4 = V-guide tracking

Other Labels:

- E = Elevating
- D = Declining

* See Ordering and Specifications Catalog for details

Conveyor Supports:

Maximum Distances:

I = 24" (610 mm) (Drive End)

J = 12 ft (3658 mm)

K = 36" (914 mm) (Idler End)

Maximum Angle:

L = 0 to 35 degrees






Figure 2

Specifications

Specifications



Conveyor Width Reference (WW)	04	06	08	10	12	18	24	30	36	48	
Conveyor Belt Width	3.75" (95m m)	6" (152 mm)	8" (203 mm)	10" (254 mm)	12" (305 mm)	18" (457 mm)	24" (609 mm)	30" (762 mm)	36" (915 mm)	48" (1220 mm)	
Conveyor Length Reference (LLLL)	0300 to 9900 in 0001 increments										
Conveyor Length	4 ft (1219mm) to 99 ft (30175mm) in 0.12" (0.31mm) increments										
Belt Travel	18.8" (478 mm) per revolution of pulley										
Maximum Belt Speed*	600 ft/minute (183 m/minute)										
Belt Takeup	16" (407 mm) of Belt Takeup										

* See Ordering and Specifications Catalog for details.

NOTE
<p><i>Maximum conveyor loads based on:</i></p> <ul style="list-style-type: none"> • Non-accumulating product • Product moving towards gearmotor • Conveyor being mounted horizontal

Table 1: Belt Speeds for Variable Speed 90° VDC Gearmotors

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHD9DEN	25	630	71	4.0–40.0	1.2–12.2
32M080HHD9DEN	31	575	65	5.0–50.0	1.5–15.2
32M060HHD9DEN	42	469	53	6.7–66.7	2.0–20.3

(vp) = voltage and phase

11 = 115 V, 1-phase

23 = 208 – 230/460 V, 3-phase

Table 2: Belt Speeds for Fixed Speed 90 Gearmotors

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHvpfN	17	913	103	27.6	8.4
32M080HHvpfN	22	833	94	34.5	10.5
32M060HHvpfN	29	680	77	46.0	14.0
32M050HHvpfN	35	1206	136	55.2	16.8
32M040HHvpfN	43	1023	116	69.0	21.0
32M030HHvpfN	58	1217	138	92.0	28.0
32M025HHvpfN	69	1069	121	110.4	33.7
32M020HHvpfN	86	1184	134	138.0	42.1
32M015HHvpfN	115	910	103	184.0	56.1
32M010HHvpfN	173	636	72	276.0	84.1
32M008HHvpfN	230	482	54	368.0	112.2

Table 3: Belt Speeds for Variable Speed 90° VFD Gearmotors

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HHvpfN	17	913	103	2.8–27.6	0.8–8.4
32M080HHvpfN	22	833	94	3.5–34.5	1.1–10.5
32M060HHvpfN	29	680	77	4.6–46.0	1.4–14.0
32M050HHvpfN	35	1206	136	5.5–55.2	1.7–16.8
32M040HHvpfN	43	1023	116	6.9–69.0	2.1–21.0
32M030HHvpfN	58	1217	138	9.2–92.0	2.8–28.0
32M025HHvpfN	69	1069	121	11.0–110.4	3.4–33.7
32M020HHvpfN	86	1184	134	13.8–138.0	4.2–42.1
32M015HHvpfN	115	910	103	18.4–184.0	5.6–56.1
32M010HHvpfN	173	636	72	27.6–276.0	8.4–84.1
32M008HHvpfN	230	482	54	36.8–368.0	11.2–112.2

Table 4: Belt Speeds for Variable Speed 90 VFD Integrated Motor Control Gearmotors

Standard Load Gearmotors				Belt Speed	
Part Number	RPM	In-lb	N-m	Ft/min	M/min
32M100HH411EC	17	913	103	4.6–36.7	1.4–11.2
32M060HH411EC	29	680	77	7.7–61.2	2.3–18.7
32M040HH411EC	43	1023	116	11.5–91.8	3.5–28.0
32M015HH411EC	69	712	80	18.4–146.8	5.6–44.8
32M020HH411EC	86	592	67	23.0–183.5	7.0–56.0
32M015HH411EC	115	455	51	30.7–244.7	9.4–74.6

(vp) = voltage and phase

11 = 115 V, 1-phase

23 = 208 – 230/460 V, 3-phase

NOTE

For belt speed other than those listed, contact factory for details.

Installation

⚠ DANGER



LPZ Series Conveyors are not reversible. Reversing creates pinch points which can cause severe injury.

DO NOT REVERSE LPZ SERIES CONVEYORS.

NOTE

Conveyor *MUST* be mounted straight, flat and level within confines of conveyor. Use a level (M of Figure 3) for setup.




Figure 3

Required Tools

- Hex-key wrenches: 4 mm, 5 mm
- Level
- Torque wrench
- 8mm hex, open end wrench

Recommended Installation Sequence

- Install support stands (see accessory instructions)
- Assemble conveyor (if required)
- Attach mounting brackets to conveyor (see page 9 for instructions)
- Adjust angle (see page 20 for instructions)
- Attach conveyor to stands
- Install return rollers on conveyor (see page 10 for instructions)
- Mount gearmotor mounting package (see page 11 for instructions)
- Attach guides/accessories (see page 42 through page 48 of “Service Parts” section for details)

Conveyors Up to 13 ft (3962 mm)

No assembly is required. Install mounting brackets and return rollers. Refer to “Mounting Brackets” on page 9 and “Return Rollers” on page 10.

Conveyors Longer Than 13 ft (3962 mm)

N	Conveyor frame
O	Section Label

1. Locate and arrange conveyor sections by section labels (Figure 4, item O).




Figure 4

2. On tension end of the conveyor, identified by the pinion locking screw (Figure 5, item S), push in head plate assembly (U): Loosen the pinion locking screw (S), adjust the pinion torque screw (Figure 6, item V). On both sides of conveyor, loosen the two tail clamp bolts (Figure 5, item T), and push head plate assembly (U) inward.




Figure 5




Figure 6

3. Roll out conveyor belt (Figure 7, item P). Loosen (4) screws (W) on both sides of knuckle (Q). Slide frame (O) into knuckle (Q). Tighten screws (W) to 60 in-lb (7 N-m) on both sides of conveyor.




Figure 7

4. Join additional conveyor sections if necessary and install connector brackets (Figure 8, item X) or connector/mount brackets (XA) and screws (Y) on both sides as indicated. Tighten screws to 60 in-lb (7 Nm).




Figure 8

5. Slide belt (Figure 9, item P) over assembled conveyor sections (Z).




Figure 9

6. Tension conveyor belt, refer to “Conveyor Belt Tensioning” on page 17.
7. Install mounting brackets and return rollers. Refer to “Mounting Brackets” on page 9 and “Return Roller” on page 10.
8. Adjust conveyor angle. See “Conveyor Angle Adjustment” on page 20.

Mounting Brackets

1. Locate brackets. Exploded views shown in Figure 10.




Figure 10

2. Remove screws (Figure 10, item AA & AB), washers (AC), nuts (AD) and T-bars (AE) from brackets.
3. Insert T-bars (Figure 10, item AE) into conveyor side slots (Figure 11, item AE). Fasten brackets (Figure 11, item AF) to conveyor with mounting screws (AA).

Installation




Figure 11

4. Fasten brackets to support stand with mounting screws (Figure 11, item AB), washers (AC) and nuts (AD).
5. Tighten screws (Figure 11, item AA & AB) to 60 in-lb (7 Nm).

Return Rollers

4–6" (102–152 mm) Wide Flat Belt Conveyors

1. Locate return rollers. Exploded view shown in Figure 12.




Figure 12

2. Remove screws (Figure 12, item AG) and clips (AH) from roller assembly.

3. Install roller assemblies (Figure 13, item AI) as shown. Tighten screws (AG) to 60 in-lb (7 Nm).




Figure 13

8–48" (203–1219 mm) Wide Flat Belt Conveyors

1. Locate return rollers. Exploded view shown in Figure 14.




Figure 14

2. Remove screws (Figure 14, item AJ) and clips (AK) from roller assembly.
3. Install roller assembly as shown (Figure 15, item AL). Tighten screws (AJ) to 60 in-lb (7 Nm).




Figure 15


Gearmotor Installation

Required Tools

- Hex key wrenches:
2 mm, 2.5 mm, 3 mm, 5 mm
- Torque wrench

Mounting

⚠ WARNING



Exposed moving parts can cause severe injury.
LOCK OUT POWER before removing guards or performing maintenance.

1. Locate components in Figure 16.




Figure 16

Gearmotor Installation Component List	
AM	Gearhead with mounting bracket
AN	Motor
AO	Gear Reducer Key
AP	Cover
AQ	Cover Bolts
AR	Motor Mount Bolts
AS	Spacer Ring

NOTE

Gearmotor may be operated in positions 1, 3 or 4 (Figure 17).




Figure 17

2. If required, change gearmotor position by removing four (4) screws (Figure 18, item AT). Rotate gearmotor mounting plate to other position and replace screws (AT). Tighten to 200 in-lb (22.5 Nm).




Figure 18

Installation

⚠ DANGER



**Drive shaft keyway may be sharp.
HANDLE WITH CARE.**

3. Install key (Figure 19, item AO) on drive shaft (AU). Install cover (AP) over bearing housing (AV)




Figure 19

4. Install cover (Figure 20, item AP) with four (4) screws (AQ).




Figure 20

5. Slide gearmotor (Figure 21, item AM) on to drive shaft (Figure 19, item AU). Tighten mounting screws (AR) to 200 in-lbs (22.5 N-m).




Figure 21

Preventive Maintenance and Adjustment

Required Tools

Standard Tools

- Hex key wrenches:
2.5 mm, 4 mm, 5 mm
- 8mm hex, open end wrench

Checklist

- Keep service parts on hand (see “Service Parts” section for recommendations)
- Keep supply of belt cleaner
- Clean entire conveyor and knurled pulley while disassembled
- Replace worn or damaged parts

Lubrication

No lubrication is required. Replace bearings if worn.

Maintaining Conveyor Belt

Troubleshooting

Inspect conveyor belt for:

- Surface cuts or wear
- Stalling or slipping
- Damage to V-guide

Surface cuts and wear indicate:

- Sharp or heavy parts impacting belt
- Jammed parts
- Improperly installed bottom wipers (if installed)
- Accumulated dirt in wipers (if installed)
- Foreign material inside the conveyor
- Improperly positioned accessories
- Bolt-on guiding is pinching belt

Stalling or slipping indicates:

- Excessive load on belt
- Conveyor belt or drive timing belt are not properly tensioned
- Worn knurl or impacted dirt on drive pulley
- Intermittent jamming or drive train problems

Damage to V-guide indicates:


- Twisted or damaged conveyor frame
- Dirt impacted on pulleys
- Excessive or improper side loading

Cleaning

Use Dorner Belt Cleaner. Mild soap and water may also be used. Do not soak the belt.

For /05 woven polyester and /06 black anti-static belts, use a bristled brush to improve cleaning.

Conveyor Belt Replacement

⚠ WARNING

Exposed moving parts can cause severe injury. LOCK OUT POWER before removing guards or performing maintenance.

Conveyor Belt Replacement Sequence

- Release Tension
- Remove old conveyor belt:
 - Conveyor without Stands or Gearmotor Mounting Package
 - Conveyor with Stands and Gearmotor Mounting Package
- Install new conveyor belt
- Tension conveyor belt

Preventive Maintenance and Adjustment

Belt Removal for Conveyor Without Stands

1. Remove air supply and remove hose (Figure 22, item AW) from center drive.




Figure 22

2. If equipped, remove return rollers and guiding and accessories from one side of conveyor.
3. Temporarily support idler guard assembly (Figure 23, item AX). Remove screws (AY).




Figure 23

4. Swing down idler guard assembly (Figure 24, item AX). Remove screw (AZ) from both sides of center drive and remove idler guard assembly (AX).



Figure 24

5. Remove screws (Figure 25, item BA) and tensioning guards (BB) from both sides of center drive.




Figure 25

6. Temporarily support the tensioning roller guard (Figure 26, item BD). Remove screws (Figure 26, item BC) on both sides of center drive and remove tensioning roller guard (Figure 26, item BD) and (Figure 27, item BD).




Figure 26

7. Loosen tensioning roller set screws (Figure 27, item BE).




Figure 27

Preventive Maintenance and Adjustment

8. Push shaft (Figure 27, item BF) through block, slide block (Figure 28, item BG) towards air cylinder (BH).




Figure 28

9. Push shaft (Figure 29, item BF) through block (BG) on opposite side of center drive, slide block toward air cylinder (BH).




Figure 29

10. Slide out tensioning roller (Figure 30, item BI).




Figure 30

11. Remove belt (Figure 31, item BJ) from center drive module (B) and conveyor.




Figure 31

12. Remove screws (BK of (Figure 32, item) on both sides of knuckle and remove guard (BL).




Figure 32

13. Push in hex posts (Figure 33, item BM) and remove roller (BN).




Figure 33

14. Remove belt (Figure 34, item BJ) from conveyor.




Figure 34

Preventive Maintenance and Adjustment

Belt Removal for Conveyor With Stands

⚠ WARNING



Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing severe injury.

When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, CHECK FOR POTENTIAL PINCH POINTS and other mechanical hazards before system start-up.

SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.

1. Place temporary support stands (Figure 37, item BO) at both ends of the conveyor. See WARNING.




Figure 35

2. If equipped, remove return rollers, guiding and accessories from one side of conveyor.
3. Repeat steps 1 thru 13 of the “Belt Removal for Conveyors Without Stands” section on page 14.
4. Remove first mounting brackets (Figure 37, item BQ) from one side of conveyor. (Reverse steps 3 & 4 of “Mounting Brackets” section on page 9).
5. Remove belt (Figure 36, item BJ) from conveyor, one stand at a time. Start on one end of conveyor and work down to opposite end.




Figure 36




Figure 37

Belt Installation for Conveyor without Stands

1. Orient belt so splice leading fingers (Figure 40, item BR) point in the direction of belt travel as identified by the conveyor directional label (BS).




Figure 38

2. Slide belt onto the conveyor frame assembly.
3. Reverse steps 1 thru 13 of the “Belt Removal for Conveyors Without Stands” section on page 14.
4. If equipped, install wipers, return rollers and guiding.
5. Reattach air supply (Figure 39, item AW) to center drive. Refer to “Conveyor Belt Tensioning” section on page 17 for more information.





Figure 39

6. Track conveyor and center drive if required. See “Center Drive Module Tracking” section on page 19 and “Conveyor Belt Tracking” section on page 19.

Preventive Maintenance and Adjustment

Belt Installation for Conveyor with Stands

⚠ WARNING

<p>Loosening stand height or angle adjustment screws may cause conveyor sections to drop down, causing severe injury.</p> <p>When conveyors are used in conjunction with other equipment or as part of a multiple conveyor system, CHECK FOR POTENTIAL PINCH POINTS and other mechanical hazards before system start-up.</p> <p>SUPPORT CONVEYOR SECTIONS PRIOR TO LOOSENING STAND HEIGHT OR ANGLE ADJUSTMENT SCREWS.</p>

1. Ensure temporary support stands (Figure 37, item BO) are placed at both ends of the conveyor. See WARNING.
2. Orient belt so splice leading fingers (Figure 40, item BR) point in the direction of belt travel as identified by the conveyor directional label (BS).




Figure 40

3. Install belt (Figure 41, item BJ) on conveyor. Lift conveyor slightly to avoid pinching belt on temporary support stands.




Figure 41

4. Re-install conveyor mounting brackets. Refer “Mounting Brackets” on page 9, steps 3 through 5.

5. Reverse steps 1 thru 13 of the “Belt Removal for Conveyors Without Stands” section on page 14.
6. If equipped, install wipers, return rollers and guiding.
7. Reattach air supply (Figure 42, item AW) to center drive. Refer to “Conveyor Belt Tensioning” section on page 17 for more information.





Figure 42

8. Track conveyor and center drive if required. See “Center Drive Module Tracking” section on page 19 and “Conveyor Belt Tracking” section on page 19.

Conveyor Belt Tensioning

⚠ WARNING

<p>Exposed moving parts can cause severe injury.</p> <p>LOCK OUT POWER before removing guards or performing maintenance.</p>

Preventive Maintenance and Adjustment

A - With Pneumatic Tensioning

1. Connect air supply (Figure 43, item AW) to regulator (BT).
2. Adjust regulator (Figure 43, item BT) until gage reads the appropriate pressure. Adjust regulator starting at 15 psi sufficiently to keep belt from slipping up to the maximum shown in the following table.




Figure 43

Suggested Maximum Tensioning Air Pressure for LPZ & 3200 Series Flat Belt Center Drive Conveyors	
Width	Pressure
4" (95 mm)	20 psi (138 kPa)
6" (152 mm)	30 psi (207 kPa)
8" (203 mm)	40 psi (276 kPa)
10" (254 mm)	50 psi (345 kPa)
14" (356 mm)	60 psi (414 kPa)
18" (457 mm)	70 psi (483 kPa)
24" (610 mm) & wider	80 psi (552 kPa)

3. If proper belt tension cannot be achieved before the out of tension indicator (Figure 44, item BU) begins to turn red, the belt must be replaced.




Figure 44

4. If belt tracking is necessary, refer to "Conveyor Belt Tracking" on page 19 and "Center Drive Module Tracking" on page 19.

B - With Manual Tensioning

1. Turn knurled knob (Figure 45, item BW) on each side of center drive unit clockwise until tensioning spring (BX) is completely behind spring cover (BY). There should be approximately 1/8" gap () between hand knob (BZ) and spring cover (BY).





Figure 45

2. As normal belt stretch occurs over time, the spring (Figure 45, item BX) will be exposed out of the spring cover (BY). When the spring is exposed over 1/2" or if conveyor belt slippage occurs, retighten knurled hand knob (BW) on each side of center drive unit clockwise until tensioning spring is completely behind spring cover.
3. If proper belt tension cannot be achieved before the out of tension indicator (Figure 44, item BU) begins to turn red, the belt must be replaced.
4. If belt tracking is necessary, refer to "Conveyor Belt Tracking" on page 19 and "Center Drive Module Tracking" on page 19.

Preventive Maintenance and Adjustment

Conveyor Belt Tracking

V-Guided Belts

V-guides on belts help maintain proper belt tracking. Track as needed to reduce belt bulge from center of belt (Figure 46). See steps below in “Non V-guided Belts” procedure for adjusting for any belt bulging. Belt bulge will be minimal when belt is properly tracked.



Figure 46




Figure 48

Non V-Guided Belts

Non V-guided belt conveyors are equipped with belt tracking assemblies.

When adjusting belt tracking, always adjust the discharge end of the conveyor first. To adjust belt tracking:

1. On the side of conveyor which the belt is tracking towards, loosen the head plate fastening screws (Figure 47, item CA).




Figure 47




Figure 49

3. Re-tighten the head plate fastening screws (Figure 47, item CA) with a 5 mm hex-key wrench to 146 in-lb (16.5 Nm).

Center Drive Module Tracking

V-Guided Belts

V-guided belts do not require tracking adjustment.

Non V-Guided Belts

Non V-guided belt center drives are equipped with cam tracking assemblies.

To adjust center drive tracking, with the conveyor running:

2. With the conveyor running, use wrench (Figure 48, item CB) to rotate the tracking screw (Figure 49, item CC) in small increments until the belt tracks in the center of the conveyor.

Preventive Maintenance and Adjustment

1. Inspect belt as it exits the center drive:
 (Figure 50) – Normally tracked belt, do nothing
 (Figure 51) – Tracking necessary, adjust tight side cam



Figure 50



Figure 51

2. If necessary, adjust the tracking cam: loosen the center drive fastening screws (Figure 52, item CD) on the side of center drive to be tracked.




Figure 52

3. Rotate the tracking cam (Figure 53, item CE) in small increments, each time inspecting the belt as it exits the center drive. Continue to rotate the tracking cam until conveyor belt is tracking normally.




Figure 53

4. Tighten the center drive fastening screws (Figure 52, item CD) to 146 in-lbs (16.5 N-m).

Conveyor Angle Adjustment

⚠ WARNING
<p>Removing mounting brackets or adjustment screws without support under gearmotor and conveyor will cause conveyor to tip or drop, causing severe injury.</p> <p>PROVIDE SUPPORT UNDERNEATH THE GEARMOTOR WHEN ADJUSTING THE CONVEYOR ANGLE</p>
⚠ WARNING
<p>Exposed moving parts can cause severe injury.</p> <p>LOCK OUT POWER before removing guards or performing maintenance.</p>

Preventive Maintenance and Adjustment

1. Place temporary support (Figure 54, item CF) under conveyor sections.




Figure 54

2. Loosen screws (Figure 55, item CG) on both sides of knuckle.




Figure 55

3. Move conveyor to desired angle as indicated by angle label (Figure 56, item CH).




Figure 56

4. Tighten screws (Figure 55, item CG) on both sides of knuckle to 100 in-lbs (12 N-m).

End and Knuckle Pulley Removal

⚠ WARNING



Exposed moving parts can cause severe injury.

LOCK OUT POWER before removing guards or performing maintenance.

⚠ WARNING



Exposed moving parts can cause severe injury.

REMOVE COMPRESSED AIR SUPPLY before removing guards or performing maintenance.

1. Remove air supply and remove hose (Figure 57, item AW) from center drive.




Figure 57

Preventive Maintenance and Adjustment

2. Temporarily support idler guard assembly (Figure 58, item AX). Remove screws (AY).




Figure 58

3. Swing down idler guard assembly (Figure 59, item AX).



Figure 59

Remove the desired pulley following the corresponding instructions below:

- A – Idler Pulley Removal
- B – Transfer Tail Pulley Removal
- C – Knuckle Idler Pulley Removal
- D – Knuckle Return Roller Removal

A – Idler Pulley Removal

1. Temporarily support the idler pulley.



Figure 60

2. On one side of conveyor, loosen the two (2) back fastening screws (Figure 61, item T) and remove two (2) front fastening screws (CI).




Figure 61

3. Pull back the outer headplate (Figure 62, item U) and remove the inner spacer (CJ).




Figure 62

4. Slide the idler pulley assembly (Figure 63, item CK) out of the headplate on the opposite side.




Figure 63

Preventive Maintenance and Adjustment

5. Remove the pulley shaft assembly: remove the clip ring (Figure 64, item CL) and washer (CM) from one side of the pulley assembly.




Figure 64

2. On one side of conveyor, loosen the two (2) back fastening screws (Figure 67, item T), and remove the two (2) front fastening screws (CI).




Figure 67

6. Slide the shaft assembly (Figure 65, item CN) out of the pulley (CK).




Figure 65

3. Pull back the outer headplate (Figure 68, item U) and remove the inner spacer (CJ).




Figure 68

B – Transfer Tail Pulley Removal

1. Temporarily support the transfer tail assembly.



Figure 66

Preventive Maintenance and Adjustment

- Slide the transfer tail pulley assembly (Figure 69, item CO) out of the headplate on the opposite side.

NOTE

Transfer tail assembly must be removed as on piece. Removal may require removing screws T of Figure 66 and headplate U of Figure 67 as shown in Figure 68




Figure 69

- Remove hex nuts (Figure 70, item CP).




Figure 70

- Remove support plates (Figure 71, item CQ) and washers (CR).




Figure 71

- Remove pulleys (Figure 72, item CS) and additional washers (CT).




Figure 72

- To remove additional pulleys, repeat steps 6 through 7.

C – Knuckle Idler Pulley Removal

- Remove knuckle return roller and guard see “Knuckle Return Roller Removal” on page 25.
- Temporarily support the knuckle idler pulley.



Figure 73

- On one side of knuckle, remove screws (Figure 74, item CU) and knuckle plate assembly (CV).




Figure 74

Preventive Maintenance and Adjustment

- Slide the idler pulley assembly (Figure 75, item CW) out of the knuckle plate on the opposite side.




Figure 75

- Remove the pulley shaft assembly: remove the clip ring (Figure 76, item CL) and washer (CM) from one side of the pulley assembly.




Figure 76

- Slide the shaft assembly (Figure 65, item CN) out of the pulley (CW).




Figure 77

D – Knuckle Return Roller Removal

- Remove screws (Figure 78, item BK) on both sides of knuckle and remove guard (BL).




Figure 78

- Push in hex posts (Figure 79, item BM) and remove pulley (BN).




Figure 79

Center Drive Pulleys Removal

⚠ WARNING



Exposed moving parts can cause severe injury.

LOCK OUT POWER before removing guards or performing maintenance.

Preventive Maintenance and Adjustment

⚠ WARNING



Exposed moving parts can cause severe injury.
REMOVE COMPRESSED AIR SUPPLY before removing guards or performing maintenance.

- A – Tensioner Pulley Removal
- B – Idler Pulley Removal
- C – Drive Pulley Removal

A – Tensioner Pulley Removal

1. Remove air supply and remove hose (Figure 80, item AW) from center drive.




Figure 80

2. Remove screws (Figure 81, item BA) and tensioning guards (BB) from both sides of center drive.




Figure 81

3. Temporarily support the tensioning roller guard (Figure 82, item BD). Remove screws (BC) on both sides of center drive and remove tensioning roller guard (Figure 82, item BD) and (Figure 83, item BD).




Figure 82

4. Loosen tensioning roller set screws (Figure 83, item BE) on one side of center drive.




Figure 83

5. Push shaft (Figure 82, item BF) through block, slide block (Figure 84, item BG) towards air cylinder (BH).




Figure 84

Preventive Maintenance and Adjustment

6. Push shaft (Figure 85, item BF) through block (BG) on opposite side of center drive, slide block toward air cylinder (BH).




Figure 85

7. Slide out tensioning pulley (Figure 86, item BI).




Figure 86

8. Remove the tension pulley locking collar (Figure 87, item CX), spacer (CY) and pulley shaft (CZ) from the roller pulley shaft assembly.




Figure 87

B – Idler Pulley Removal

1. Remove air supply and remove hose (Figure 88, item AW) from center drive.




Figure 88

2. Temporarily support idler guard assembly (Figure 89, item AX). Remove screws (AY).




Figure 89

3. Swing down idler guard assembly (Figure 90, item AX). Remove screw (AZ) from both sides of center drive and remove idler guard assembly (AX).



Figure 90

Preventive Maintenance and Adjustment

4. Remove screws (Figure 91, item DA) and idler guide side plate (DB).




Figure 91

5. Slide the idler pulley assembly (Figure 92, item DC) out of the idler guide side plate on the opposite side.




Figure 92

6. Remove the pulley shaft assembly: remove the clip ring (Figure 93, item CL) and washer (CM) from one side of the pulley assembly.




Figure 93

7. Slide the shaft assembly (Figure 94, item CN) out of the pulley (CK).




Figure 94

C – Drive Pulley Removal

⚠ WARNING



Exposed moving parts can cause severe injury.
LOCK OUT POWER before removing guards or performing maintenance.

1. Remove air supply and remove hose (Figure 95, item AW) from center drive.




Figure 95

2. Remove screws (Figure 95, item DD) and guard (DE).

Preventive Maintenance and Adjustment

3. Remove screws (Figure 96, item DF) and remove gearmotor (DG) (Gearhead shown with motor removed for clarity, motor can remain attached to gearhead).

NOTE

Gearhead shown with motor removed for clarity, motor can remain attached to gearhead.




Figure 96

4. Remove spacer ring (Figure 97, item AS) and key (AO).
5. Reverse steps 3 thru 10 of the “Belt Removal for Conveyors Without Stands” section on page 14.




Figure 97

6. Loosen clamp screw (Figure 98, item DH) and remove bearing collar (DI).




Figure 98

7. Disconnect flexible air hose (Figure 99, item DJ) from fitting (DK).




Figure 99

8. Temporarily support the drive pulley (Figure 100, item DL).




Figure 100

Preventive Maintenance and Adjustment

9. Loosen clamp screw (Figure 101, item DH) and remove bearing collar (DI).




Figure 101

10. Remove screws (DM) and pull side plate assembly (DN) off conveyor.




Figure 102

11. Slide drive pulley (Figure 103, item DL) out of attached side plate.




Figure 103

Bearing Replacement

⚠ WARNING



Exposed moving parts can cause severe injury.
LOCK OUT POWER before removing guards or performing maintenance.

⚠ WARNING



Exposed moving parts can cause severe injury.
REMOVE COMPRESSED AIR SUPPLY before removing guards or performing maintenance.

- A – Idler Bearing
- B – Drive Bearing
- C – Transfer Tail Bearing
- D – Knuckle Idler Bearing
- E – Knuckle Return Roller Bearing

A – Idler Bearing Replacement

The bearings in a 3200 Series Idler Pulley can not be removed. Replace the entire pulley assembly when worn.

B – Drive Bearing Removal and Replacement

⚠ WARNING



Drive shaft keyway may be sharp.
HANDLE WITH CARE.

Preventive Maintenance and Adjustment

Drive Side Bearing

1. Remove air supply (Figure 104, item AW) from center drive module.




Figure 104

2. Remove screws (Figure 105, item DF) and remove gearmotor (DG) (Gearhead shown with motor removed for clarity, motor can remain attached to gearhead).




Figure 105

3. Remove spacer ring (Figure 106, item AS) and key (AO). Loosen clamp screw (DH) and remove bearing collar (DI).




Figure 106

4. Remove the three (3) mounting screws (Figure 107, item DO).




Figure 107

5. Remove and replace bearing housing assembly (Figure 107, item AV).
6. Tighten three (3) mounting screws (Figure 108, item DO) to 200 in-lbs (22.5 N-m).




Figure 108

7. Reinstall bearing collar (Figure 106, item DI). Tighten clamp screw (DH) to 95 in-lbs (11 N-m).
8. Reinstall key (Figure 106, item AO).
9. Reinstall spacer ring (Figure 109, item AS) and gearmotor (DG). Tighten screws (Figure 105, item DF) to 150 in-lbs (17 N-m).




Figure 109

Preventive Maintenance and Adjustment

Idler Side Bearing

1. Remove air supply (Figure 110, item AW) from center drive module.




Figure 110

2. Remove screws (Figure 110, item DD) and cover (DE).
3. Loosen clamp screw (Figure 111, item DH) and remove bearing collar (DI).




Figure 111

4. Remove the three (3) mounting screws (Figure 112, item DO).




Figure 112

5. Remove and replace housing assembly (Figure 112, item AV).
6. Tighten three (3) mounting screws (Figure 112, item DO) to 200 in-lbs (22.5 N-m).
7. Reinstall bearing collar (Figure 111, item DI). Tighten clamp screw (DH) to 95 in-lbs (11 N-m).
8. Reinstall cover (Figure 110, item DE). Tighten screws (DD) to 69 in-lbs (8 N-m).

C – Transfer Tail Bearing Replacement

The bearings in a 3200 Series Transfer Tail Pulley can not be removed. Replace the entire pulley assembly when worn.

D – Knuckle Idler Bearing Replacement

The bearings in a 3200 Series Knuckle Idler Pulley can not be removed. Replace the entire pulley assembly when worn.

E – Knuckle Return Roller Bearing Replacement

The bearings in a 3200 Series Knuckle Return Roller can not be removed. Replace the entire roller assembly when worn.

Pulley Replacement

Idler Pulley

To replace the idler pulley, reverse the “Idler Pulley Removal” procedure on page 22.

Drive Pulley

To replace the drive pulley, reverse the “Drive Pulley Removal” procedure on page 28.

Transfer Tail Pulley

To replace the transfer tail pulley, reverse the “Transfer Tail Pulley Removal” procedure on page 23.

Knuckle Pulley


To replace the knuckle pulley, reverse the “Knuckle Pulley Removal” procedure on page 24.

Knuckle Return Roller


To replace the knuckle return roller, reverse the “Knuckle Return Roller Removal” procedure on page 25.

Service Parts

NOTE

For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo . Dorner recommends keeping these parts on hand.

Center Drive Assembly



3200 Series Flat Belt Center Drive LPZ Conveyors

Service Parts


Item	Part Number	Description
1	200038	Cam Clamping Plate
2	See Table 1	Flat Guard
3	301088	Tail Clamping Bar
4	3227WW	Wand Assy for 3" Idler Roller
5	532419	Cylinder Channel Guard
6	301216	Cylinder Guard Mounting Block
7	301217	Torsion Arm Plate
8	301218	Side Plate Spacer
9	301219	Center Drive Side Plate
10	301220	End Roller Mounting Plate
11	301221	Horseshoe Guard Mount Plate
12	301222	Center Drive Tension Pulley Spacer
13	301278	Center Drive Bearing Guard
14	301281	Pipe Guard
15	301355	Cylinder Mounting Block
16	301356	Cylinder-Rod Mounting Block
17	301357	Tension Pulley Spacer
18	3242WW	Tension Pulley Axle Shaft
19	3243WW	Bottom End Guard
20	3244WW	Bottom Corner Guard
21	3287WW	6" Diameter Pulley
22	3290WW	3" Center Drive Pulley
23	200039P	Belt Tracking Cam
24	200341M	Cam Retaining Block
25	See Table 1	Inner Shaft Tube
26	802-138	3 Bolt Bearing
27	807-226	Snap Out Plastic Plug
28	807-1162	Hex Stand Off
29	807-1167	Gearhead Cover
30	812-061	Anti-rotation Bushing
31	824-331	1/2" EMT Steel Connector
32	825-160	1/4" BSPT Pipe Plug
33	911020M	Button Head Screw M10 x 20 mm
34	912-111	Square Key
35	915-265	E Retaining Ring
36	920512M	Socket Head Screw M5 x 12 mm
37	920520M	Socket Head Screw M5 x 20 mm
38	920610M	Socket Head Screw M6 x 10 mm
39	920816M	Socket Head Screw M8 x 16 mm
40	920860M	Socket Head Screw M8 x 60 mm
41	950812M	Low Head Cap Screw M8 x 12 mm
42	970820M	Cup Set Screw M8 x 20mm
43	301213	Pneumatic Tension Assy
44	32CD-WW	Center Drive Kit (includes items 4, 18, 22 and 26)

WW = Conveyor width reference: 04 – 60 in 02 increments

Conveyor Width	Item 2 – Flat Guard	Item 25 – Inner Shaft Tube
4"	300895-00374	301164
6"	300895-00599	301198-00209
8"	300895-00799	301198-00409
10	300895-00999	301198-00609
12	300895-01199	301198-00809
14	300895-01399	301198-01009
16	300895-01599	301198-01209
18	300895-01799	301198-01409
20	300895-01999	301198-01609
22	300895-02199	301198-01809
24	300895-02399	301198-02009
26	300895-02599	301198-02209
28	300895-02799	301198-02409
30	300895-02999	301198-02609
32	300895-03199	301198-02809
34	300895-03399	301198-03009
36	300895-03599	301198-03209
38	300895-03799	301198-03409
40	300895-03999	301198-03609
42	300895-04199	301198-03809
44	300895-04399	301198-04009
46	300895-04599	301198-04209
48	300895-04799	301198-04409
50	300895-04999	301198-04609
52	300895-05199	301198-04809
54	300895-05399	301198-05009
56	300895-05599	301198-05209
58	300895-05799	301198-05409
60	300895-05999	301198-05609

Service Parts


Center Drive Manual Tensioner



Item	Part Number	Description
1	301410	Threaded Rod 1/2" x 17" Long
2	3015WW	Spring Cage (04" through 24" Wide Conveyor)
	301524	Spring Cage (26" through 60" Wide Conveyor)
3	605280P	Hard Washer
4	802-139	Thrust Bearing Cage
5	802-140	Thrust Bearing Washer
6	807-1182	Spring – Blue (04" through 08" Wide Conveyor)
	807-1183	Spring – Red (10" through 12" Wide Conveyor)
	807-1184	Spring – Bronze (14" through 60" Wide Conveyor)
7	807-1185	Knurled Knob
8	807-1186	End Cap
9	807-1187	Threaded Plug
10	910-081	Hex Jam Nut 1/2"-20
11	950816M	Low Head Cap Screw M8 x 16 mm


WW = Conveyor width reference: 04 – 60 in 02 increments

3200 Center Drive 90° Industrial Gearmotors



Item	Part No.	Part Description
1	32M008HH	Gear Reducer, 7.5:1 NEMA 140TC
	32M010HH	Gear Reducer, 10:1 NEMA 140TC
	32M015HH	Gear Reducer, 15:1 NEMA 140TC
	32M020HH	Gear Reducer, 20:1 NEMA 140TC
	32M025HH	Gear Reducer, 25:1 NEMA 140TC
	32M030HH	Gear Reducer, 30:1 NEMA 140TC
	32M040HH	Gear Reducer, 40:1 NEMA 140TC
	32M050HH	Gear Reducer, 50:1 NEMA 140TC
	32M060HH	Gear Reducer, 60:1 NEMA 56C Gear
	32M080HH	Reducer, 80:1 NEMA 56C Gear
	32M100HH	Reducer, 100:1 NEMA 56C
2	62MS411FN	Motor, 0.25hp (0.19Kw), 115/230 Volts, 60 Hz, 1-Phase
	62MH411	Motor, 0.5hp (0.37Kw), 115/230 Volts, 60Hz, 1-Phase
	62MH423	Motor, 0.5hp (0.37Kw) 208-230/460 Volts, 60Hz, 3 Phase
	32MHH423FN10	Motor, 1 hp (0.75Kw), 230 Volts, 3 Phase
	32MS423EN	Motor, 0.5hp (0.37Kw), 230 Volts, 3 Phase Inverter Duty
	32MHH423EN10	Motor, 1hp (0.75Kw), 230 Volts, 3 Phase Inverter Duty
	32MHH423EN15	Motor, 1.5hp (1.1Kw), 230 Volts, 3 Phase Inverter Duty
	32MHH423FN15	Motor, 1.5hp (1.1Kw), 230 Volts, 3 Phase
	62MHD9DEN	Motor, 0.5hp (0.37Kw), 90 Volts DC
	62MHD9DEN75	Motor, 0.75hp (0.56Kw), 90 Volts DC
	32MHH423EN20	Motor, 2.0hp (1.5Kw), 230 Volts, 3 Phase Inverter Duty
	32MHH423FN20	Motor, 2.0hp (1.5Kw), 230 Volts, 3 Phase
	32MHH411EC10	Motor, 1.0hp (0.75Kw), 115 Volts, Integrated Controller
	32MHH411EC05	Motor, 0.5hp (0.37Kw), 115 Volts, Integrated Controller
3	820-329	Bushing Shaft Adapter, 56C to 140TC

Transfer Tail Assembly




Item	Part Number	Description
1	301082	Nosebar Cover Plate
2	301084	1" Inner Tail Plate
3	301088	Tail Bar Clamp Transfer
4	301090	Tail Support Plate
5	301196	Hex Tension Tracking Shaft
6	301352	Nut, E-ring, Brace
7	301354	Inner Transfer Tail Support Plate
8	3202 WW	Tail Articulation Bar
9	3217 WW	1" Idler Tail Axle Shaft
10	3219 WW	Support Bar
11	3237 WW	Transfer Tail Roller – (Qty. = 4 for 04–24 Wide, 8 for 26–48 Wide)
12	807-1136	Washer
13	807-1151	Retaining Ring

Item	Part Number	Description
14	807-1152	Hex Head Cap Screw M6 x 20 mm
15	910-203	3/8" Hex Nut
16	915-319	Retaining Ring
17	920408M	Hex Head Cap Screw M4 x 8 mm
18	950816M	Low Head Cap Screw M8 x 16 mm
19	32T1- WW	1" Idler Spindle Kit (includes items 6, 9, 11, 12, 15 and 16)
20	32TT1- WW	Tail Assembly (includes items 1 through 4, 6 through 12, 15 through 18)

~~WW~~ = Conveyor width reference: 04 – 48 in 02 increments

Service Parts


Idler End Tail Assembly



Item	Part Number	Description
1	301049	Idler Cover Plate
2	301083	Inner 3" Tail Plate
3	301088	Tail Bar Clamp
4	3282 WW	Idler Spindle Wand Assembly (includes items 8 and 11)
5	301196	Hex Tension Tracking Shaft
6	3202 WW	Tail Articulation Bar
7	3289 WW	3" Idler Pulley
8	605280P	Hard Washer
9	807-1151	Tracking Shaft Retaining Ring
10	807-1152	Hex Head Cap Screw M6 x 20 mm
11	915-235	Stub Shaft Retaining Ring
12	950816M	Low Head Cap Screw M8 x 16 mm
13	32T3- WW	Idler Spindle Kit (includes items 4 and 7)
14	32TT3- WW	Tail Assembly (including items 1 through 4, 6, 7 and 12)

~~WW~~ = Conveyor width reference: 04 – 48 in 02 increments

Knuckle Assembly




Item	Part Number	Description
1	300657	Slots Pointer Cover Disc
2	301155	Short LPZ Cover Plate
3	301156	Flat Upper Outside Plate
4	301160	LPZ Inside Pivot Plate
5	301223	LH Angle Label 0-35
6	301224	RH Angle Label 0-35
7	3225 WW	Return Roller Cover
8	3276 WW	Belt Support Rail Assy
9	3285 WW	LPZ-CD Idler Pulley Assy (includes items 15 and 16)
10	300150M	Drop In Tee Bar
11	3252 WW	Return Roller
12	920516M	Socket Head Screw M5 x 16 mm
13	920612M	Socket Head Screw M6 x 12 mm
14	950612M	Low Head Cap Screw M6 x 12 mm
15	3289 WW	3" Idler Pulley
16	3283 WW	Idler Shaft Assembly
17	915-235	Retaining Ring
18	LPZNO- WW	Nose Over Knuckle Kit (includes items 11, 15 and 16)

~~WW~~ = Conveyor width reference: 04 – 48 in 02 increments

Service Parts

Frame Assembly



Item	Part Number	Description
1	240420	Rack Gear
2	301091	Pinion Bearing
3	605279P	Washer
4	920484M	Flange Torx Screw, M4 x 16 mm
5	920616M	Socket Head Screw, M6 x 16 mm
6	950616M	Low Head Cap Screw M6 x 16 mm
7	3245WW	Cross Support Rail
8	301041-LLLLL	RH Side Rail
9	301042-LLLLL	LH Side Rail
10	3229WW	Pinion
11	See Bed Plate Rail Chart	Bed Plate Rail

WW = Conveyor width reference: 04 - 48 in 02 increments
 LLLLL = Frame Length (see Bed Plate & Frame Formulas)

Item 11: Bed Plate Rail	
Width	Part Number
1.75" (mm)	300887-LLLLL
2" (54mm)	300888-LLLLL
4" (102mm)	300889-LLLLL
6" (152mm)	300890-LLLLL

LLLLL = Bed Plate Length (see Bed Plate & Frame Formulas on the next page)

Bed Plate and Frame Formulas


Bed Plate and Frame Formulas

- Bed Plate LLLLL = Frame LLLLL – 00013
- Frame LLLLL = Conveyor Length LLLL X 12 – Tail Adder
of Sections of Conveyor
- Tail Adder = 00600 for each Tension End
00425 for each Non-Tension End
00600 for each Knuckle Attachment


Width	Bed Plate Configuration												
4"							1.75"						
6"							4"						
8"							6"						
10"						2"	4"	2"					
12"						2"	6"	2"					
14"						4"	4"	4"					
16"						4"	6"	4"					
18"						6"	4"	6"					
20"						6"	6"	6"					
22"					4"	4"	4"	4"	4"				
24"					4"	4"	6"	4"	4"				
26"					6"	4"	4"	4"	6"				
28"					6"	4"	6"	4"	6"				
30"					6"	6"	4"	6"	6"				
32"					6"	6"	6"	6"	6"				
34"				4"	4"	6"	4"	6"	4"	4"			
36"				4"	4"	6"	6"	6"	4"	4"			
38"				4"	6"	6"	4"	6"	6"	4"			
40"				4"	6"	6"	6"	6"	6"	4"			
42"				6"	6"	6"	4"	6"	6"	6"			
44"				6"	6"	6"	6"	6"	6"	6"			
46"			4"	4"	6"	6"	4"	6"	6"	4"	4"		
48"			4"	4"	6"	6"	6"	6"	6"	4"	4"		
50"			4"	6"	6"	6"	4"	6"	6"	6"	4"		
52"			4"	6"	6"	6"	6"	6"	6"	6"	4"		
54"			6"	6"	6"	6"	4"	6"	6"	6"	6"		
56"			6"	6"	6"	6"	6"	6"	6"	6"	6"		
58"		4"	4"	6"	6"	6"	4"	6"	6"	6"	4"	4"	
60"		4"	4"	6"	6"	6"	6"	6"	6"	6"	4"	4"	
62"		4"	6"	6"	6"	6"	4"	6"	6"	6"	6"	4"	
64"		4"	6"	6"	6"	6"	6"	6"	6"	6"	6"	4"	
66"		6"	6"	6"	6"	6"	4"	6"	6"	6"	6"	6"	
68"		6"	6"	6"	6"	6"	6"	6"	6"	6"	6"	6"	
70"	4"	4"	6"	6"	6"	6"	4"	6"	6"	6"	6"	4"	4"
72"	4"	4"	6"	6"	6"	6"	6"	6"	6"	6"	6"	4"	4"

Service Parts


Conveyor Configurations




Guiding Options (TT)



Section and Length Determination



Walk Through Frame – Section L1



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	639971M	Single Drop-in Tee Bar

Item	Part Number	Description
3	950620M	Low Head Cap Screw M6 x 20 mm

Elevating Belt Travel

Section L1 Length – LLLL	I	II	III
0200	No Guiding Section	38TT17	38TT18
0201 – 0399	$38TT00 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$	$38TT17 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$	$38TT18 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 12) - 02400$	38TT17	38TT18

For TT options see "Guide Options" section on page 42


Declining Belt Travel

Section L1 Length – LLLL	I	II	III
0200	No Guiding Section	38TT15	38TT16
0201 – 0399	$38TT00 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$	$38TT15 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$	$38TT16 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \underline{\text{LLLLL LLLLL}} = (\text{LLLL} \times 12) - 02400$	38TT15	38TT16

For TT options see "Guide Options" section on page 42

Service Parts

Walk Through Frame – Section L2



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	639971M	Single Drop-in Tee Bar

Item	Part Number	Description
3	950620M	Low Head Cap Screw M6 x 20 mm

Elevating Belt Travel

Section L2 Length – LLLL	I	II	III	IV	V
0200 – 0383	38TT17–LLLLL LLLLL = (LLLL x 6) + 00075	38TT18–LLLLL LLLLL = (LLLL x 6) + 00075	No Guiding Section	38TT15–LLLLL LLLLL = (LLLL x 6) + 00075	38TT16–LLLLL LLLLL = (LLLL x 6) + 00075
0384 – 0600	38TT17–LLLLL LLLLL = (LLLL x 4) + 00050	38TT18–LLLLL LLLLL = (LLLL x 4) + 00050	38TT00–LLLLL LLLLL = (LLLL x 4) + 00050	38TT15–LLLLL LLLLL = (LLLL x 4) + 00050	38TT16–LLLLL LLLLL = (LLLL x 4) + 00050
0601 and up	38TT17	38TT18	38TT00–LLLLL LLLLL = (LLLL x 12) – 04600	38TT15	38TT16


For TT options see “Guide Options” section on page 42

Declining Belt Travel

Section L2 Length – LLLL	I	II	III	IV	V
0200 – 0373	38TT15–LLLLL LLLLL = (LLLL x 6) + 00075	38TT16–LLLLL LLLLL = (LLLL x 6) + 00075	No Guiding Section	38TT17–LLLLL LLLLL = (LLLL x 6) + 00075	38TT18–LLLLL LLLLL = (LLLL x 6) + 00075
0373 – 0600	38TT15–LLLLL LLLLL = (LLLL x 4) + 00050	38TT16–LLLLL LLLLL = (LLLL x 4) + 00050	38TT00–LLLLL LLLLL = (LLLL x 4) + 00050	38TT17–LLLLL LLLLL = (LLLL x 4) + 00050	38TT18–LLLLL LLLLL = (LLLL x 4) + 00050
0601 and up	38TT15	38TT16	38TT00–LLLLL LLLLL = (LLLL x 12) – 04600	38TT17	38TT18

For TT options see “Guide Options” section on page 42

Walk Through Frame – Section L3



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	639971M	Single Drop-in Tee Bar

Item	Part Number	Description
3	950620M	Low Head Cap Screw M6 x 20 mm

Elevating Belt Travel

Section L3 Length – LLLL	I	II	III
0200	No Guiding Section	38TT15	38TT16
0201 – 0399	$38TT00 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT15 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT16 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 12) - 02400$	38TT15	38TT16

For TT options see "Guide Options" section on page 42


Declining Belt Travel

Section L3 Length – LLLL	I	II	III
0200	No Guiding Section	38TT17	38TT18
0201 – 0399	$38TT00 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT17 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT18 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \underline{\text{LLLLL}} \text{ LLLLL} = (\text{LLLL} \times 12) - 02400$	38TT17	38TT18

For TT options see "Guide Options" section on page 42

Service Parts

Nose Over Frame – Section L2



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	639971M	Single Drop-in Tee Bar

Item	Part Number	Description
3	950620M	Low Head Cap Screw M6 x 20 mm

Elevating Belt Travel

Section L2 Length – LLLL	I	II	III
0200	No Guiding Section	38TT17	38TT18
0201 – 0399	$38TT00 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$	$38TT17 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$	$38TT18 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \text{LLLL LLLL} = (\text{LLLL} \times 12) - 02400$	38TT17	38TT18


For TT options see "Guide Options" section on page 42

Declining Belt Travel

Section L2 Length – LLLL	I	II	III
0200	No Guiding Section	38TT15	38TT16
0201 – 0399	$38TT00 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$	$38TT15 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$	$38TT16 - \text{LLLL LLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \text{LLLL LLLL} = (\text{LLLL} \times 12) - 02400$	38TT15	38TT16

For TT options see "Guide Options" section on page 42

Nose Over Frame – Section L3



Item	Part Number	Description
1	200121	Guide Retaining Clip
2	639971M	Single Drop-in Tee Bar

Item	Part Number	Description
3	950620M	Low Head Cap Screw M6 x 20 mm

Elevating Belt Travel

Section L3 Length – LLLL	I	II	III
0200	No Guiding Section	38TT15	38TT16
0201 – 0399	$38TT00 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT15 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT16 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \text{LLLLL LLLLL} = (\text{LLLL} \times 12) - 02400$	38TT15	38TT16

For TT options see "Guide Options" section on page 42


Declining Belt Travel

Section L3 Length – LLLL	I	II	III
0200	No Guiding Section	38TT17	38TT18
0201 – 0399	$38TT00 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT17 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$	$38TT18 - \text{LLLLL LLLLL} = (\text{LLLL} \times 6) + 00038$
0400 and up	$38TT00 - \text{LLLLL LLLLL} = (\text{LLLL} \times 12) - 02400$	38TT17	38TT18

For TT options see "Guide Options" section on page 42


Service Parts

-13 Adjustable Guiding



Item	Part Number	Description
1	202983	Aluminum Profile Guide 2' (610mm)
	202984	Aluminum Profile Guide 3' (914mm)
	202985	Aluminum Profile Guide 4' (1219mm)
	202986	Aluminum Profile Guide 5' (1524mm)
	202987	Aluminum Profile Guide 6' (1829mm)
	202988	Aluminum Profile Guide 7' (2134mm)
	202989	Aluminum Profile Guide 8' (2438mm)
	202990	Aluminum Profile Guide 9' (2743mm)
	202991	Aluminum Profile Guide 10' (3048mm)
	202992	Aluminum Profile Guide 11' (3353mm)
	202993	Aluminum Profile Guide 12' (3658mm)
	202994	Aluminum Profile Guide 13' (3962mm)
	2	200830M
3	202004	Mounting Bracket
4	202027M	Guide Mounting Shaft Vertical
5	202028M	Guide Mounting Shaft Horizontal
6	674175MP	Square Nut
7	807-652	Cross Block
8	807-948	Vinyl Shaft Cap
9	614068P	Flat Extruded Guide (per foot)
10	920612M	Socket Head Screw M6 x 12 mm
11	920616M	Socket Head Screw M6 x 16 mm

-14 Tool-Less Adjustable Guiding




Item	Part Number	Description
1	807-948	Shaft Cap
2	807-1470	Cross Block
3	200830M	Drop-In Tee Bar
4	202004M	Mounting Bracket
5	202027M	Vertical Mounting Guide Shaft
6	202028M	Horizontal Mounting Guide Shaft

Item	Part Number	Description
7	674175MP	Square Nut, M6-1.00
8	920612M	Socket Head Screw, M6-1.00 x 12 mm
9	920616M	Socket Head Screw, M6-1.00 x 16 mm
10	460063-LLLLL	Aluminum Profile Guide
11	614068P-LLLLL	Extruded Guide

LLLLL = Length in inches with 2 decimal places.
 Length Example: Length = 95.25" LLLLL = 09525

Service Parts


Flat Belt Mounting Brackets



Item	Part Number	Description
1	240831	Stand Mount
2	300150M	Drop-In Tee Bar
3	605279P	Washer


Item	Part Number	Description
4	807-920	Square Nut M6 5 mm x 10 mm
5	920620M	Socket Head Screw M6 x 20 mm
6	950612M	Low Head Cap Screw M6 x 12 mm

Connecting Assembly without Stand Mount



Item	Part Number	Description
1	240858	Frame Bar Connector
2	240859	Intermediate Clamp Plate
3	950612M	Low Head Cap Screw M6 x 12 mm


Flat Belt Connecting Assembly with Stand Mount



Item	Part Number	Description
1	240858	Frame Connector Bar
2	240831	Stand Mount Joint
3	605279P	Washer

Item	Part Number	Description
4	807-920	Square Nut M6 5 mm x 10 mm
5	920620M	Socket Head Screw M6 x 20 mm
6	950612M	Low Head Cap Screw M6 x 12 mm

4" (102 mm) to 6" (152 mm) Flat Belt Return Roller



Item	Part Number	Description
1	240825	Return Roller Guard – Short
2	240827	Return Roller Clip
3	802-027	Bearing
4	913-100	Dowel Pin
5	950616M	Low Head Cap Screw M6 x 16 mm
6	240840	Roller Assembly (Includes Items 1, 3 and 4)
7	240830	4" (102mm) to 6" (152mm) Flat Belt Return Roller Assy

Service Parts

8" (203 mm) to 48" (1219 mm) Flat Belt Return Roller

Width	Bearing Quantity
8" (203mm) – 12" (305mm)	3
14" (356mm) – 18" (457mm)	4
20" (508mm) – 24" (610mm)	5
26" (660mm) – 28" (711mm)	6
30" (762mm) – 34" (864mm)	7
36" (914mm) – 40" (1016mm)	8
42" (1067mm) – 46" (1168mm)	9
48" (1219mm)	10

Item	Part Number	Description
1	240826	Return Roller Bearing
2	240827	Return Roller Clip
3	2409 \overline{WW}	Return Roller Guard
4	2410 \overline{WW}	Return Roller Rod

Item	Part Number	Description
5	950616M	Low Head Cap Screw M6 x 16 mm
6	3249 \overline{WW}	8" (203mm) – 48" (1219mm) Flat Belt Return Roller Assembly
\overline{WW} = Conveyor width reference: 08 – 48 in 02 increments		

Conveyor Belt Part Number Configuration

Flat Belt Conveyor Model Number

3 T – \overline{WW} \overline{LLLL} / \overline{SBV} *




Figure 113

Flat Belt Part Number Configuration

Refer to Dorner patent plate (Figure 113). From the model number, determine tail type (“T”), width (“ \overline{WW} ”), length (“ \overline{LLLL} ”), splice type (“S”) and belt type (“B”). Use data to configure belt part number as indicated below. *Add “V” for V-guided belts.

3 T – \overline{WW} \overline{LLLL} / \overline{SBV} *

3 _ – _ (Fill In) / _ \overline{V} *

Return Policy

Returns must have prior written factory authorization or they will not be accepted. Items that are returned to Dorner without authorization will not be credited nor returned to the original sender. When calling for authorization, please have the following information ready for the Dorner factory representative or your local distributor:

1. Name and address of customer.
2. Dorner part number(s) of item(s) being returned.
3. Reason for return.
4. Customer's original order number used when ordering the item(s).
5. Dorner or distributor invoice number (if available, part serial number).

A representative will discuss action to be taken on the returned items and provide a Returned Goods Authorization (RMA) number for reference. RMA will automatically close 30 days after being issued. To get credit, items must be new and undamaged. There will be a return charge on all items returned for credit, where Dorner was not at fault. It is the customer's responsibility to prevent damage during return shipping. Damaged or modified items will not be accepted. The customer is responsible for return freight.


Product Type									
Standard Products									Engineered to order parts
Product Line	Conveyors	Gearmotors & Mounting Packages	Support Stands	Accessories	Spare Parts (non-belt)	Spare Belts - Standard Flat Fabric	Spare Belts - Cleated & Specialty Fabric	Spare Belts - Plastic Chain	All equipment and parts
1100	30% return fee for all products except: 50% return fee for conveyors with modular belt, cleated belt or specialty belts						non-returnable		case-by-case
2200									
2200 Modular Belt									
2200 Precision Move									
2300									
2300 Modular Belt									
3200									
3200 LPZ									
3200 Precision Move									
4100									
5200									
5300									
6200									
Controls									
7200 / 7300	50% return fee for all products								
7350	non-returnable								
7360									
7400									
7600									

Returns will not be accepted after 60 days from original invoice date. The return charge covers inspection, cleaning, disassembly, disposal and reissuing of components to inventory. If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Contact Dorner for the name of your local representative. Our Customer Service Team will gladly help with your questions on Dorner products.

For a copy of Dorner's Warranty, contact factory, distributor, service center or visit our website at www.dorner.com.

For replacement parts, contact an authorized Dorner Service Center or the factory.

 <p>Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. © Dorner Mfg. Corp. 2010</p>	<p>DORNER MFG. CORP. 975 Cottonwood Ave., PO Box 20 Hartland, WI 53029-0020 USA TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA) Internet: www.dorner.com</p>	<p>Outside the USA: TEL 1-262-367-7600 FAX 1-262-367-5827</p>
---	--	---