Repair & Re-adjustment Instructions

Conveyor Belt Tracking Guides for 2100 Series and 3100 Series Low Side Conveyors



WARNING



To prevent injury, make sure all electrical and pneumatic power sources have been disconnected and locked-out before you perform any maintenance or replace any components.

These belt tracking guides are being supplied with your new conveyor belt to be used on **any low side aluminum frame conveyor**. These belt tracking guides (A of Figure 1) should be installed on each side of discharge end of conveyor. Each guide is a 3.5" (89 mm) long piece of formed plastic which


snaps onto the portion of the conveyor sidewall (C) above the T-slot channel.

To install the guide onto the conveyor sidewall, first place the lower lip (B), of the guide, against the upper edge of the conveyor sidewall T-slot channel. Then, apply inward and upward pressure to completely snap it into place.

To remove the guide from the conveyor sidewall, apply a slight outward and downward finger-pressure on one of the top corners of the guide and gradually peel it off the portion of the conveyor sidewall (C).

NOTE:

Use the belt tracking guides (A of Figure 1) during initial conveyor startup for tracking conveyor belt, as necessary (see startup procedure in conveyor "Set-up, Operation and Maintenance Manual"). Guides may be left on or removed, after startup. Be sure to save the belt tracking guides *for startup after conveyor maintenance*.






Figure 1: Conveyor Low Side Belt Tracking Guide Installation - 2100 Series (left) & 3100 Series (right)

DORNER

Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. ©Dorner Mfg. Corp. 1997

DORNER MFG. CORP.

580 Industrial Drive, PO Box 20 Hartland, WI 53029-0020 USA **USA**

TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA)

Outside the USA: TEL 1-414-367-7600, FAX 1-414-367-5827

DORNER

Arnold-Sommerfeld-Ring 2 D-52499 Baesweiler Germany TEL (02401) 80 52 90 FAX (02401) 80 52 93