

Installation, Maintenance & Parts Manual

3200 & LPZ Series Side Mount Parallel Drive Package for Standard Load 60 Hz Gearmotors



Table of Contents

Warnings – General Safety	2
Introduction	2
Product Description	3
Specifications	
Gearmotors	6
3200 Belt Speeds	6
Installation	6
Required Tools	6
Mounting	6

Preventive Maintenance & Adjustment	7
Required Tools	7
Motor Replacement	7
Service Parts	9
Side Mount Drive Package	9
Gearmotors 10	0
Return Policy 12	2

Warnings – General Safety



Introduction

IMPORTANT: Some illustrations may show guards removed. Do NOT operate equipment without guards.

Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage.
- Accessories may be shipped loose. See accessory instructions for installation.

Dorner 3200 Series conveyors are covered by patent numbers 5156260, 5156261, 5203447, 5265714 and patent applications in other countries.

Dorner LPZ Series conveyors are covered by patent numbers 5156260, 5156261, 5203447, 5265714, 5875883 and patent applications in other countries.

Dorner's Limited Warranty applies.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits logo

Product Description

Refer to Figure 1 for typical components.

Typical Components

- A Conveyor
- B Gearmotor Assembly
- C Spider Web Bushing D Anti-rotation Pin
- E Anti–rotation Pin



Figure 1

Specifications

Gearmotor Mounting Package Models: Example:





Table 1: Gearmotor Specifications

	Single Phase	Three Phase	DC Variable Speed	VFD Variable Speed
Power/ Gear Ratio	hp (kW)	hp (kW)	hp (kW)	hp (kW)
5:1	.08 (.06)	.17 (.13)	.12 (.09)	.17 (.13)
10:1	.17 (.13)	.17 (.13)	.25 (.19)	.17 (.13)
20:1	.33 (.25)	.38 (.28)	.25 (.19)	.38 (.28)
30:1	.33 (.25)	.38 (.28)	.25 (.19)	.38 (.28)
60:1	.33 (.25)	.38 (.28)	.33 (.25)	.38 (.28)
180:1	.33 (.25)	.38 (.28)	N/A	.38 (.28)
Input Voltage	115 VAC	230 VAC	130 VDC	230 VAC
Input Frequency	60 Hz	60 Hz	N/A	10 to 60 Hz

3200 & LPZ Series Side Mount Parallel Drive Package for Light & Standard Load 60 Hz Gearmotors IMPM Dorner Mfg. Corp. 3 851-524 Rev. B

Specifications

Table 1: Gearmotor Specifications Continued

	Single Phase	Three Phase	DC Variable Speed	VFD Variable Speed
Input Current/ Gear Ratio	FLA	FLA	FLA	FLA
5:1	1.2	1.0	1.0	1.0
10:1	1.9	1.0	1.8	1.0
20:1	4	1.9	1.8	1.9
30:1	4	1.9	1.8	1.9
60:1	4	1.9	2.3	1.9
180:1	4	1.9	N/A	1.9
Motor RPM	1725	1725	2500	1725
Power/Ratio	Totally Enclosed	Fan Cooled	Totally Enclosed Non-Ventilated	Totally Enclosed Fan Cooled

Table 2: Belt Speeds for Fixed Speed Parallel Shaft 60 Hz Gearmotors

Standard Loa	Belt Speed				
Part Number	RPM	In-Ib	N-m	Ft/min	M/min
62M180PS4vpFn	10	226		7.6	2.3
62M060PS4vpFn	29	237		22.9	7.0
32M030PS4vpFn	58	142		45.8	14.0
32M020PS4vpFn	86	78		68.6	20.9
32M010PS4vpFn	173	41		137.3	41.9
32M005PS4vpFn	345	41		274.6	83.7

(vp) = voltage and phase

11 = 115 V, 1-phase

23 = 208 - 230/460 V, 3-phase

Table 3: Belt Speeds for Variable Speed Parallel Shaft VFD Gearmotors

Standard Load	Belt S	peed			
Part Number	RPM	In-lb	N-m	Ft/min	M/min
62M180PS4vpFn	10	226		1.3–7.6	0.4-2.3
62M060PS4vpFn	29	237		3.8–22.9	1.2–7.0
32M030PS4vpFn	58	142		7.6–45.8	2.3–14.0
32M020PS4vpFn	86	78		11.5–68.6	3.5–20.9
32M010PS4vpFn	173	41		22.9–137. 3	7.0–41.9
32M005PS4vpFn	345	41		45.9–274. 6	14.0-83.7

Table 4: Belt Speeds for Variable Speed Parallel Shaft DC Gearmotors

Standard L	Belt S	Speed			
Part Number	RPM	In-lb	N-m	Ft/min	M/min
62M180PSD3DEN	14	226		1.3–11.1	0.4–3.4
62M060PSD3DEN	42	237		4.0-33.2	1.2-10.1
62M030PSD3DEN	83	142		8.0-66.3	2.4-20.2
62M020PSD3DEN	125	78		11.9–99.5	3.6–30.3
62M010PSD3DEN	250	41		23.9–199.0	7.3–60.7

NOTE: For belt speed other than those listed, contact factory for details.

Installation

Required Tools

- Hex key wrenches: 2 mm, 2.5 mm, 3 mm, 5 mm
- Straight edge
- Torque wrench

Mounting



WARNING

Exposed moving parts can cause severe injury. LOCK OUT POWER before removing guards or performing maintenance.

Installation Component List

- B Gearmotor Assembly
- C Spider Web Bushing
- D Anti Rotation Pin
- 1. Typical components (Figure 2)



Figure 2

2. Install spider bushing (C of Figure 3) in three jaw coupling (F).



Figure 3

3. Rotate conveyor belt and attached conveyor coupling (G of Figure 4) to align with gearmotor coupling (H).





4. Slide mounting screws (I of Figure 5) through slots (J) in gearmotor bracket (K) and rotate gearmotor assembly into desired position.



Tighten screws (I of Figure 6) to 146 in-lbs (16.5 N-m) and install anti rotation pin (D).



Figure 6

Preventive Maintenance and Adjustment

Required Tools

- Hex key wrenches: 2 mm, 2.5 mm, 3 mm, 5 mm
- Adjustable wrench (for hexagon head screws)
- Straight edge
- Torque wrench

Motor Replacement



BEFORE WIRING.

- **1.** For single phase motor, unplug power cord from outlet.
- 2. For three phase and VFD variable speed motor:
- **a**. Loosen terminal box screws (L of Figure 7) and remove cover (M).



- **b**. Record wire colors on terminals 1, 2 and 3. Loosen wire nuts and remove wires 1, 2 and 3.
- **c**. Loosen cord grip and remove cord.
- **3.** For DC variable speed motor, unplug motor cord at disconnect (N of Figure 8).



- **4.** Reverse steps 2 thru 5 of the "Mounting" section on page 6.
- **5.** Remove four (4) screws (O of Figure 9) and detach coupling covers (P).



Figure 9

6. Loosen set screw (Q of Figure 10) and remove 3 jaw coupling (F).



Figure 10

7. Remove four (4) screws (R of Figure 11) and detach motor (S).

Preventive Maintenance and Adjustment



- **8.** Install mounting plate (T of Figure 11) on new motor with screws (R) and tighten to 75 in–lbs (8.5 N–m).
- **9.** Install 3 jaw coupling (F of Figure 12) and tighten set screw (Q) to 45 in–lbs (5 N–m).
- **10.** Install coupling covers (P of Figure 9) with four (4) screws (O) and tighten to 110 in–lbs (12 N–m).



Figure 12

11. Follow steps 2 thru 5 of the "Mounting" section on page 6.

12. Replace wiring:

- For a single phase motor, reverse step 1 on this page.
- For a three phase or VFD variable speed motor, reverse step 2 on this page.
- For a DC variable speed motor, reverse step 3 on this page.

NOTE: For replacement parts other than those shown on this page, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo. Dorner recommends keeping these parts on hand.

6

807-1142

3/4" 3 Jaw Coupling



			7	5		12 View of the second s
Item	Part Number	Description	7		807–1143	3 Jaw Rubber Spider
1	301092	Short Side Drive Guard	8		902-130	Socket Head Cap Screw 1/4-20 x 0.62"
2	301093	Long Side Drive Guard	9		912-078	Square Key
3	301094	Side Drive Mounting Ring	10	0	920635M	Socket Head Screw M6 x 35mm
4	301096	Parallel Face Motor Mounting Plate	1	1	920680M	Socket Head Screw M6 x 80mm
5	807–1140	20mm 3 Jaw Coupling	1:	2	980632M	Square Key, Undersize
					-	-

Service Parts

3200 Standard Load Parallel Shaft Industrial Gearmotors



Figure 13

aearr	notors	
Item	Part No.	Part Description
1	62M180PS411FN	Motor, 0.08hp (0.06Kw), 115 Volts, 60 Hz, 1-Phase
	62M180PS411FR	Motor, 0.08hp (0.06Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M180PS423FN	Motor, 0.17hp (0.13Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	62M060PS411FN	Motor, 0.17hp (0.13Kw), 115 Volts, 60 Hz, 1-Phase
	62M060PS411FR	Motor, 0.17hp (0.13Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M060PS423FN	Motor, 0.17hp (0.13Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	32M030PS411FN	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase
	32M030PS411FR	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M030PS423FN	Motor, 0.38hp (0.28Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	32M020PS411FN	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase
	32M020PS411FR	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M020PS423FN	Motor, 0.38hp (0.28Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	32M010PS411FN	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase
	32M010PS411FR	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M010PS423FN	Motor, 0.38hp (0.28Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	32M005PS411FN	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase
	32M005PS411FR	Motor, 0.33hp (0.25Kw), 115 Volts, 60 Hz, 1-Phase with Reversing
	62M005PS423FN	Motor, 0.38hp (0.28Kw), 208–230/460 Volts, 60 Hz, 3-Phase
	62M180PSD3DEN	Motor, 0.12 (0.09 Kw), 130 Volts DC
	62M060PSD3DEN	Motor, 0.25 (0.19 Kw), 130 Volts DC
	62M030PSD3DEN	Motor, 0.25 (0.19 Kw), 130 Volts DC
	62M020PSD3DEN	Motor, 0.25 (0.19 Kw), 130 Volts DC
	62M010PSD3DEN	Motor, 0.33 (0.25 Kw), 130 Volts DC
	62M180PS423EN	Motor, 0.17 (0.13 Kw), 230 Volts, 60 Hz, 3-Phase VFD
	62M060PS423EN	Motor, 0.17 (0.13 Kw), 230 Volts, 60 Hz, 3-Phase VFD
	62M030PS423EN	Motor, 0.38 (0.28 Kw), 230 Volts, 60 Hz, 3–Phase VFD
	62M020PS423EN	Motor, 0.38 (0.28 Kw), 230 Volts, 60 Hz, 3–Phase VFD
	62M010PS423EN	Motor, 0.38 (0.28 Kw), 230 Volts, 60 Hz, 3–Phase VFD
2	917–078	Key, Square, 0.188" x 0.75" L

Return Policy

No returns will be accepted without prior written factory authorization. When calling for authorization, please have the following information ready for the Dorner Factory representative or your local distributor:

- 1. Name and address of customer.
- 2. Item(s) being returned.
- 3. Reason for return.
- 4. Customer's original order number used when ordering the item(s).
- 5. Dorner or distributor invoice number.

A representative will discuss action to be taken on the Returned items and provide a Returned Goods Authorization Number to reference.

There will be a 15% restocking charge on all new items returned for credit where Dorner was not at fault. These will not be accepted after 60 days from original invoice date. The restocking charge covers inspection, cleaning, disassembly, and reissuing to inventory.

If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Feel free to contact Dorner for the name of your local representative. Our technical sales and service staff will gladly help with your questions on Dorner products.

For a copy of Dorner's Limited Warranty, contact factory, distributor, service center or visit our website at www.dorner.com.



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. [©]Dorner Mfg. Corp. 2000

DORNER MFG. CORP. 975 Cottonwood Ave. PO Box 20 Hartland, WI 53029-0020 USA USA TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA) Internet: www.domer.com

Outside the USA: TEL 1-262-367-7600 FAX 1-262-367-5827

Printed in U.S.A.