

2100, 2200, 4100, 6200 and MPB Series Bottom Mount Drive Package for Light Load 60 Hz Gearmotors

Installation Maintenance & Parts Manual







DORNER MFG. CORP. P.O. Box 20 • 975 Cottonwood Ave. Hartland, WI 53029-0020 USA INSIDE THE USA TEL: 1-800-397-8664 FAX: 1-800-369-2440 OUTSIDE THE USA TEL: 262-367-7600 FAX: 262-367-5827

For other service manuals visit our website at: www.dorner.com/service_manuals.asp

Table of Contents

Introduction	2
Warnings – General Safety	3
Product Description	4
Specifications	4
Installation	7
Required Tools	7
Mounting	7
Preventive Maintenance and Adjustment 1	(
Required Tools 1	С
Timing Belt Tensioning 1	0

Introduction

IMPORTANT

Some illustrations may show guards removed. Do NOT operate equipment without guards.

Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage.
- Accessories may be shipped loose. See accessory instructions for installation.

Dorner 2100 Series conveyors are covered by the following patent numbers: 5131529, 5174435, and corresponding patents and patent applications in other countries.

Timing Belt Replacement	10
Drive or Driven Pulley Replacement	11
Gearmotor Replacement	11
Service Parts	14
2100, 2200, 4100, 6200 Series and MPB Series	
Light Load Bottom Mount Drive Package	14
4100 Series Adapter Package	15
Gearmotors	15
Return Policy	16
•	

Dorner 2200 and MPB Series conveyors are covered by patent number 5174435 and corresponding patents and patent applications in other countries.

Dorner 4100 Series conveyors are covered by patent number 3923148 and corresponding patents and patent applications in other countries.

Dorner 6200 Series conveyors are covered by patent number 6685009, 5174435, 6109427 and corresponding patents and patent applications in other countries.

Dorner's Limited Warranty applies.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits logo

Warnings – General Safety



Product Description

Refer to Figure 1 for typical components.

А	Conveyor
В	Mounting Bracket
С	Gearmotor
D	Belt Tensioner
Е	Cover
F	Timing Belt
G	Drive Pulley
Н	Driven Pulley



* See "Ordering and Specifications" Catalog for details.

Specifications

Gearmotor Mounting Package Models:

Example:

2 M B P L WW A - 32 32

Driven Pulley (see Belt Speed Tables) Drive Pulley (see Belt Speed Tables) Belt Type: - = flat belt, A through J = cleated belt Mount Position = A, B, C or D (see detail to the right) Conveyor Width Reference* Gearmotor Type: L = Fixed Speed, V = Variable Speed Output Shaft Type: P = Parallel Shaft Mount Style: B = Bottom Mount F = Flush Mount (2200 Series Only) Language Code: M = U.S. English 2 = 2100 Series Conveyor 22 = 2200 Series Conveyor 4 = 4100 Series Conveyor 6 = 6200 Series Conveyor

<u></u>	
->	Α







* See "Ordering and Specifications" Catalog for details.

2P = MPB Series Conveyor

Table 1: Gearmotor Specifications

	Single Phase	DC Variable Speed
Output Power	0.03 hp (0.025 kw)	0.06 hp (0.04 kw)
Input Voltage	115 Volts A.C.	130 Volts D.C.
Input Frequency	60 Hz	N/A
Full Load Amperes	0.49 Amperes	0.48 Amperes
Gearmotor Ratios	15:1 and 36:1	18:1 and 60:1

Specifications

Table 2: Belt Speeds for Light Load Fixed Speed Parallel Shaft 60 HzGearmotors on 2100, 2200 Gang Drive, 4100 and 6200 Series Conveyors

Gearmotors*						Speed	Drive	Driven
Part Number	Gear Ratio	RPM	In-lb	N-m	Ft/min	M/min	Pulley	Pulley
62M036PL4FN	36:1	42	36	4.1	8	2.4	22	32
62M036PL4FN	36:1	42	36	4.1	12	3.7	32	32
62M036PL4FN	36:1	42	36	4.1	17	5.2	32	22
62M036PL4FN	36:1	42	36	4.1	24	7.3	44	22
62M015PL4FN	15:1	100	15	1.7	29	8.8	32	32
62M015PL4FN	15:1	100	15	1.7	41	12.5	32	22

* 115V, 1 phase, non-reversing

Table 3: Belt Speeds for Light Load Fixed Speed Parallel Shaft 60 HzGearmotors on 2200 Series Conveyors (Excluding Gang Drive)

Gearmotors*						speed	Drive	Driven
Part Number	Gear Ratio	RPM	In-lb	N-m	Ft/min	M/min	Pulley	Pulley
62M036PL4FN	36:1	42	36	4.1	13	4.0	28	32
62M036PL4FN	36:1	42	36	4.1	15	4.6	28	28
62M036PL4FN	36:1	42	36	4.1	21	6.4	32	22
62M036PL4FN	36:1	42	36	4.1	29	8.8	44	22
62M015PL4FN	15:1	100	15	1.7	35	10.7	28	28
62M015PL4FN	15:1	100	15	1.7	55	16.8	44	28

* 115V, 1 phase, non-reversing

Table 4: Belt Speeds for Standard Load Fixed Speed Parallel Shaft 60 HzGearmotors on MPD Series Conveyors

	Gearmotors*						Drive	Driven
Part Number	Gear Ratio	RPM	In-Ib	N-m	Ft/min	M/min	Pulley	Pulley
62M036PL4FN	36:1	42	36	4.1	25	7.5	28	32
62M036PL4FN	36:1	42	36	4.1	28	8.6	28	28
62M036PL4FN	36:1	42	36	4.1	45	13.6	44	28
62M036PL4FN	36:1	42	36	4.1	57	17.3	44	22

* 115V, 1 phase, non-reversing

Table 5: Belt Speeds for Light Load Variable Speed Parallel Shaft DCGearmotors on 2100, 4100 and 6200 Series Conveyors

	Gearmotors*						Drive	Driven
Part Number	Gear Ratio	RPM	In-Ib	N-m	Ft/min	M/min	Pulley	Pulley
62M060PLD3DEN	60:1	42	65	7.4	1.0-8.2	.3–2.5	22	32
62M060PLD3DEN	60:1	42	65	7.4	1.4–12	.4–3.6	32	32
62M018PLD3DEN	18:1	139	21	2.4	4.8–40	1.5–12	32	32
62M018PLD3DEN	18:1	139	21	2.4	7–58	2.1–18	32	22

* 130VDC

Specifications

Table 6: Belt Speeds for Standard Load Variable Speed Parallel Shaft DCGearmotors on 2200 Series Conveyors (Excluding Gang Drive)

	Gearmotors*						Drive	Driven
Part Number	Gear Ratio	RPM	In-lb	N-m	Ft/min	M/min	Pulley	Pulley
62M060PLD3DEN	60:1	42	65	7.4	1.8–14	.5–4.5	28	28
62M060PLD3DEN	60:1	42	65	7.4	2.8–23	.8–7	44	28
62M018PLD3DEN	18:1	139	21	2.4	6–49	1.8–15	28	28
62M018PLD3DEN	18:1	139	21	2.4	9–77	2.8–23	44	28

Table 7: Belt Speeds for Standard Load Variable Speed Parallel Shaft DCGearmotors on MPB Series Conveyors

	Belt S	peed	Drive	Driven				
Part Number	Gear Ratio	RPM	In-lb	N-m	Ft/min	M/min	Pulley	Pulley
62M060PLD3DEN	60:1	42	65	7.4	2.3–19	.7–5.9	22	32
62M060PLD3DEN	60:1	42	65	7.4	3.4–28	1–8.6	28	28
62M060PLD3DEN	60:1	42	65	7.4	5.3–44	1.6–13	44	28
62M018PLD3DEN	18:1	139	21	2.4	11–94	3.5–28	28	28
62M018PLD3DEN	18:1	139	21	2.4	16–148	5–45	44	28

* 130VDC

NOTE

For belt speed other than those listed, contact factory for details.

Installation

Required Tools

- Hex key wrenches: 2.5 mm, 3 mm & 5 mm
- Torque wrench

Installation Component List:

Ι	Bottom Mount Assembly

- J Driven Pulley
- K Cover
- L M4 Socket Head Screws (4x)
- M Timing Belt
- N Key
- O M6 Socket Head Screws (2x)

Mounting



1. Typical components (Figure 2)



Figure 2



2. Locate drive output shaft (Figure 3, item P) and remove two screws (Q).



Figure 3

3. For your reference, the following five figures show the attachment area of complete mounting packages for the various conveyor series.



2200 Series Figure 4

Installation



6200 Series





4100 Series

Figure 6



2100 Series Figure 7



MPB Series Figure 8

4. Attach mount assembly (Figure 9, item I) with screws (O). Tighten screws to 80 in-lb (9 Nm).



Figure 9



5. Install key (Figure 10, item N).



Figure 10

Installation

- 6. Wrap timing belt (M) around driven pulley (J) and drive pulley (R). Install driven pulley (J) onto conveyor shaft.
- 7. Remove cam bearing and spacer (Figure 9, item U). Place the cam bearing and spacer (Figure 11, item U) next to the driven pulley (J). Ensure the flanges of the driven pulley are aligned with the cam bearing. Tighten driven pulley set screws (T). This will allow for proper belt alignment while conveyor is in use. Replace cam bearing and spacer (U).



Figure 11

Depending on direction of conveyor belt travel (1 or 2 of Figure 12), position timing belt tensioner (U) as shown. Tension timing belt to obtain 1/8" (3 mm) deflection for 1 lb (456 grams) of force at timing belt mid-point (V). Tighten tensioner screw to 106 in-lb (12 Nm).



Figure 12

9. Install cover (Figure 13, item K) with four (4) screws (L). Tighten to 35 in-lb (4 Nm).



Figure 13

Preventive Maintenance and Adjustment

Required Tools

- Hex key wrenches: 2.5 mm, 3 mm, 5 mm
- Straight edge
- Screwdriver (for terminal box screws)
- Torque wrench

Timing Belt Tensioning



1. Remove four (4) screws (Figure 14, item L) and remove cover (K).



Figure 14

2. Loosen tensioner (Figure 15, item U).



Figure 15

Depending on direction of conveyor belt travel (1 or 2 of Figure 16), position timing belt tensioner (U) as shown. Tension timing belt to obtain 1/8" (3 mm) deflection for 1 lb (456 grams) of force at timing belt mid-point (V). Tighten tensioner screw to 106 in-lb (12 Nm).



Figure 16

4. Install cover (Figure 14, item K) with four (4) screws (L). Tighten screws to 35 in-lb (4 Nm).

Timing Belt Replacement



- 1. Remove four (4) screws (Figure 14, item L) and remove cover (K).
- 2. Loosen tensioner (Figure 15, item U).
- 3. Remove timing belt (Figure 17, item M).



Figure 17

Preventive Maintenance and Adjustment

NOTE

If timing belt does not slide over pulley flange, loosen driven pulley set screws (Figure 17, item T) and remove pulley with belt. For re-installation, see steps 6 through 9 on page 9.

- 4. Install new timing belt.
- Depending on direction of conveyor belt travel (Figure 16, item 1 or 2), position timing belt tensioner (U) as shown. Tension timing belt to obtain 1/8" (3 mm) deflection for 1 lb (456 grams) of force at timing belt mid-point (V). Tighten tensioner screw to 106 in-lb (12 Nm).
- 6. Install cover (Figure 14, item K) with four screws (L). Tighten screws to 4 Nm.

Drive or Driven Pulley Replacement



NOTE

If drive pulley (Figure 18, item R) is replaced, wrap timing belt (M) around drive pulley and complete step 3.



Figure 18

3. Complete steps 6 through 9 of "Installation" section on page 9.

Gearmotor Replacement

WARNING WARNING Exposed moving parts can cause severe injury. LOCK OUT POWER before removing guards or performing maintenance.

A DANGER



Hazardous voltage will cause severe injury or death. LOCK OUT POWER BEFORE WIRING.

- 1. For single phase motor, unplug power cord from outlet.
- 2. For DC variable speed motor, unplug motor cord at disconnect (Figure 19, item W).



Figure 19

- 3. Remove four screws (Figure 14, item L) and remove cover (K).
- 4. Loosen tensioner (Figure 15, item U).
- 5. Remove timing belt (Figure 17, item M).

Preventive Maintenance and Adjustment

NOTE

If timing belt does not slide over pulley flange, loosen driven pulley set screws (Figure 20, item T) and remove pulley with belt (M). For re-installation, see steps 6 through 9 on page 9.



Figure 20

6. Loosen two (2) set screws (Figure 21, item T). Remove drive pulley (R).



Figure 21

7. Remove four screws (Figure 22, item X) and detach gearmotor.



Figure 22

- 8. Mount new gearmotor with four screws (X). Tighten to 45 in-lb (5 Nm).
- 9. Replace drive pulley (Figure 21, item R) and tighten set screws (T).
- 10. Complete steps 6 through 9 of "Installation" section on page 9.
- 11. Replace wiring:
- For a single phase motor, reverse step 1 on page 11.
- For DC variable speed motor, reverse step 2 on page 11.

Notes

Service Parts

NOTE

For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo 🚌 . Dorner recommends keeping these parts on hand.

2100, 2200, 4100, 6200 Series and MPB Series Light Load Bottom Mount **Drive Package**



Item	Part Number	Description
1	202390M	Nut, Cam Follower
2	450027M	Drive Spacer (2100 – Cleated Belt and all
		6200)
	450377M	Drive Spacer (2100, 2200 and MPB – Flat
		Belt and all 4100)
3	450047M	Cover Mounting Bracket (Flat Belt)
	450375M	Cover Mounting Bracket (Cleated Belt and
		MPB)
4	200376M	Drive Guard (Flat Belt)
	450376M	Drive Guard (Cleated Belt and MPB)
5	450046M	Light Duty Motor Mount Plate – Short (Flat
		Belt, except MPB)
	450026M	Light Duty Motor Mount Plate (Cleated Belt
		and MPB)
	242532	Flush Top Mount Plate (Flush Drive only)
6	450445	Spacer (Fixed Speed Gearmotors only)
	450195	Spacer (Variable Speed
		Gearmotors only)
7	802–046	Bearing
8	807–226	Snap-out Plastic Plug
9	807–952	Groove Pin (Used with Item 2 Only)
10	920545M	Socket Head Screw M5x45mm – 15:1
		Gearhead (Fixed Speed Gearmotor Only)
	920555M	Socket Head Screw M5x55mm – 36:1
		Gearhead (Fixed Speed Gearmotor Only)
	920416M	Socket Head Cap Screw M4x16mm
		(Variable Speed Gearmotor Only)

ltem	Part Number	Description
11	980422M	Square Key, 0.4mm x 22mm (Fixed Speed
		Gearmotor)
	912–084	Square Key, 0.125" x 0.75" (Variable
		Speed Gearmotor)
12	920406M	Socket Head Screw M4 x 6mm
13	920408M	Socket Head Screw M4 x 8mm
14	920625M	Socket Head Screw M6 x 25mm (2100)
	920622M	Socket Head Screw M6 x 22mm (2200
		Cleated Belt and Flush Drive)
	920618M	Socket Head Screw M6 x 18mm (4100)
	920630M	Socket Head Screw M6 x 30mm (2200 Flat
		Belt and all 6200)
15	920840M	Socket Head Screw M8 x 40mm
16	980422M	Square Key 4mm x 22mm
	912–084	Square Key, 0.125" x 0.75" (1" Wide
		Conveyor – 4100 Only)
17	814-105	Timing Belt, 15mm W x 460mm L
	814-065	Timing Belt, 15mm W x 475mm L
	814-101	Timing Belt, 15mm W x 500mm L
	814-108	Timing Belt, 15mm W x 520mm L
18	450366MP	Driven Pulley, 22Tooth, 12mm bore
	450367MP	Driven Pulley, 28Tooth, 12mm bore
	450368MP	Driven Pulley,32Tooth, 12mm bore
	243325	Driven Pulley,16Tooth, 12mm bore (Flush Drive only)

2100, 2200, 4100, 6200 and MPB Series Bottom Mount Drive Package for Light Load 60 Hz Gearmotors Dorner Mfg. Corp. 14

Service Parts

ltem	PartNumber	Description
19	450384MP	Drive Pulley, 22Tooth, 10mm bore
	450385MP	Drive Pulley, 28Tooth, 10mm bore
	450386MP	Drive Pulley, 32Tooth, 10mm bore
	450387MP	Drive Pulley, 44Tooth, 10mm bore
	450556P	Drive Pulley, 22Tooth, 0.5" bore
	450556P	Drive Pulley, 28Tooth, 0.5" bore
	450556P	Drive Pulley, 32Tooth, 0.5" bore
	450556P	Drive Pulley, 44Tooth, 0.5" bore

4100 Series Adapter Package



Item	Part No.	Part Description
1	609486	Mounting Block 1" (25mm)
	609487	Mounting Block 2" (51mm)
	609488	Mounting Block 3" (76mm)
	609479	Mounting Block 4" (102mm)
	609480	Mounting Block 5" (127mm)
	609481	Mounting Block 6" (152mm)
	609482	Mounting Block 7" (178mm)
	609483	Mounting Block 8" (203mm)
	609484	Mounting Block 10" (254mm)
	609485	Mounting Block 12" (305mm)
2	613602P	Bolt & Flat Washer Assembly
3	450374	Drive Adapter Plate
4	910–126	Hex Nut with Lock Washer
5	930612M	Flat Head Screw M6 x 12mm

Gearmotors



Item	Part No.	Part Description
1	62M036PL411FN	Gearmotor, 0.03 hp, 115 Volts, 42 RPM, 60 Hz, 1-Phase, 36:1
	62M015PL411FN	Gearmotor, 0.03 hp, 115 Volts, 100 RPM, 60 Hz, 1-Phase, 15:1
	62M060PLD3DEN	Gearmotor, 0.06 hp, 130 Volts, 42 RPM, DC, 60:1
	62M018PLD3DEN	Gearmotor, 0.06 hp, 130 Volts, 139 RPM, DC, 18:1
	62M036PL423FN	Gearmotor, 0.03 hp, 230 Volts, 42 RPM, 60 Hz, 3-Phase, 36:1
	62M015PL423FN	Gearmotor, 0.03 hp, 230 Volts, 100 RPM, 60 Hz, 3-Phase, 15:1
	62M036PL423EN	Gearmotor, 0.03 hp, 230 Volts, 7-42 RPM, 60 Hz, 3-Phase, 36:1
	62M015PL423EN	Gearmotor, 0.03 hp, 230 Volts, 17- 100 RPM, 60 Hz, 3-Phase, 15:1
2	980422M	Key, 4mm x 22mm, 10mm Bore
	912–052	Key, 1/8" x 5/8", 1/2" Bore

Return Policy

Returns must have prior written factory authorization or they will not be accepted. Items that are returned to Dorner without authorization will not be credited nor returned to the original sender. When calling for authorization, please have the following information ready for the Dorner factory representative or your local distributor:

- 1. Name and address of customer.
- 2. Dorner part number(s) of item(s) being returned.
- 3. Reason for return.
- 4. Customer's original order number used when ordering the item(s).
- 5. Dorner or distributor invoice number (if available, part serial number).

A representative will discuss action to be taken on the returned items and provide a Returned Goods Authorization (RMA) number for reference. RMA will automatically close 30 days after being issued. To get credit, items must be new and undamaged. There will be a return charge on all items returned for credit, where Dorner was not at fault. It is the customer's responsibility to prevent damage during return shipping. Damaged or modified items will not be accepted. The customer is responsible for return freight.

Conveyors and conveyor accessories

Standard catalog conveyors	30%
MPB, 7200, 7300 Series, cleated and specialty belt	50%
AquaGard & AquaPruf Series conveyors	non-returnable items
Engineered to order products	case by case
Drives and accessories	30%
Sanitary stand supports	non-returnable items

Parts

Standard stock parts
Plastic chain, cleated and specialty belts

30% non-returnable items

Returns will not be accepted after 60 days from original invoice date. The return charge covers inspection, cleaning, disassembly, disposal and reissuing of components to inventory. If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Contact Dorner for the name of your local representative. Our Customer Service Team will gladly help with your questions on Dorner products.

For a copy of Dorner's Warranty, contact factory, distributor, service center or visit our website at www.dorner.com.

For replacement parts, contact an authorized Dorner Service Center or the factory.



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. © Dorner Mfg. Corp. 2010

DORNER MFG. CORP.

975 Cottonwood Ave., PO Box 20 Hartland, WI 53029-0020 USA TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA) Internet: www.dorner.com

Outside the USA: TEL 1-262-367-7600 FAX 1-262-367-5827