

Installation, Maintenance & Parts Manual

6100 Series Idler End Filler Kit 703617

Installation



1. Remove and discard tail screws (A of Figure 1).




Figure 1

2. Install square head bolt (B of Figure 2)in block (C) (Note orientation – block is not symmetrical).




Figure 2

3. Install block with square head bolt (D of Figure 3) with screw (E) to conveyor. Make sure edge of block (D) contacts head plate edge (F).




Figure 3

4. Adjust square head bolt (G of Figure 4) to contact conveyor frame (H).




Figure 4

5. Repeat steps 1–4 for opposite side of conveyor.

Belt Tensioning



1. Follow belt tensioning procedure in 851–268 "6100 Series End Drive Conveyors" manual.

2. Adjust square head bolt (G of Figure 5) to contact conveyor frame (H) on both sides of conveyor.





Figure 5

Belt Installation



1. Remove screw and filler block (D of Figure 6) on both sides of conveyor.




Figure 6

2. Follow belt installation instructions in 851–268 "6100 Series End Drive Conveyors" manual.

- **3.** Install block with square head bolt (D of Figure 3) with screw (E) to conveyor. Make sure edge of block (D) contacts head plate edge (F).
- **4.** Adjust square head bolt (G of Figure 7) to contact conveyor frame (H).




Figure 7

5. Repeat steps 3 and 4 for opposite side of conveyor.

Service Parts




Figure 8

4. M5x16mm Screw

1. Block RH	(694020)
2. Block LH	(694021)
3. Square Head Bolt	(807–1130)



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. ©Dorner Mfg. Corp. 2000

DORNER MFG. CORP. 580 Industrial Drive, PO Box 20 Hartland, WI 53029-0020 USA USA

TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA) Outside the USA:

TEL 1-262-367-7600, FAX 1-262-367-5827

DORNER

Arnold-Sommerfeld-Ring 2 D-52499 Baesweiler Germany TEL (02401) 80 52 90

FAX (02401) 80 52 93

Internet: www.dorner.com

(920593M)