

# 7200 Series Sanitary End Drive Conveyors

## Installation, Maintenance & Parts Manual



DORNER MFG. CORP. P.O. Box 20 • 975 Cottonwood Ave. Hartland, WI 53029-0020 USA INSIDE THE USA TEL: 1-800-397-8664 FAX: 1-800-369-2440 OUTSIDE THE USA TEL: 262-367-7600 FAX: 262-367-5827

For other service manuals visit our website at: www.dorner.com/service\_manuals.asp

# **Table of Contents**

Introduction
Warnings - General Safety
Product Description
Specifications 4
Installation
Required Tools 6
Recommended Installation Sequence
Conveyors Up to 12 ft (3658 mm) 6
Conveyors Longer Than 12 ft (3658 mm) 6
Attaching Conveyor to Stands or Mounting Brackets 7
Return Rollers 8
2" to 6" (44 mm to 152 mm) Wide Conveyor 8
8" to 18" (203 mm to 457 mm) Wide Flat
Belt Conveyors 8
Preventive Maintenance and Adjustment 10
Required Tools 10
Standard Tools 10
Special Tools 10
Checklist 10
Lubrication 10
Conveyor Bearings 10
Return Rollers 10
Maintaining Conveyor Belt 10
Troubleshooting 10
Cleaning 10
Conveyor Belt Replacement 10
Conveyor Belt Replacement Sequence 11
A – Belt Removal for Conveyor Without
Gearmotor Mounting Package or Stands 11
B – Belt Removal for Conveyor With Stands
and/or Gearmotor Mounting Package 11

A – Belt Installation for Conveyor without	
Gearmotor Mounting Package or Stands	13
B – Belt Installation for Conveyor with	
Gearmotor Mounting Package and/or Stands	13
Conveyor Belt Tensioning	13
Pulley Removal	
A – Drive Pulley Removal	14
B – Idler Pulley Removal	15
Bearing Replacement for Drive or Idler Pulley	15
Bearing Removal	15
Bearing Installation	16
Pulley Installation	16
A – Drive Pulley Installation	16
B – Idler Pulley Installation	17
Service Parts	18
Drive End Components	18
Tension End Components	19
Conveyor Frame and Extension	
-21 1" (25mm) Sanitary Bolt-On High Sides	
-22 2" (51mm) Sanitary Bolt - On High Sides	
-23 Sanitary Fully Adjustable UHMW Guide	23
-24 Sanitary Adjustable Width UHMW Guides 2	4
Sanitary 2" (51mm) Through 6" (152mm) Wide	
Flat or Cleated Belt Return Roller	25
Sanitary 8" (203mm) Through 18" (457mm) Wide	
Flat Belt Return Roller	
Conveyor Mounting Brackets	
Configuring Conveyor Belt Part Number	
Return Policy	28

# Introduction

#### IMPORTANT

Some illustrations may show guards removed. DO NOT operate equipment without guards.

Upon receipt of shipment:

- Compare shipment with packing slip. Contact factory regarding discrepancies.
- Inspect packages for shipping damage. Contact carrier regarding damage.
- Accessories may be shipped loose. See accessory instructions for installation.

Dorner's Limited Warranty applies.

Dorner 7200 Series conveyors are covered by Patent Nos. 5174435, 6109427 and corresponding patents and patent applications in other countries.

Dorner reserves the right to make changes at any time without notice or obligation.

Dorner has convenient, pre-configured kits of Key Service Parts for all conveyor products. These time saving kits are easy to order, designed for fast installation, and guarantee you will have what you need when you need it. Key Parts and Kits are marked in the Service Parts section of this manual with the Performance Parts Kits logo

# Warnings - General Safety



# **Product Description**

Refer to Figure 1 for typical conveyor components.

- A Conveyor B Gearmotor
- C Belt (Flat Belt Shown)
- D Mounting Plates
- E Return Roller
- F Support Stands
- G Motor Controller
- H Drive End
- I Tensioning End



# **Specifications**

#### Models

#### Flat Belt 7200 Series Sanitary Conveyor

#### Flat Belt 7200 Series Sanitary Conveyor

72 <u>B M WW LLLL P GG BB</u>



# Cleated Belt 7200 Series Sanitary Conveyor



\* See "Ordering and Specifications" Catalog for details.

## **Conveyor Supports:**

Maximum Distances:

J = 18" (457 mm)\*\*

K= 6 ft (1829 mm)\*\*\*

L= 18" (457 mm)

\*\* For Heavy Load Bottom Mount Package, mount support under gearmotor.

\*\*\* For conveyors longer than 12 ft (3658 mm), install support at frame joint.



Figure 2

# **Specifications**

## **Specifications:**

Conveyor Width Reference (WW)	02	03	04	05	06	08	10	12	18
Conveyor Belt Width	1.75 <sup>°°</sup> (44mm)	2.75 <sup>°°</sup> (70mm)	3.75 <sup>°°</sup> (95mm)	5 <sup>"</sup> (127mm)	6 <sup>"</sup> (152mm)	8 <sup>"</sup> (203mm)	10 <sup>"</sup> (254mm)	12 <sup></sup> (305mm)	18 <sup></sup> (457mm)
Maximum Conveyor Load* (See NOTE Below)	30 lb (14 kg)	35 lb (16 kg)	42 lb (19 kg)	50 lb (23 kg)	60 lb (27 kg)	70 lb (32 kg)	80 lb (36 kg)	80 lb (36 kg)	80 lb (36 kg)
Conveyor Start-up Torque*	4 in-lb (0.5 Nm)	5 in-lb (0.6 Nm)	6 in-lb (0.7 Nm)	7 in-lb (0.8 Nm)	8 in-lb (0.9 Nm)	10 in-lb (1.1 Nm)	12 in-lb (1.4 Nm)	14 in-lb (1.5 Nm)	15 in-lb (1.7 Nm)
Belt Travel		4.3" (109 mm) per revolution of pulley							
Maximum Belt Speed*	235 feet/minute (72 meters/minute)								
Belt Take-up			0.38 <sup></sup> (10	mm) of stro	ke = 0.75" (1	9 mm) of bel	t take-up		

Conveyor Length Reference (LL)	02	03	04	05	06	07	08	09	10	11	12	13**	14**	15**	16**	17**	18**
Conveyor Length	2-ft (610 mm)	3-ft (914 mm)	4-ft (1219 mm)	5-ft (1524 mm)	6-ft (1829 mm)	7-ft (2134 mm)	8-ft (2438 mm)	9-ft (2743 mm)	10-ft (3048 mm)	11-ft (3353 mm)	12-ft (3658 mm)	13-ft (3962 mm)**	14-ft (4267 mm)**	15-ft (4572 mm)**	16-ft (4877 mm)**	17-ft (5182 mm)**	18-ft (5486 mm)**

\* See "Ordering and Specifications" Catalog for details.

#### NOTE

Maximum conveyor loads are based on:

- Non-accumulating product
- Product moving towards gearmotor
- Conveyor being mounted horizontal
- Conveyor being located in a dry environment
- Conveyor with standard belt only

\*\* Lengths available only in 6" (152 mm) &wider conveyors.

## NOTE

7200 Series sanitary conveyors are shipped with a "belt travel direction" sticker (Figure 3, item M) installed. After drive is installed and tested, remove sticker.





## NOTE

Dorner recommends cleaning all the "food zones" prior to placing conveyor into service. Insure adequate access is provided for cleaning and servicing equipment so that the required level of hygiene can be maintained.

## NOTE

Conveyor MUST be mounted straight, flat, and level within confines of conveyor. Use a level (Figure 4, item N) during setup.



Figure 4

## **Required Tools**

- 10 mm wrench (for hexagon head fasteners)
- Level
- Torque wrench

# Recommended Installation Sequence

- Assemble conveyor (if required)
- Install stands (see accessory instructions)
- Attach stands/mounting brackets to conveyor (see page 7)
- Mount gearmotor mounting package (see accessory instructions)
- Attach return rollers (see page 8)
- Attach guides/accessories (see "Service Parts" section starting on page 18)

## Conveyors Up to 12 ft (3658 mm)

No assembly is required. Install stands/mounting brackets and return rollers. Refer to "Attaching Conveyor to Stands or Mounting Brackets" on page 7 and "Return Rollers" on page 8.

# Conveyors Longer Than 12 ft (3658 mm)

- 1. Typical components (Figure 5).
- O Conveyor frame extension
- P M6 x 10 mm Hex Head Cap Screws (12x)
- Q Connector Strips (2x)
- R Conveyor frame



#### Figure 5

2. Compress tensioning end (Figure 6). Refer to steps 4 and 5 under the "Belt Removal for Conveyor Without Gearmotor Mounting Package or Stands" on page 11.



#### Figure 6

3. Install frame connecting bar (Figure 7, item Q) on conveyor frame (R) with three screws (P). Do not tighten screws.



Figure 7

- 4. Repeat step 3 for other side of conveyor frame.
- 5. Install conveyor frame extension (Figure 8, item O) on frame connecting bar (Q) with three screws (P). Install three screws (P) on opposite side. Tighten all screws to 92 in-lb (10.4 Nm).



Figure 8

- 6. Install conveyor belt. Refer to steps 1 through 3 under "Belt Installation for Conveyor without Gearmotor Mounting Package or Stands" on page 13.
- 7. Tension conveyor belt. Refer to "Conveyor Belt Tensioning" on page 13.

#### Attaching Conveyor to Stands or Mounting Brackets

#### NOTE

Conveyor may be mounted using mounting brackets as shown in Figure 9 and Figure 10 or directly to support stands. For direct support stand mounting, see stand manual.

- 1. Typical mounting bracket components (Figure 9) (One Pair).
- S M6 x 10 mm Hex Head Cap Screw (4x)
- T M6 x 12 mm Hex Head Cap Screw (4x)
- U Stand/Conveyor Ear Mount Bracket (2x)
- V Clamp Plate, Flat Belt (2x) or
- W Clamp Plate, Cleated Belt (2x)



#### Figure 9

- 2. Attach clamp plate (Figure 9, item V or W) to stand/ conveyor ear mount bracket (U) with two screws (S). Do not tighten screws.
- Attach stand/conveyor ear mount bracket (Figure 10, item U) to bottom of conveyor (Z). Make sure notch (AA) on bracket straddles conveyor edge as shown. Snug-up two screws (S).



Figure 10

4. Repeat steps 2 and 3 for other mounting bracket(s). Tighten all screws (S) to 80 in-lb (9 Nm).

## **Return Rollers**

#### 2" to 6" (44 mm to 152 mm) Wide Conveyor

#### NOTE

No return rollers are required on conveyor lengths up to 7 ft (2134 mm). Use one pair of rollers centered between the tensioning and drive spindles on 8–15 ft (2438–4572 mm) conveyors. Use two pairs of rollers at one third distances between the tensioning and drive spindles on 16–18 ft (4877–5486 mm) conveyors.

- 1. Return roller components (Figure 11).
- AB Mounting Block
- AC Clamp Plate
- AD Hex Head Cap Screw M6–1.0 x 12mm (2x)



Figure 11

2. Loosely attach clamp plate (Figure 12, item AC) on mounting block (AB) with two screws (AD). Do not tighten screws.



#### Figure 12

3. Attach return roller assembly (Figure 13, item AE) on each side of conveyor (Z). Tighten screws (AD) to 80 in-lb (9 Nm).



Figure 13

4. On 8–18 ft (2338–5486 mm) conveyor, repeat step 3 as necessary for other return rollers.

#### 8" to 18" (203 mm to 457 mm) Wide Flat Belt Conveyors

#### NOTE

No return rollers are required on conveyor lengths up to 7 ft (2134 mm). Use one roller centered between the idler and drive spindles on 8–15 ft (2438–4572 mm) conveyors. Use two rollers at one third distances between the idler and drive spindles on 16–18 ft (4877– 5486 mm) conveyors.

- 1. Typical return roller components (Figure 14)
- AF Return Roller and Guard Assembly
- AG Return Roller Clamp Plate (2x)
- AH Hex Head Cap Screw M6–1.0 x 12mm (4x)



Figure 14

2. Loosely attach two clamp plates (Figure 15, item AG) on roller and guard assembly (AF) with four screws (AH). Do not tighten screws.



Figure 15

3. Attach return roller assembly (Figure 16, item AI) on conveyor (Z). Make sure return roller assembly is perpendicular with conveyor frame as shown. Tighten screws (Figure 15, item AH) to 80 in-lb (9 Nm).



Figure 16

4. On 16–18 ft (4877–5486 mm) conveyor, repeat step 3 for other return roller.

## **Required Tools**

#### **Standard Tools**

- Wrenches: 8 mm, 10 mm, 3/8" (or an adjustable wrench)
- Small bearing puller
- Arbor press

#### **Special Tools**

- 456063 Bearing Removal Tool
- 456085 Bearing Installation Tool

## Checklist

- Keep service parts on hand (see "Service Parts" section for recommendations)
- Keep supply of belt cleaner (part # 625619)
- Clean entire conveyor and knurled pulley while disassembled
- Replace worn or damaged parts

## Lubrication

#### **Conveyor Bearings**

No lubrication is required. Replace bearings if worn.

#### **Return Rollers**

No lubrication is required. Replace bearings if worn.

## **Maintaining Conveyor Belt**

### Troubleshooting

Inspect conveyor belt for:

- Surface cuts or wear
- Stalling or slipping
- Damage to V-guide

Surface cuts and wear indicate:

- Sharp or heavy parts impacting belt
- Jammed parts
- Improperly installed bottom wiper(s)
- Accumulated dirt in wiper(s)
- Foreign material inside the conveyor
- Improperly positioned accessories
- Bolt-on guiding is pinching belt

Stalling or slipping indicates:

- Excessive load on belt
- Conveyor belt or drive timing belt are not properly tensioned
- Worn knurl or impacted dirt on drive pulley
- Intermittent jamming or drive train problems

Damage to V-guide indicates:

- Twisted or damaged conveyor frame
- Dirt impacted on pulleys
- Excessive or improper side loading

### NOTE

Visit www.dorner.com for complete list of troubleshooting solutions.

#### Cleaning

### NOTE

Dorner recommends cleaning all the "food zones" prior to placing conveyor into service. Insure adequate access is provided for cleaning and servicing equipment so that the required level of hygiene can be maintained.

## IMPORTANT

Do not use belt cleaners that contain alcohol, acetone, Methyl Ethyl Ketone (MEK) or other harsh chemicals.

Use Dorner Belt Cleaner (part # 625619). Mild soap and water may also be used. Do not soak the belt.

For /05 woven polyester and /06 black anti-static belts, use a bristled brush to improve cleaning.

## **Conveyor Belt Replacement**



# Conveyor Belt Replacement Sequence (see Table of Contents for page number)

· Remove old conveyor belt

A - Conveyor without Gearmotor Mounting Package or Stands

B - Conveyor with Stands and/or Gearmotor Mounting Package

• Install new conveyor belt

A - Conveyor without Gearmotor Mounting Package or Stands

B - Conveyor with Stands and/or Gearmotor Mounting Package

• Tension conveyor belt

# A – Belt Removal for Conveyor Without Gearmotor Mounting Package or Stands

1. If installed, remove and retain two M5 hex head screws (Figure 17, item AJ), bottom wiper (AK) and two sleeves (AL).



Figure 17

- 2. If installed, repeat step 1 for tension end wiper.
- 3. If conveyor is equipped with guiding and accessories or return rollers, remove and retain them as necessary.
- 4. Loosen four M6 hex head cap screws (Figure 18, item AM) and (Figure 19, item AM).



Figure 18

5. Retract idler spindle assembly (Figure 19, item AN) by pushing in on it or by turning M6 hex head pinion screw (AO) clockwise.



Figure 19

6. Remove conveyor belt (Figure 20, item AP).



Figure 20

#### B – Belt Removal for Conveyor With Stands and/or Gearmotor Mounting Package

#### NOTE

For conveyor with a Heavy Load Bottom or Top Gearmotor Mounting Package, bracket (Figure 21, item AR) must be removed.

- Remove two M6x30 mm hex head cap screws and spacers (AQ).
- Remove two M6x16 mm hex head cap screws (AS).
- Remove bracket (AR).



Figure 21

- 1. If installed, remove and retain two M5 hex head screws (Figure 17, item AJ), bottom wiper (AK) and two sleeves (AL).
- 2. If installed, repeat step 1 for tension end wiper.
- 3. If conveyor is equipped with guiding and accessories or return rollers, remove and retain them as necessary.
- 4. Loosen four M6 x 20 mm hex head cap screws (Figure 18, item AM) and (Figure 19, item AM).
- 5. Retract idler spindle assembly (Figure 19, item AN) by pushing in on it or by turning M6 x 25 mm hex head pinion screw (Figure 19, item AO) and (Figure 20, item AO) clockwise.

## **WARNING**

The weight of the gearmotor is all on one end of the conveyor which could cause it to tip off the stands when the mounting clamp plates are loosened. Be sure to provide support (Figure 21, item AT) and (Figure 22, item AT) underneath the gearmotor while changing the belt.

6. Place a temporary support (Figure 21, item AT) and (Figure 22, item AT) under gearmotor mounting package.



Figure 22

7. Loosen two clamp plate screws (Figure 23, item S) on side of conveyor opposite drive motor.



Figure 23

- 8. Repeat step 7 for remaining stand/conveyor ear mount brackets or stand assemblies on same side of conveyor.
- 9. Raise conveyor and remove conveyor belt (Figure 24, item AP).



Figure 24

10. If a new belt will not be installed immediately, secure conveyor with stand/conveyor ear mount brackets or stand assemblies.

# A – Belt Installation for Conveyor without Gearmotor Mounting Package or Stands

 Orient conveyor belt so the splice leading fingers (Figure 25, item AV) point in the direction of belt travel (AW) as identified by the label (Figure 26, item AU).



Figure 25

- 2. Slide belt (Figure 20, item AP) onto the conveyor frame assembly.
- 3. If removed, install sleeves (Figure 17, item AL), bottom wiper(s) (AK) and M5 hex head screws (AJ). Tighten screws to 33 in-lb (3.7 Nm).
- 4. Tension belt. Refer to "Conveyor Belt Tensioning" on page 13.
- 5. If removed, install return rollers, guiding and accessories.

#### B – Belt Installation for Conveyor with Gearmotor Mounting Package and/or Stands

#### IMPORTANT

Do not use belt cleaners that contain alcohol, acetone, Methyl Ethyl Ketone (MEK) or other harsh chemicals.



Figure 26

- 1. Orient conveyor belt so that the splice leading fingers (Figure 25, item AV) point in the direction of belt travel (AW) as identified by the label (Figure 26, item AU).
- 2. Slide belt (Figure 24, item AP) onto conveyor frame assembly.
- 3. Tighten two clamp plate screws (Figure 23, item S)

- 4. Repeat step 3 for remaining stand/conveyor ear mount brackets or stand assemblies.
- 5. If removed, install sleeves (Figure 17, item AL), bottom wiper(s) (AK) and M5 hex head screws (AJ). Tighten screws to 33 in-lb (3.7 Nm).
- 6. For a conveyor with a Heavy Load Bottom or Top Mounting package, install bracket (Figure 21, item AR).
- Tension belt. Refer to "Conveyor Belt Tensioning" on page 13.
- 8. If removed, install return rollers, guiding and accessories.

## **Conveyor Belt Tensioning**



injury. LOCK OUT POWER before removing guards or performing maintenance.

1. On tension end of the conveyor, loosen two M6 hex head cap screws (Figure 27, item AM) on each side of conveyor.



Figure 27

### NOTE

Do not exceed a torque of 25 in-lb (2.8 Nm) for 2" through 12" (44 mm through 305 mm) wide conveyors or 40 in-lb (4.5 Nm) for an 18" (457 mm) wide conveyor on tensioning screw (AX). Over-tensioning the conveyor belt could cause excessive pulley bearing load and early failure.

- 2. Extend idler spindle assembly (AN) by turning M6 hex head screw (AX) clockwise to sufficiently tension belt to handle conveyor load.
- 3. Tighten four M6 hex head screws (AM) to 40 in-lb (4.5 Nm) to secure idler spindle assembly (AN).

#### NOTE

If the maximum take-up stroke is achieved, replace the conveyor belt.

## Pulley Removal



Remove conveyor belt to access pulley(s). See "Conveyor Belt Replacement" on page 10. Remove the desired pulley following instructions:

- A Drive Pulley Removal
- B Idler Pulley Removal

#### A – Drive Pulley Removal



1. Remove the gearmotor mounting package. See accessory instructions.

### NOTE

Two screws (Figure 28, item AY) were removed in step 1.

Cross support post (Figure 30, item BC) will not be secure and may drop when screws (Figure 28, item AZ) and (Figure 29, item AZ) are removed.

2. Remove screw (Figure 28, item AZ) and (Figure 29, item AZ) from each side of conveyor.



Figure 28

## NOTE

For a conveyor with a Heavy Load Bottom or Top Gearmotor Mounting Package, the two screws (Figure 29, item BA) were removed in step 1.

Drive spindle assembly (Figure 29, item BB) will not be secure and may drop when screws (Figure 28, item AZ and BA) and (Figure 29, item AZ and BA) are removed.

3. Remove two screws (Figure 29, item BA) from side of conveyor opposite drive shaft.



#### Figure 29

- 4. Remove drive spindle assembly (BB).
- 5. Remove cross support post (Figure 30, item BC).
- 6. Remove two head plates (BD).
- 7. Remove drive pulley and bearing assembly (BE).

## NOTE

If bearings require removal from drive pulley, see "Bearing Removal" on page 15.



Figure 30

#### **B** – Idler Pulley Removal

While holding hex pinion (Figure 31, item BF) with a 3/ 1. 8" open-end wrench, loosen M6 hex head cap screw (AO).



2. Remove M6 hex head cap screw (Figure 32, item AO) and sleeve (BG) from conveyor (Z) and hex pinion (BF).



- Repeat steps 1 and 2 for screw (Figure 27, item AX) and 3. (Figure 33, item AX) on opposite side of conveyor.
- 4. Remove two M6 hex head cap screws (AM) from each side of conveyor.
- 5. Remove two pinion ends (Figure 33, item BH), clamp blocks (BI), hex pinion (BF), two spacers (BJ) and tail assembly (AN) from conveyor (Z).



Figure 33

Remove two head plates (Figure 34, item BK) from 6. spindle and bearing assembly (BL).



Figure 34

#### **Bearing Replacement for Drive or Idler Pulley**

#### IMPORTANT

Once removed, do not re-use bearings.

#### **Bearing Removal**

Place bearing removal tool (Figure 35, item BM) (part # 1. 456063) below bearing (BN) with lip (BO) located in gap (BP) between bearing and spindle hub (BQ) as shown.





2. Using a puller (Figure 36, item BR), remove and discard bearing.



Figure 36

#### **Bearing Installation**

- 1. Inspect bearing seating surface(s) for damage. Replace spindle if damaged.
- 2. Slide bearing (part # 240338) (Figure 37, item BN) onto spindle (BQ).



Figure 37

3. Slide sleeve (Figure 38, item BU) of tool (part # 456085) over bearing.



Figure 38

4. Place open end of pusher (Figure 39, item BV) into sleeve.



Figure 39

5. Using an arbor press or similar device, press bearing onto pulley shaft (Figure 40).



Figure 40

6. Repeat steps 1 through 5 for each bearing.

## **Pulley Installation**

#### A – Drive Pulley Installation

1. Reverse the removal procedure "A" (see page 14).

#### **B** – Idler Pulley Installation

#### **IMPORTANT**

Loosely install two spacers (Figure 33, item BJ) and (Figure 41, item BJ) and four screws (AM) prior to installing idler tail assembly (AN) on conveyor.



Figure 41

#### IMPORTANT

During idler pulley installation, orient both pinion ends (Figure 42, item BH) so they engage the same tooth positions on their respective racks.



Figure 42

1. Reverse the removal procedure "B" (see page 15).

## NOTE

For replacement parts other than those shown in this section, contact an authorized Dorner Service Center or the factory. Key Service Parts and Kits are identified by the Performance Parts Kits logo C. Dorner recommends keeping these parts on hand.

## **Drive End Components**



Item	Part Number	Description
1	807–1263	Plastic Hole Plug
2	456005	Head Plate Fixed w/o Wiper
	450646	Head Plate Fixed w/Wiper LH
	450647	Head Plate Fixed w/Wiper RH
3	240338	Bearing Spherical OD
4	4564 <u>WW</u>	Drive Spindle
5	980422MSS	Square Key 4mm x 22mm
6	4588 <u>WW</u>	Cross Support Post
7	960620MSS	Hex Head Cap Screw M6–1.0x20mm
8	960616MSS	Hex Head Cap Screw M6–1.0x16mm
9	4557 <u>WW</u>	Washdown Wiper
10	456049	Sleeve
11	960520MSS	Hex Head Cap Screw M5–0.80 x 20mm

Item	Part Number	Description
12	456034	Name Tag
13	914–008	Rivet
14	807–1301	Spacer
15	960612MSS	Hex Head Cap Screw M6–1.0x12mm
16	4525 <u>WW</u> MSS	Frame Support Post
17	72DT– <u>WW</u>	Drive Tail Kit w/o Wiper (Includes Items 1 through 8)
	72DTWA- <u>WW</u>	Drive Tail Kit w/Wiper – Shaft Position A or B (Includes Items 1 through 11)
	72DTWD- <u>WW</u>	Drive Tail Kit w/Wiper – Shaft Position C or D (Includes Items 1 through 11)
18 <b>D</b>	72DS- <u>WW</u>	Drive Spindle Kit (Includes Items 1, 3, 4 and 5)
$\underline{WW} = 0$	Conveyor width ref.:	02, 03, 04, 05, 06, 08, 10, 12, 18

## **Tension End Components**



Item	Part Number	Description	
1	4525 <u>WW</u> SS	Frame Support Post	
2	960612MSS	Hex Head Cap Screw M6-1.0x12mm	
3	960625MSS	Hex Head Cap Screw M6–1.0x25mm	
4	960620MSS	Hex Head Cap Screw M6–1.0x20mm	
5	456064	Head Plate Spacer	
6	807–1263	Plastic Hole Plug	
7	456003	Head Plate Tension RH w/o Wiper	
	450645	Head Plate Tension RH w/Wiper	
8	240338	Bearing Spherical OD	
9	4561 <u>WW</u>	Idler Spindle	
10	456002	Head Plate TensionLH w/o Wiper	
	450644	Head Plate Tension LH w/Wiper	

Item	Part Number	Description			
11	456049	Sleeve .312 OD x .035 Wall			
12	456045	Pinion End			
13	456041	Clamp Block			
14	4563 <u>WW</u>	Hex Pinion			
15	4557 <u>WW</u>	Washdown Wiper			
16	456049	Sleeve			
17	960520MSS	Hex Head Cap Screw M5–0.80 x 20mm			
18	72TT– <u>WW</u>	Tension Tail Kit w/o Wiper (Includes Items 3 through 14)			
	72TTW- <u>WW</u>	Tension Tail Kit w/Wiper (Includes Items 3 through 17)			
19 <b>D</b>	72TS– <u>WW</u>	Tension Spindle Kit (Includes Items 6, 8 and 9)			
<u>WW</u> =	Conveyor width	ref.: 02, 03, 04, 05, 06, 08, 10, 12, 18			

## **Conveyor Frame and Extension**



Item	Part Number	Description
1	456046	Frame Connecting Bar
2	960610MSS	Hex Head Cap Screw M6– 1.0x10mm

Item	Part Number	Description
3	See Conveyor Frame chart	Conveyor Frame
4	See Conveyor Frame chart	Conveyor Frame Extension

Items 3 and 4: Conveyor Frame						
Length	Frame Part Number	Frame Extension Part Number				
2' (610mm)	4730 <u>WW</u> –01860	n/a				
3' (914mm)	4730 <u>WW</u> –03060	n/a				
4' (1219mm)	4730 <u>WW</u> –04260	n/a				
5' (1524mm)	4730 <u>WW</u> –05460	n/a				
6' (1829mm)	4730 <u>WW</u> –06660	n/a				
7' (2134mm)	4730 <u>WW</u> –07860	n/a				
8' (2438mm)	4730 <u>WW</u> –09060	n/a				
9' (2743mm)	4730 <u>WW</u> –10260	n/a				

Items 3 and 4: Conveyor Frame						
Length	Frame Part Number	Frame Extension Part Number				
10' (3048mm)	4730 <u>WW</u> –11460	n/a				
11' (3353mm)	4730 <u>WW</u> –12660	n/a				
12' (3658mm)	4730 <u>WW</u> -13860	n/a				
13' (3962mm)	4730 <u>WW</u> –07860	4750 <u>WW</u>				
14' (4267mm)	4730 <u>WW</u> –09060	4750 <u>WW</u>				
15' (4572mm)	4730 <u>WW</u> -10260	4750 <u>WW</u>				
16' (4877mm)	4730 <u>WW</u> –11460	4750 <u>WW</u>				
17' (5182mm)	4730 <u>WW</u> –12660	4750 <u>WW</u>				
18' (5486mm)	4730 <u>WW</u> –13860	4750 <u>WW</u>				

## -21 1" (25mm) Sanitary Bolt-On High Sides



Item	Part Number	Description
1	462150MSS	1" Guide Mounting Bracket Guide
2	See chart below	1" Guide LH
3	See chart below	1" Guide RH
4	450188SS	Tie Plate
5	960608MSS	M6–1.0 x 8mm Hex Head Screw
6	960506MSS	M5–0.8 x 6mm Hex Head Screw
7	990508MSS	M5 Acorn Nut

Conveyor Length		Tail End Guide	Center Guide	Drive End Guide
2'	Right Hand	462132SSP	N/A	N/A
(610mm)	Left Hand	462132SSP	N/A	N/A
3'	Right Hand	462133SSP	N/A	N/A
(914mm)	Left Hand	462133SSP	N/A	N/A
4'	Right Hand	462134SSP	N/A	N/A
(1219mm)	Left Hand	462134SSP	N/A	N/A
5'	Right Hand	462135SSP	N/A	N/A
(1524mm)	Left Hand	462135SSP	N/A	N/A
6'	Right Hand	462136SSP	N/A	N/A
(1829mm)	Left Hand	462136SSP	N/A	N/A
7'	Right Hand	462137SSP	N/A	N/A
(2134mm)	Left Hand	462137SSP	N/A	N/A
8'	Right Hand	462154SSP	N/A	462144SSP
(2438mm)	Left Hand	462144SSP	N/A	462154SSP
9'	Right Hand	462155SSP	N/A	462144SSP
(2743mm)	Left Hand	462145SSP	N/A	462154SSP
10'	Right Hand	462155SSP	N/A	462145SSP
(3048mm)	Left Hand	462145SSP	N/A	462155SSP

Conveyor Length		Tail End Guide	Center Guide	Drive End Guide
11'	Right Hand	462156SSP	N/A	462145SSP
(3353mm)	Left Hand	462146SSP	N/A	462155SSP
12'	Right Hand	462156SSP	N/A	462146SSP
(3658mm)	Left Hand	462146SSP	N/A	462156SSP
13'	Right Hand	462156SSP	462163SSP	462144SSP
(3962mm)	Left Hand	462146SSP	462163SSP	462154SSP
14'	Right Hand	462156SSP	462163SSP	462145SSP
(4267mm)	Left Hand	462146SSP	462163SSP	462155SSP
15'	Right Hand	462156SSP	462163SSP	462146SSP
(4572mm)	Left Hand	462146SSP	462163SSP	462156SSP
16'	Right Hand	462156SSP	462166SSP	462144SSP
(4877mm)	Left Hand	462146SSP	462166SSP	462154SSP
17' (5182mm)	Right Hand	462156SSP	462166SSP	462145SSP
	Left Hand	462146SSP	462166SSP	462155SSP
18'	Right Hand	462156SSP	462166SSP	462146SSP
(5486mm)	Left Hand	462146SSP	462166SSP	462156SSP

## -22 2" (51mm) Sanitary Bolt - On High Sides



Item	Part Number	Description		
1	462250MSS	2" Guide Mounting Bracket Guide		
2	See chart below	2" Guide LH		
3	See chart below	2" Guide RH		
4	450188SS	Guide Tie Plate		
5	960608MSS	M6–1.0 x 10mm Hex Head Screw		
6	960506MSS	M5–0.8 x 6mm Hex Head Screw		
7	990508MSS	M5 Acorn Nut		

Conveyor Length		Tail End Guide	Center Guide	Drive End Guide
2'	Right Hand	462232SSP	N/A	N/A
(610mm)	Left Hand	462232SSP	N/A	N/A
3'	Right Hand	462233SSP	N/A	N/A
(914mm)	Left Hand	462233SSP	N/A	N/A
4'	Right Hand	462234SSP	N/A	N/A
(1219mm)	Left Hand	462234SSP	N/A	N/A
5'	Right Hand	462235SSP	N/A	N/A
(1524mm)	Left Hand	462235SSP	N/A	N/A
6'	Right Hand	462236SSP	N/A	N/A
(1829mm)	Left Hand	462236SSP	N/A	N/A
7'	Right Hand	462237SSP	N/A	N/A
(2134mm)	Left Hand	462237SSP	N/A	N/A
8'	Right Hand	462254SSP	N/A	462244SSP
(2438mm)	Left Hand	462244SSP	N/A	462254SSP
9'	Right Hand	462255SSP	N/A	462244SSP
(2743mm)	Left Hand	462245SSP	N/A	462254SSP
10'	Right Hand	462255SSP	N/A	462245SSP
(3048mm)	Left Hand	462245SSP	N/A	462255SSP

Conveyor Length		Tail End Guide	Center Guide	Drive End Guide
11'	Right Hand	462256SSP	N/A	462245SSP
(3353mm)	Left Hand	462246SSP	N/A	462255SSP
12'	Right Hand	462256SSP	N/A	462246SSP
(3658mm)	Left Hand	462246SSP	N/A	462256SSP
13'	Right Hand	462256SSP	462263SSP	462244SSP
(3962mm)	Left Hand	462246SSP	462263SSP	462254SSP
14'	Right Hand	462256SSP	462263SSP	462245SSP
(4267mm)	Left Hand	462246SSP	462263SSP	462255SSP
15'	Right Hand	462256SSP	462263SSP	462246SSP
(4572mm)	Left Hand	462246SSP	462263SSP	462256SSP
16'	Right Hand	462256SSP	462266SSP	462244SSP
(4877mm)	Left Hand	462246SSP	462266SSP	462254SSP
17' (5182mm)	Right Hand	462256SSP	462266SSP	462245SSP
	Left Hand	462246SSP	462266SSP	462255SSP
18'	Right Hand	462256SSP	462266SSP	462246SSP
(5486mm)	Left Hand	462246SSP	462266SSP	462256SSP



	-23	Sanitary	/ Fully	Ad	justable	UHMW	Guide
--	-----	----------	---------	----	----------	------	-------

Item	Part Number(s)	Description
1	462332	Guide Mounting Rail 2' (610mm)
	462333	Guide Mounting Rail 3' (914mm)
	462334	Guide Mounting Rail 4' (1219mm)
	462335	Guide Mounting Rail 5' (1524mm)
	462336	Guide Mounting Rail 6' (1829mm)
	462337	Guide Mounting Rail 7' (2134mm)
	462338	Guide Mounting Rail 8' (2438mm)
	462339	Guide Mounting Rail 9' (2743mm)
	462340	Guide Mounting Rail 10' (3053mm)
	462341	Guide Mounting Rail 11' (3353mm)
	462342	Guide Mounting Rail 12' (3658mm)
	462337 462336	Guide Mounting Rail 13' (3962mm)
	462337 462337	Guide Mounting Rail 14' (4267mm)
	462338 462337	Guide Mounting Rail 15' (4572mm)
	462338 462338	Guide Mounting Rail 16' (4877mm)
	462339 462338	Guide Mounting Rail 17' (5182mm)
	462339 462339	Guide Mounting Rail 18' (5486mm)

Item	Part Number(s)	Description
2	462351MSS	Shaft Brace
3	462352SS	Horizontal Shaft Mounting Guide
4	462350MSS	Vertical Shaft Adjustable Guide
5	911–201	Flat Washer
6	807–978	Guide Clamp
7	450187MSS	Cross Block
8	960608MSS	Hex Head Screw (Metric) M6–1.0 x 8mm
9	960650MSS	Hex Head Screw (Metric) M6–1.0 x 50mm
10	807–948	Cap, Vinyl
11	462300MSS	Support Assembly, Adjustable Guide (Includes Items: 2 through 10)

## -24 Sanitary Adjustable Width UHMW Guides



Item	Part Number(s)	Description
1	462332	Guide Mounting Rail 2' (610mm)
	462333	Guide Mounting Rail 3' (914mm)
	462334	Guide Mounting Rail 4' (1219mm)
	462335	Guide Mounting Rail 5' (1524mm)
	462336	Guide Mounting Rail 6' (1829mm)
	462337	Guide Mounting Rail 7' (2134mm)
	462338	Guide Mounting Rail 8' (2438mm)
	462339	Guide Mounting Rail 9' (2743mm)
	462340	Guide Mounting Rail 10' (3053mm)
	462341	Guide Mounting Rail 11' (3353mm)
	462342	Guide Mounting Rail 12' (3658mm)
	462337 462336	Guide Mounting Rail 13' (3962mm)
	462337 462337	Guide Mounting Rail 14' (4267mm)
	462338 462337	Guide Mounting Rail 15' (4572mm)
	462338 462338	Guide Mounting Rail 16' (4877mm)
	462339 462338	Guide Mounting Rail 17' (5182mm)
	462339 462339	Guide Mounting Rail 18' (5486mm)

Item	Part Number(s)	Description
2	462452MSS	Horizontal Shaft Gullwing Guide
3	462450MSS	Vertical Shaft Gullwing Guide
4	807–977	Acorn Nut
5	807–978	Guide Clamp
6	450187MSS	Cross Block
7	807–948	Cap, Vinyl
8	960612MSS	Hex Head Cap Screw M6–1.0 x 12mm
9	970620MSS	Socket Head Set Screw M6–1.0 x 20mm
10	462400MSS	Support Assembly, Gull Wing (Includes Items: 2 through 7)

# Sanitary 2" (51mm) Through 6" (152mm) Wide Flat or Cleated Belt Return Roller



Item	Part Number	Description	ľ	Item	Part Number	Description
1	450593	Clamp Plate		5	960612MSS	Hex Head Screw M6-1.0 x 12mm
2	450596	Mounting Block		6	450594	Return Roller Assembly
3	802–123	Bearing		7 🖸	450595	Roller Assembly (3 piece)
4	913–103	Dowel Pin				

## Sanitary 8" (203mm) Through 18" (457mm) Wide Flat Belt Return Roller



Item	Part Number	Description
1	960612MSS	Hex Head Cap Screw M6–1.0 x 12mm
2	450628	Clamp Plate
3	990408MSS	Acorn Nut M4–0.70
4	4516 <u>WW</u>	Return Roller Guard

Item	Part Number	Description	
5	960435MSS	Hex Head Cap Screw M4–0.70 x 35mm	
6	450626	Mounting Block	
7 🗖	4517 <u>WW</u>	Shaft/Bearing Assembly	
8	4514 <u>WW</u>	Return Roller Assembly	
<u>WW</u> = Conveyor width ref.: 08, 10, 12, 18			

## **Conveyor Mounting Brackets**



	•				
	]	Item	Part Number	Description	
m		5	492566SS	Clamp Plate – Cleated Belt	
		6	450589	Mount Assembly – Flat Belt	
m		7	450591	Mount Assembly – Cleated Belt	

Item	Part Number	Description
1	960612MSS	Hex Head Cap Screw M6–1.0 x 12mm
2	450590	Stand/Conveyor Ear Mount Bracket
3	960610MSS	Hex Head Cap Screw M6–1.0 x 10mm
4	492564SS	Clamp Plate – Flat Belt

### **Configuring Conveyor Belt Part Number**



Figure 43

#### Flat Belt

Refer to your serial and model number plate (Figure 43). From the model number, determine conveyor width (WW), length (LLLL) and belt type (BB). Use data to configure belt part number as indicated below.

#### 7D-WWLLLL/BBV



#### EXAMPLE:

#### 721M030200A0102 Conveyor

7200 Series end drive, flat belt conveyor with mounting brackets, USA English, 3" (76mm) wide x 2.0 ft (610mm) long, shaft position A, guide profile 01 and belt type /02 (general purpose)

#### 72-030200/02V Belt

#### **Cleated Belt**

Refer to your serial and model number plate (Figure 43). From the model number, determine conveyor type (D), width (WW), length (LLLL), belt cleat type (B), and cleat spacing (SSSS). Use data to configure belt part number as indicated below.

#### 7<u>D</u>–<u>WWLLLLBSSSS</u>V



#### EXAMPLE:

#### 74AM030200A0659 Conveyor

7200 Series standard cleated belt conveyor with mounting brackets, A–style cleat, USA English, 3" (76mm) wide x 2.0 ft (610mm) long, shaft position A, and 6.59 in (167.4mm) cleat spacing

#### 74-030200A0659V Belt

# **Return Policy**

Returns must have prior written factory authorization or they will not be accepted. Items that are returned to Dorner without authorization will not be credited nor returned to the original sender. When calling for authorization, please have the following information ready for the Dorner factory representative or your local distributor: 1. Name and address of customer. 2. Dorner part number(s) of item(s) being returned. 3. Reason for return. 4. Customer's original order number used when ordering the item(s). 5. Dorner or distributor invoice number. A representative will discuss action to be taken on the returned items and provide a Returned Goods Authorization number for reference. There will be a return charge on all new undamaged items returned for credit where Dorner was not at fault. Dorner is not responsible for return freight on such items. Conveyors and conveyor accessories Standard catalog conveyors 30% MPB Series, cleated and specialty belt conveyors 50% 7400 & 7600 Series conveyors non-returnable items Engineered special products case by case Drives and accessories 30% Sanitary stand supports non-returnable items Parts Standard stock parts 30% MPB, cleated and specialty belts non-returnable items

Returns will not be accepted after 60 days from original invoice date.

The return charge covers inspection, cleaning, disassembly, disposal and reissuing of components to inventory.

If a replacement is needed prior to evaluation of returned item, a purchase order must be issued. Credit (if any) is issued only after return and evaluation is complete.

Dorner has representatives throughout the world. Contact Dorner for the name of your local representative. Our Technical Sales, Catalog Sales and Service Teams will gladly help with your questions on Dorner products.

For a copy of Dorner's Warranty, contact factory, distributor, service center or visit our website at www.dorner.com.

For replacement parts, contact an authorized Dorner Service Center or the factory.



Dorner Mfg. Corp. reserves the right to change or discontinue products without notice. All products and services are covered in accordance with our standard warranty. All rights reserved. © Dorner Mfg. Corp. 2006 DORNER MFG. CORP.

975 Cottonwood Ave., PO Box 20 Hartland, WI 53029-0020 USA USA TEL 1-800-397-8664 (USA) FAX 1-800-369-2440 (USA) Internet: www.dorner.com

Outside the USA: TEL 1-262-367-7600 FAX 1-262-367-5827

Printed in U.S.A.